

PilotStar[®] NX Operator Unit

Software Version E00.20 and higher

Operator and Service Manual

102-820.NG001



Dieses Dokument sowie dessen Inhalt sind urheberrechtlich geschützt. Die Weitergabe, Vervielfältigung und Speicherung sowie die Übersetzung wie auch Verwendung dieses Dokuments oder dessen Inhalts, als Ganzes oder in Teilen und egal in welcher Form, ist ohne vorherige ausdrückliche schriftliche Genehmigung nicht gestattet. Zuwiderhandlungen verpflichten zu Schadenersatz.

Änderungen dieses Dokuments und dessen Inhalt bleiben vorbehalten.

This document and its content are copyright protected. Distribution, reproduction and storage as well as translation and exploitation of this document and its content, in whole or in parts and regardless of what form, are prohibited without prior express written permission. Offenders will be held liable for the payment of damages.

Changes and modification to this document and its content reserved.

Table of Content

0	Introduction.....	1
0.1	Preliminary Remarks.....	1
0.2	Change History.....	2
0.3	Safety.....	2
0.3.1	General Safety Regulations.....	2
0.3.2	General Safety Instructions.....	3
0.4	List of Further Documents.....	5
0.5	Test Standards.....	6
1	Description.....	7
1.1	Intended Purpose.....	7
1.2	Use Limitations.....	7
1.3	Application Cases.....	8
1.3.1	NautoSteer AS Integration.....	8
1.3.2	Standalone.....	9
1.4	Modes of Operation.....	10
1.4.1	Active Modes.....	10
1.4.1.1	Heading Control (HDG).....	10
1.4.1.2	Waypoint Steering (NAV).....	10
1.4.1.3	Manual Steering via Operation Unit (NFU/FU).....	11
1.4.2	Inactive Modes.....	11
1.4.2.1	Manual Steering via External Source / Standby.....	11
1.4.2.2	Override.....	11
1.4.2.3	Not Activatable.....	11
1.5	Multiple PilotStar® NX Operator Units.....	12
1.5.1	Master - Slave Installation.....	12
1.5.2	Master - Master Installation.....	12
1.6	Rear Steering Stand.....	13
1.7	Operating Elements.....	13
1.8	LEDs.....	15
1.8.1	Button LEDs.....	15
1.8.2	PCB LEDs.....	16
1.9	Interfaces.....	17
1.9.1	Interface Inputs and Outputs.....	17
1.9.2	Plug Assignment / Interfaces.....	17
1.10	Output Relays.....	18
1.11	Sensor Data.....	19

1.11.1	Heading	19
1.11.2	Speed	19
1.11.3	Time.....	19
1.12	Condition-Based Input Parameters	19
1.13	Monitoring and Limit Functions.....	19
1.13.1	Rudder Angle Limit	19
1.13.2	Heading Monitor.....	20
1.13.3	Off Heading.....	20
1.13.4	Cross Track Error Limit	20
1.13.5	Course Trim Limit.....	20
1.14	Bridge Alert Management.....	21
1.15	Technical Data	24
1.16	CAN Bus	26
2	Mounting	27
3	Installation.....	29
3.1	Establish a Common Ground Point	29
3.2	Proper Cable Connections	30
3.3	Installation for BNWAS / BAM	31
3.4	Connection Overview	32
3.5	Connect Supply Voltage.....	33
3.6	Connect Dual CAN Bus.....	33
3.7	Connect RS422 Serial Inputs / Outputs.....	35
3.8	Connect Alarm and Status Outputs (Relays).....	37
4	Operation	39
4.1	Safety Information	39
4.2	Switching On and Off	39
4.3	General Display Elements for Operation	39
4.3.1	Day / Night Softkey	39
4.3.2	Limits Indicator	40
4.3.3	Status Header Line	40
4.3.4	Alert Messages Indication	41
4.3.5	Parameter Indicator.....	41
4.3.6	Value / Speed Indicator.....	42
4.3.7	Operation Mode Softkeys.....	43
4.4	Operation Displays Pages.....	45
4.4.1	HDG Main	45
4.4.2	NAV Main.....	48
4.4.3	NFU/FU Main	50
4.4.4	HDG & Rudder Plot.....	52
4.4.5	Track Data	54

4.4.6	Limits	56
4.4.7	Speed Selection.....	58
4.4.8	HDG Selection.....	59
4.4.9	Parameter Memory	61
4.4.10	Parameter Modify	63
4.4.11	RoT & Radius	64
4.4.12	Ship Data.....	66
4.4.13	Simplified View	67
4.5	Inactive Modes.....	69
4.6	Basic Operating Steps	70
4.6.1	Adjust RoT or Radius Controlled Heading changes	70
4.6.2	Set Digital NFU Tiller	71
4.6.3	Set Digital FU Tiller.....	72
4.6.4	Heading Control Mode Operating Steps	73
4.6.4.1	Change Set Heading via Rotary Knob - Preselected Mode	73
4.6.4.2	Change Set Heading via Rotary Knob - Direct Mode.....	73
4.6.4.3	Change Set Heading via Fix Turn.....	73
4.6.4.4	Using HDG Trim Function	75
5	Service and Configuration.....	76
5.1	Safety Information.....	76
5.2	Setting Reset	76
5.3	Service Menu.....	77
5.3.1	Open Service Menu	78
5.3.2	Close Service Menu.....	79
5.3.3	Structure of Service Menu	80
5.3.4	General Display Elements for Service Menu.....	81
5.3.4.1	Combobox.....	81
5.3.4.2	Number Field.....	81
5.3.4.3	Checkbox	82
5.3.4.4	Text Field	82
5.3.4.5	Information Field	83
5.3.5	Service Menu Points / Display Pages	84
5.3.5.1	Service Menu Main	84
5.3.5.2	Display Sensor Data.....	86
5.3.5.3	Local Settings.....	87
5.3.5.4	Error Log	89
5.3.5.5	Export / Import.....	91
5.3.5.6	Steering Components.....	92
5.3.5.7	PilotStar® NX Settings	94
5.3.5.8	Setup Assistant	96
5.3.6	Configurable Parameters	113

5.3.6.1	Shipname	127
5.3.6.2	IMO no.	127
5.3.6.3	Length	127
5.3.6.4	No. of Rudder	127
5.3.6.5	Rudder Type.....	127
5.3.6.6	Order Code.....	128
5.3.6.7	Instance Number	128
5.3.6.8	Day Colour	128
5.3.6.9	Night Colour	129
5.3.6.10	Software Archive	129
5.3.6.11	Software Action	129
5.3.6.12	Service Menu enabled	130
5.3.6.13	Serial 1	130
5.3.6.14	Serial 2	130
5.3.6.15	Serial 3	131
5.3.6.16	Can Group.....	131
5.3.6.17	Can- Dev. Nb.....	132
5.3.6.18	CAN ID	132
5.3.6.19	CAN Nav.Data enabled	132
5.3.6.20	Alert Mgr. UDP	132
5.3.6.21	Alert Mgr. Type.....	133
5.3.6.22	BNWAS Mgr. UDP.....	133
5.3.6.23	PSIFs	133
5.3.6.24	CAN Central Dimming	133
5.3.6.25	DDC Central Dimming	134
5.3.6.26	INS	134
5.3.6.27	Turn headings 180deg.....	134
5.3.6.28	MISC	134
5.3.6.29	TGTD	134
5.3.6.30	SATD	135
5.3.6.31	NAVD	135
5.3.6.32	TIME	135
5.3.6.33	PROP	135
5.3.6.34	USR1	135
5.3.6.35	USR2	136
5.3.6.36	USR3	136
5.3.6.37	USR4	136
5.3.6.38	USR5	137
5.3.6.39	USR6	137
5.3.6.40	USR7	137
5.3.6.41	USR8	137
5.3.6.42	Outgoing transm. grp.....	137
5.3.6.43	Rudder Gain [%].....	138
5.3.6.44	Max. Rudder Angle.....	139

5.3.6.45	Heading Monitor.....	139
5.3.6.46	Heading Grad. Control	139
5.3.6.47	HDG Grad. [deg/s]	140
5.3.6.48	Set Rudder limited.....	140
5.3.6.49	High Speed Craft.....	140
5.3.6.50	SW-Key.....	141
5.3.6.51	Low Speed	141
5.3.6.52	Eff. Ship Length.....	141
5.3.6.53	Back up Nav. Alarm.....	141
5.3.6.54	Developer Key.....	142
5.3.6.55	Server-IP address	142
5.3.6.56	Input Beep enabled	142
5.3.6.57	Rear Steering Stand.....	143
5.3.6.58	Steering Location	143
5.3.6.59	Client-IP address.....	143
5.3.6.60	Client-Subnet	144
5.3.6.61	Operator Unit Type.....	144
5.3.6.62	Select System	144
5.3.6.63	Tiller Connected.....	145
5.3.6.64	Update Devicelist	145
5.3.6.65	Gyro Heading Port	145
5.3.6.66	Mag. Heading Port	146
5.3.6.67	Speed Input Port	147
5.3.6.68	BAM Port.....	147
5.3.6.69	BNWAS Port	148
5.3.6.70	NFU Tiller xxx.....	149
5.3.6.71	PING Tiller xxx	149
5.3.6.72	FU Tiller xxx	149
5.3.6.73	PING FU Tiller xxx	150
5.3.6.74	Handwheel xxx.....	150
5.3.6.75	PING Handwheel xxx	150
5.3.6.76	Feedback Input	151
5.3.6.77	Current Angle.....	151
5.3.6.78	Set Rudder Output	151
5.3.6.79	NAV Input Port	152
5.3.6.80	Disable Ethernet X19	152
5.3.7	Change Configurations of Parameters	153
5.3.7.1	Configure Combobox	153
5.3.7.2	Configure Checkbox.....	154
5.3.7.3	Configure Text Field	155
5.3.7.4	Configure Number Field	157
5.3.8	Update of Software	158
5.3.9	Export of Configuration	160

5.3.10	Import of Configuration.....	161
5.3.11	Configure PilotStar® NX for BAM.....	162
5.3.12	Configure PilotStar® NX for BNWAS	163
5.3.13	Configure MOXA Switch	164
6	Fault Finding	171
6.1	Faults	171
6.1.1	Alert Messages	171
6.1.2	Further Faults.....	176
6.2	Change Fuse	177
6.3	Start Display Test.....	177
7	Documentation of Settings	179
8	Disposal	183
9	Annex.....	185
	PANZRSA Telegram	
	PANZSTA Telegram	
	Alert List	
	IEC 61162-450 Support	
	Dimensional Drawing 102-820.HP005	
	Wiring Diagram 102-820.HP008	
	Licenses	
	Spare Parts Catalogue	

Table of Figures

Figure 1-1	PilotStar® NX Integration with NautoSteer AS	8
Figure 1-2	Standalone Applicaton	9
Figure 1-3	Master - Slave Installation	12
Figure 1-4	Operating Elements	13
Figure 3-1	Establish a Common Ground Connection.....	29
Figure 3-2	Stripping of Connection Cable.....	30
Figure 3-3	Example Cable Connection	30
Figure 3-4	Installation for BNWAS / BAM with MOXA Switch	31
Figure 4-1	Day / Night Softkey	39
Figure 4-2	Parameter Indicator.....	40
Figure 4-3	Status Header Line Operation Display Page	40
Figure 4-4	Unacknowledged Alert Indication	41
Figure 4-5	Alert Indication with an Ascending Number while Alert Scrolling	41
Figure 4-6	Parameter Indicator.....	41
Figure 4-7	Value / Speed Indicator	42
Figure 4-8	Green Colored Time Bar	44
Figure 4-9	Blue Colored Time Bar	44
Figure 4-10	HDG Main Display Page	45
Figure 4-11	NAV Main Display Page	48
Figure 4-12	NFU/FU Main Display Page	50
Figure 4-13	HDG & Rudder Plot Display Page	52
Figure 4-14	Track Data Display.....	54
Figure 4-15	Limits Display Page.....	56
Figure 4-16	Speed Selection Display Page	58
Figure 4-17	HDG Selection Display Page.....	59
Figure 4-18	Parameter Memory Display Page.....	61
Figure 4-19	Parameter Modify Display Page	63
Figure 4-20	RoT & Radius Display Page	64
Figure 4-21	Ship Data Display Page	66
Figure 4-22	Simplified View Display Page	67
Figure 4-23	Main Display Page in Inactive Mode.....	69
Figure 5-1	Service Menu Structure.....	80
Figure 5-2	Combobox and Selection Softkeys.....	81
Figure 5-3	Number field and +/- Softkeys	81
Figure 5-4	Checkbox and Check Softkey	82
Figure 5-5	Text Field and Edit softkey	82
Figure 5-6	On-Screen Keyboard.....	82
Figure 5-7	Information Field	83
Figure 5-8	Service Menu Main Display Page.....	84
Figure 5-9	Sensor Data Service Display Page.....	86
Figure 5-10	Local Settings Service Display Page	87
Figure 5-11	Error Log Service Display Page	89

Figure 5-12	Export / Import Service Display Page	91
Figure 5-13	Steering Components Service Display Page	92
Figure 5-14	PilotStar® NX Settings Service Display Page.....	94
Figure 5-15	Master/Slave Setup Assistant Display Page	97
Figure 5-16	System Type Setup Assistant Display Page	98
Figure 5-17	CAN Bus Addresses Setup Assistant Display Page.....	100
Figure 5-18	Additional Tillers Setup Assistant Display Page.....	101
Figure 5-19	Heading Input Setup Assistant Display Page.....	102
Figure 5-20	Speed Input Setup Assistant Display Page.....	103
Figure 5-21	BAM/BNWAS Setup Assistant Display Page	104
Figure 5-22	VDR Setup Assistant Display Page	105
Figure 5-23	Steering Locations Setup Assistant Display Page	106
Figure 5-24	Ship Parameters Setup Assistant Display Page	107
Figure 5-25	Rudder Feedback Setup Assistant Display Page.....	108
Figure 5-26	Rudder Control Setup Assistant Display Page.....	109
Figure 5-27	Heading Control Setup Assistant Display Page	110
Figure 5-28	NAV Control Setup Assistant Display Page	111
Figure 5-29	Summary Setup Assistant Display Page.....	112

Table of Tables

Table 1-1	General Display Elements	13
Table 1-2	Button LEDs	15
Table 1-3	Active / Standby LED within Operation Mode	15
Table 1-4	PCB LEDs	16
Table 1-5	Inputs and Outputs	17
Table 1-6	Plug Assignment / Interfaces	17
Table 1-7	Output Relays	18
Table 1-8	Alert List – Alarm Symbols	22
Table 1-9	Alert List – Warning Symbols	23
Table 1-10	Alert List – Caution Symbol	23
Table 1-11	CAN Bus Cable Data	26
Table 3-1	Connection Overview	32
Table 3-2	Pole Assignment Supply Voltage	33
Table 3-3	Pole Assignment Dual CAN Bus	33
Table 3-4	Dual CAN Bus Termination Jumper Position	34
Table 3-5	Pole Assignment RS4ff22 Serial Inputs / Outputs	35
Table 3-6	DIP Switches for Termination of Serial Inputs / Outputs	36
Table 3-7	Pole Assignment Alarm and Status Outputs (Relays)	37
Table 4-1	Operation Mode Softkeys	43
Table 4-2	Access to Display Pages during Inactive Mode	69
Table 5-1	Setup Assistant Influenced Parameter	96
Table 5-2	Parameters within PilotStar® NX Settings / Ship Data	113
Table 5-3	Parameters within PilotStar® NX Settings / System	113
Table 5-4	Parameters within PilotStar® NX Settings / Interfaces	114
Table 5-5	Parameters within PilotStar® NX Settings / Controller	116
Table 5-6	Parameters within Steering Components / PSIF	117
Table 5-7	Parameters within Steering Components / Tiller Hand Wheel	119
Table 5-8	Parameters within Steering Components / CAN Distribution Unit	121
Table 5-9	Parameters within Local Settings	122
Table 5-10	Parameters within Setup Assistant / Master/Slave	122
Table 5-11	Parameters within Setup Assistant / System Type	122
Table 5-12	Parameters within Setup Assistant / CAN Bus Addresses	123
Table 5-13	Parameters within Setup Assistant / Additional Tillers	123
Table 5-14	Parameters within Setup Assistant / Heading Input	123
Table 5-15	Parameters within Setup Assistant / Speed Input	123
Table 5-16	Parameters within Setup Assistant / BAM/BNWAS	124
Table 5-17	Parameters within Setup Assistant / Steering Locations	124
Table 5-18	Parameters within Setup Assistant / Ship Parameters	124
Table 5-19	Parameters within Setup Assistant / Rudder Feedback	124
Table 5-20	Parameters within Setup Assistant / Rudder Control	125
Table 5-21	Parameters within Setup Assistant / NAV Control	125
Table 5-22	Parameters within Setup Assistant / Summary	125

Table 6-1	User Alert Messages	172
Table 6-3	Further Faults	176
Table 7-1	Documentation of User Settings	179

List of Abbreviations

AS	Advanced Steering
BNWAS	Bridge Navigational Watch Alarm System
CCRS	Consistent Common Reference System
COG	Course Over Ground
Deg	Degree
EMC	Electromagnetic Compatibility
FU	Follow Up
GNSS	Global Navigation Satellite System
HDG	Heading
INS	Integrated Navigation System
Mag	Magnetic
NFU	Non-Follow Up
RoT	Rate of Turn
RTC	Real-time clock
Rad	Radius
Stbd	Starboard
THD	True Heading Device
XTE	Cross Track Error

Intentionally left blank

0 Introduction

0.1 Preliminary Remarks

The present manual has been drawn up as a description and reference book. It will help answer questions and will solve problems in the quickest possible manner.

Before operating the equipment read and follow the instructions and hints in this manual.

For this purpose, refer to the table of contents and read the corresponding chapters thoroughly.

If you have any further questions, please contact us on the following address:

RAYTHEON ANSCHÜTZ GMBH
Zeyestr. 16 - 24
D-24106 Kiel
Germany

Tel. +49 431 / 3019 - 0
Fax +49 431 / 3019 - 291

All rights reserved. No part of this manual may be copied, neither mechanically, electronically, magnetically, manually nor otherwise, or distributed, forwarded or stored in a data bank without written permission of RAYTHEON ANSCHÜTZ GMBH.

Copyright:
RAYTHEON ANSCHÜTZ GMBH
Zeyestr. 16 - 24
D-24106 Kiel
Germany

Since errors can hardly be avoided in the documentation in spite of all efforts, we should appreciate any remark and suggestion.

Subject to alterations.


0.2 Change History


Edition	Date	Change
001	September 2017	First Edition
002	January 2018	Setup Assistant added
003	May 2018	Second Edition
004	August 2018	Change 1.15 Technical Data: Protection class "IP12" deleted and "IP23" inserted
005	December 2020	Annex-Drawings updated
006	April 2021	<ul style="list-style-type: none">• Chapter 0.4: document number updated• Chapter 1.7: note added• Chapter 6.1.1: Note regarding responsibility transfer added, table regarding alert messages moved to the annex


0.3 Safety

0.3.1 General Safety Regulations


The following safety symbols are used in this manual:


<p>WARNING</p> 	<p>Warning statements indicate a hazardous situation that, if not avoided, could result in minor, moderate or serious injury or death.</p>
---	--


<p>CAUTION</p> 	<p>Caution statements indicate a hazardous situation that, if not avoided, could result in equipment damage or environmental damage.</p>
---	--


	<p>Notes indicate information considered important, but not hazard related.</p>
---	---


0.3.2 General Safety Instructions

<p>WARNING</p> 	<p>Danger due to voltage-regulated devices</p> <p>Risk of death or serious injury caused by electrical shock</p> <ul style="list-style-type: none"> • Switch off voltage supply if the wires have damaged insulation. • Work on the electric system must be performed only by qualified electricians. • Keep moisture away from live parts. • Keep system closed. • Do not attempt to bypass or disable fuses.
---	--


<p>WARNING</p> 	<p>Danger due to improper operation and purpose</p> <p>Risk of serious injury and material damage</p> <ul style="list-style-type: none"> • Use product only for the intended purpose. • Perform operation steps according to this manual. • Do not make any product modifications without authorization.
---	--

<p>WARNING</p> 	<p>Danger due to operation / maintenance by unqualified personnel</p> <p>Risk of serious injury and material damage</p> <ul style="list-style-type: none"> • Keep unqualified personnel away from the operation area. • All operation / maintenance must be performed only by qualified personnel.
---	---

<p>WARNING</p> 	<p>Danger due to non-adherence of general rules and regulations</p> <p>Risk of death or serious injury and material damage</p> <ul style="list-style-type: none">• Adhere all national and regional disposal rules and regulations.• Adhere all general rules and regulations specified for the work area.• Adhere all instructions placed on the components or described in related documentation.
---	--

<p>CAUTION</p> 	<p>Hazard due to wrong disposal of harmful substances</p> <p>Risk of environmental damage caused by wrong disposal</p> <ul style="list-style-type: none">• Adhere all national and regional disposal rules and regulations.• Adhere all disposal instructions placed on the components or described in related documentation.
---	---

ESD = Electrostatic Sensitive Device



EBP
(Earth Bonding
Point)

Dissipative
mating work
surface

Devices/assemblies, which are labelled as shown are electrostatic sensitive. This label indicates that handling or use of this item may result in damage from ESD if proper precautions are not taken. To perform installation and/or calibration work appropriate protective measures must be deployed. All necessary equipment for these protective measures can be supplied (on special order) with the RAYTHEON Anschutz Ident. -Number 1.990106.

0.4 List of Further Documents

Documentation No.	Title	Type
3963	Configuration Tool AS (Service Tool AS)	NB42-232
3928	Rudder Feedback Unit AS	101-532.NG001 - NG004 and 101-532.SA200
4362	PilotStar® Interface Unit PSIF	102-821.NG001
4060	Tiller Follow Up AS	105-307.NG001 - NG006
4061	Tiller Non-Follow Up AS	105-308.NG001 - NG003
4054	FU Handwheel AS	105-400.NG001 - NG006
3957	CAN BUS Distribution Unit AS	138-128.NG001

0.5 Test Standards

Standards	Description
ISO 11674	Ships and marine technology - Heading control systems
IEC 62288	Maritime navigation and radiocommunication equipment and systems – Presentation of navigation-related information on shipborne navigational displays – General requirements, methods of testing and required test results
IEC 62616	Maritime navigation and radiocommunication equipment and systems - Bridge navigational watch alarm system (BNWAS)
IEC 61924-2	Maritime navigation and radiocommunication equipment and systems - Integrated navigation systems - Part 2: Modular structure for INS - Operational and performance requirements, methods of testing and required test results
IEC 62923-1:2018	Maritime navigation and radiocommunication equipment and systems - Bridge alert management - Part 1: Operational and performance requirements, methods of testing and required test results
IEC 61162 series	Maritime navigation and radiocommunication equipment and systems - digital interfaces
IEC 60945	Maritime navigation and radiocommunication equipment and systems - General requirements - Methods of testing and required test results
ISO 16329	Ships and marine technology - Heading control systems for high-speed craft

1 Description

1.1 Intended Purpose

PilotStar® NX to control steering of the ship.

1.2 Use Limitations



Waypoint steering (NAV) operation mode is only permitted for non-SOLAS vessels.
For SOLAS vessels, it is not allowed to have an external navigator connected except track control.

IMO has defined 2 different operating modes / systems for automatic steering. These are:

- Heading Control and
- Track Control

For both of these operating modes performance and test standards have been defined. Authorities / classification societies test against these standards and issue a corresponding certificate if the products are compliant to these standards. There are no performance and test standards for waypoint steering (NAV) operating mode. Thus, these systems are not tested by authorities / classification societies.

1.3 Application Cases

1.3.1 NautoSteer AS Integration

PilotStar® NX is connected to a CAN bus of NautoSteer AS. In this application no PilotStar® NX Interface is required.




Figure 1-1 PilotStar® NX Integration with NautoSteer AS

1.3.2 Standalone

In the standalone application, PilotStar® NX controls the steering gear directly or is used in combination with steering gear control systems from other makers. For this application, the PilotStar® interface unit (102-821) is required.




Figure 1-2 Standalone Application

1.4 Modes of Operation

1.4.1 Active Modes

Within these modes the autopilot is active. The autopilot controls the rudder steering.


1.4.1.1 Heading Control (HDG)


Vessels heading is the controlled parameter in this mode. Within heading control mode, the set heading value can be adjusted. Heading control can be performed with a heading value from a gyro compass, or a gyro equivalent compass (GPS, FDG, Strap Down) or from a magnetic compass.

The autopilot controls the heading by comparing the set heading value and the actual heading value.

Within in heading control mode it is possible to adjust a rudder offset. This function is called trim function and intended heading control for vessels with asymmetrical loads, such as fishing vessels and tugs.

1.4.1.2 Waypoint Steering (NAV)

	Waypoint steering (NAV) operation mode is only permitted for non-SOLAS vessels. For SOLAS vessels, it is not allowed to have an external navigator connected except track control.
---	---

	To use waypoint steering, a gyro (THD) must be used.
---	--

The waypoint steering mode is available if a route planning system is connected. Within mode waypoint steering a route is planned on a route planning system. The PilotStar® NX receives the route data from the route planning system to steer the vessel.

Possible route planning systems:

- GPS system
- Chart plotter

1.4.1.3 Manual Steering via Operation Unit (NFU/FU)

NFU/FU mode includes 2 possibilities of manual steering:

- NFU mode: rudder angle is set via control keys.
- FU mode: entry of target rudder angle value via rotary knob)

1.4.2 Inactive Modes

Within these modes, the autopilot is inactive. The autopilot does not control the rudder steering.

1.4.2.1 Manual Steering via External Source / Standby

An external tiller or hand wheel controls rudder.

1.4.2.2 Override

This mode is indicated when a manual steering unit (hand wheel or tiller) with an override function interrupts the control of the autopilot.

The override function must be activated on the respective steering unit to interrupt the control of the autopilot.

1.4.2.3 Not Activatable

Main steering is active or steering system is disconnected from voltage or autopilot is not selected by steering mode selector switch (is part of bridge installation). PilotStar® NX is inactive and not activatable.

1.5 Multiple PilotStar® NX Operator Units

1.5.1 Master - Slave Installation

It is possible to install up to 10 PilotStar® NX operator units in a steering system. The operator unit, which is connected with the CAN bus, is the master operator unit. The operator units, which are connected with the master operator unit, are called slave operator units.

Only the master operator unit performs the control function of a steering control system. The slave operator units are used for remote operation of the master operator unit.

At the current used operator unit, a green LED is on at the **Active / Standby** pushbutton, see chapter 1.8.1.

At the current unused operator units, a yellow LED is on at the **Active / Standby** pushbutton, see chapter 1.8.1.




Figure 1-3 Master - Slave Installation

1.5.2 Master - Master Installation

It is possible to install up to 9 PilotStar® NX within NautoSteer AS system. PilotStar® NX is connected to the redundant CAN bus of NautoSteer AS. No PilotStar® NX interface unit required.

Use conditions:

- Each operator unit is independent, with own sets of parameters and adjustments.
- Occurred alert messages are not synchronized between the operator units.
- Switching over from override mode (see chapter 1.4.2.2) is performed to the last active operator unit. If the last active operator unit is currently not active, an alert is generated at the override unit.

1.6 Rear Steering Stand

It is possible to install a slave operator unit or master operator unit in opposite direction. The operator unit can be configured for rear steering stand, see chapter 5.3.7.59.

1.7 Operating Elements

The mentioned operating elements are on the front plate of the operator unit. Further operational items are softkey elements on the touchscreen (see chapter 4.3) and a reset button on the back of the operator unit casing (see chapter 5.2).

i	Only standard function listed. Additional functions for operation elements possible in certain settings or operations, which are described within respective chapter.
----------	---





Figure 1-4 Operating Elements

Table 1-1 General Display Elements

Pos.	Depiction	Function
1	Touchscreen display	Displays data and enables operation via softkeys

Pos.	Depiction	Function
2	Pushbutton, Alert Acknowledgement	<ul style="list-style-type: none"> • Acknowledge alert • Scroll through the current alerts
3	Pushbutton, Dim	Adjust brightness of the display
4	Pushbutton, Set	Confirm value change
5	Pushbutton, Active / Standby	<ul style="list-style-type: none"> • Activate user interface • Activates heading control mode
6	Rotary knob	<p>Turn:</p> <ul style="list-style-type: none"> • Adjust set heading within HDG operation mode • Adjust set rudder within NFU/FU operation mode <p>Press:</p> <ul style="list-style-type: none"> • Confirm adjusted set heading within HDG operation mode • Close pages, which include no heading adjustment or rudder adjustment
-	Pushbutton, Reset	See chapter 5.2

	<p>In order to avoid unintended acknowledgement of a new incoming alert, pushbutton Alert Acknowledgement is deactivated for 1 second after receiving a new alert.</p>
---	--

1.8 LEDs

1.8.1 Button LEDs

Table 1-2 Button LEDs





LED	Color	Light Condition
	Green	Autopilot is active
	Yellow	<ul style="list-style-type: none"> • 1 operator unit: Autopilot is not active, but activatable • 2 or more operator units: Operator unit is not active
	<ul style="list-style-type: none"> • Red • Red flashing 	<ul style="list-style-type: none"> • Acknowledged, but still active alert • Unacknowledged alert
	Yellow flashing	Value changed, but not yet confirmed by pressing the Set button

Table 1-3 Active / Standby LED within Operation Mode

Mode	Active LED	Standby LED
Heading control	On	Off
Waypoint steering	On	Off
Manual steering via operation unit	On	Off
Manual steering via external source	Off	On
Override	Off	On
Not activatable	Off	Off
Fail	Off	Off

1.8.2 PCB LEDs

The operator unit consist of two PCBs. The numbering of the LEDs is unmistakable. There are no double designations of LEDs.

Table 1-4 PCB LEDs

LED	Color	Light Condition
P1 - P9	Green	Internal voltage available
P10	<ul style="list-style-type: none"> • Green flashing 1 s • Green flashing 4 s 	<ul style="list-style-type: none"> • HMI Running a connection to Server • HMI running and no connection to server
P11	Red	System buzzer is disabled
P12	Red	Alert buzzer is disabled
P26	Yellow	Ethernet 1 is connected
P27	<ul style="list-style-type: none"> • Green • Green flashing 	<ul style="list-style-type: none"> • Ethernet 1 is connected • Data transmission at Ethernet 1
P28	Yellow	Ethernet 2 is connected
P29	<ul style="list-style-type: none"> • Green • Green flashing 	<ul style="list-style-type: none"> • Ethernet 2 is connected • Data transmission at Ethernet 2
P501	Red	Alert is processed and transferred via relay SYS FAIL at X508
P502	Red	Alert is processed and transferred via relay OFF HEADING at X509
P503	Red	Alert is processed and transferred via relay HEADING MONITOR at X510
P504	Red	Alert is processed and transferred via relay BACKUP NAVIGATOR at X511
P505	Green flashing	Data transmission at X505 (RS422 interface)
P506	Green flashing	Data transmission at X506 (RS422 interface)
P507	Green flashing	Data transmission at X507 (RS422 interface)
P508	Green flashing	Data transmission at X508 (dual CAN interface)
P509	Green flashing	Data transmission at X509 (dual CAN interface)

1.9 Interfaces

1.9.1 Interface Inputs and Outputs

Table 1-5 Inputs and Outputs

Designation	Data / Signal	Plug
Outputs		
Relays / alarm and status outputs	System and alarm status	X508, X509, X510, X511
Inputs		
Supply voltage	24 V DC (18 to 36 V DC); 25 W (maximum)	X512
Output / Input		
Dual CAN bus	According to ISO 11898 with proprietary Raytheon Anschütz telegrams	X513, X514
USB	Software update	X20
Ethernet	Sensor data, navigation data, alert data, data for slave operator units	X19, X21
RS422 serial input / output	Sensor data, navigation data, alert data	X505, X506, X507

1.9.2 Plug Assignment / Interfaces

Table 1-6 Plug Assignment / Interfaces

Plug	Function
X19*	Ethernet 1 plug
X20	USB plug
X21*	Ethernet 2 plug
X501	Not used
X502	Not used
X505	Connects RS422 serial input / output, see chapter 3.7
X506	Connects RS422 serial input / output, see chapter 3.7

Plug	Function
X507	Connects RS422 serial input / output, see chapter 3.7
X508	Connects relay SYS FAIL , see chapter 3.8
X509	Connects relay OFF HEADING , see chapter 3.8
X510	Connects relay HEADING MONITOR , see chapter 3.8
X511	Connects relay BACKUP NAVIGATOR , see chapter 3.8
X512	Connects power supply, see chapter 3.5
X513	Connects dual CAN bus (CAN BUS 1), see chapter 3.6
X514	Connects dual CAN bus (CAN BUS 2), see chapter 3.6

* The available ethernet interfaces are a hardware redundancy. Internally, both represent one ethernet interface with the same IP and Mac address. The redundancy is managed by the operating system of the Operator unit.

1.10 Output Relays

Table 1-7 Output Relays

Plug	Relay	Function
X508	System failure (Sys Fail)	Indicates a failure within the PilotStar® NX Operator Unit if necessary data for operation are not accessible or user interface is not accessible, see chapter 6.1.2
X509	Off Heading	Trips if off heading threshold is exceeded, see chapter 1.13.3
X510	Heading Monitor	Trips if heading monitor threshold is exceeded, see chapter 1.13.2
X511	Backup Navigator	Trips if user alarm message is escalated by transfer to BNWAS, see chapter 6.1.1

1.11 Sensor Data

PilotStar® NX needs the following sensor data for heading control mode and NAV mode.

1.11.1 Heading

Heading data are the essential data for the device. A compass provides the heading data. Actual heading is required for the controller. Therefore a heading value from a gyro compass (THD (GNSS)) or from a magnetic compass (THD (Mag)) must be used.

1.11.2 Speed

A speed input is required as the rudder order from PilotStar® NX is speed dependent. The primary speed input is speed through water. The backup speed input is speed over ground. The third possibility is the manual editing of speed data by user.

1.11.3 Time

Upon reception of a valid ZDA-telegram the received time is used to synchronize the internal clock automatically to the received time information. Without a ZDA telegram a received position information is not used.

1.12 Condition-Based Input Parameters

To adjust the autopilot to the particular conditions, the relevant parameters must be evaluated and adjusted regularly on the environment and vessel conditions (e.g. loading, weather).

Condition-based parameters are:

- Rudder
- Counter rudder
- Yawing
- Radius or Rate of Turn
- Fix turn

1.13 Monitoring and Limit Functions

PilotStar® NX has several functions to monitor the autopilot function and the sensors.

1.13.1 Rudder Angle Limit

The rudder angle limit limits the rudder angle. This threshold is adjustable. An alert message indicates when the rudder angle limit is reached. The adjusted threshold

cannot be exceeded during heading control. The threshold can be exceeded during waypoint steering mode. The threshold is not used during manual steering modes.

1.13.2 Heading Monitor

The heading monitor monitors two independent sources for heading. One source must be from a gyro the other source from a magnetic compass. The accepted difference between both sensors is adjustable. An alert message indicates when this threshold is exceeded.

1.13.3 Off Heading

An off-heading alert is provided, if the vessel does not reach the set heading. The accepted difference between actual heading and set heading is adjustable. An alert message indicates when this threshold is exceeded.

1.13.4 Cross Track Error Limit

A cross track error alert is provided, if the vessel deviates from the course over ground line. The accepted cross track error is adjustable. An alert message indicates when this threshold is exceeded. This threshold applies only for waypoint steering operation mode.

1.13.5 Course Trim Limit

The accepted limit between actual heading and set course over ground is adjustable. An alert message indicates when this threshold is exceeded. This threshold applies only for waypoint steering operation mode.

1.14 Bridge Alert Management

Bridge alert management (BAM) is an overall concept to enhance the handling, distribution and presentation of alerts on the bridge in a consistent manner.

This concept is described in the IMO performance standard MSC.302(87) Performance standard for Bridge Alert Management. Equipment related details are defined in other equipment related performance and test standards.

The objective of BAM is to harmonize the priority, classification, handling, distribution and presentation of alerts, to enable the bridge team to devote full attention to the safe operation of the ship and to immediately identify any alert situation requiring attention and/or action to maintain the safe operation of the ship.

Unnecessary distraction of the bridge team by redundant and superfluous audible and visual alert announcements should be avoided. It reduces the cognitive workload of the operator by minimizing the information presented which is necessary to draw attention to and to assess the situation.

On the bridge alerts are presented on the individual equipment and/or on a central alert management human machine interface (CAM-HMI). This autopilot serves as a backup for the CAM display.

Alerts are divided in different priorities:

- **Emergency alarm**
Highest priority of an alert. Alarms which indicate immediate danger to human life or to the ship and its machinery exists and that immediate action must be taken.

- **Alarm**
An alarm is a high-priority alert. Conditions requiring immediate attention and action by the bridge team to avoid any kind of hazardous situation and to maintain the safe operation of the ship.

- **Warning**
Conditions or situations which require immediate attention for precautionary reasons, to make the bridge team aware of conditions which are not immediately hazardous, but may become so. (Warning may be escalated to alarm.)

- **Caution**
Lowest priority of an alert. Awareness of a condition which still requires attention out of the ordinary consideration of the situation or of given information.

Alerts are divided in different categories:

- **Category A**
 Alerts for which graphical information at the task station (such as Radar or ECDIS) directly assigned to the function generating the alert is necessary, as decision support for the evaluation of the alert-related condition. These alerts can only be acknowledged at the task station.

- **Category B**
 Alerts where no additional information for decision support is necessary besides the information which can be presented at the CAM-HMI. These alerts can be acknowledged at the task station or at the CAM-HMI.

- **Category C**
 Alerts that cannot be acknowledged on the bridge, but for which information is required about the status and treatment of the alerts (e.g. certain alerts from the engine).

Table 1-8 Alert List – Alarm Symbols






Icon/Symbol	Description
	Active – unacknowledged alarm (flashing)
	Active – silenced alarm (flashing)
	Active – acknowledged alarm
	Active - responsibility transferred alarm
	Rectified – unacknowledged alarm (flashing)

Table 1-9 Alert List – Warning Symbols







Icon/Symbol	Description
	Active – unacknowledged warning (flashing)
	Active – silenced warning (flashing)
	Active – acknowledged warning
	Active - responsibility transferred warning
	Rectified – unacknowledged warning (flashing)

Table 1-10 Alert List – Caution Symbol

Icon/Symbol	Description
	Caution

1.15 Technical Data

Supply voltage	24 V DC
Protection class	IP56 (front side) IP23 (back side)
Power consumption	25 W
Allowed ambient temperature	-15 to +55 °C
Display conditions:	Main viewing distance 1 m
Output telegrams	According to 61162-1: Talker ID for all output telegrams is always AG <ul style="list-style-type: none">• ALC• ALF• ALR• ARC• DDC• EVE• HBT• HSC• HTD• RSA• TXT• VER• PANZRSA• PANZSTA


Input telegrams

According to 61162-1:

- ACK: All Talker
- CAN: All Talker
- APB: All Talker
- DDC: All Talker
- GGA: Talker GA, GL, GN, GP, HC, HE, LC, II, IN, VD, VM, VW, ZA, ZC, ZQ, ZV
- GLL: Talker GA, GL, GN, GP, HC, HE, LC, II, IN, VD, VM, VW, ZA, ZC, ZQ, ZV
- GNS: Talker GA, GL, GN, GP, HC, HE, LC, II, IN, VD, VM, VW, ZA, ZC, ZQ, ZV
- HDG: Talker HE, HF
- HDT: Talker GP, HC, HE, HF
- NSR: Talker IN
- RMC: Talker GA, GL, GN, GP, HC, HE, LC, II, IN, VD, VM, VW, ZA, ZC, ZQ, ZV
- THS: Talker GP, HC, HE, HF
- VBW: Talker GP, VD, VM, VW, II, IN
- VHW: Talker VD, VM, VW, II, IN
- VTG: Talker GP, VD, II, IN
- ZDA: All Talker

1.16 CAN Bus

The CAN bus is a Multi-Master-Bus allowing the connection of all devices and systems regardless of their task and function. This means that any number of devices can be connected. These devices must be designed for CAN bus technology. For the CAN bus it is essential that every CAN bus participant is addressable via a unique address. This address is set within each bus participant or via a component (participant) which is able to look into the CAN bus architecture.

	<p>This CAN bus address can be set with a special Service Tool by the service personnel only. It cannot be changed without this tool.</p>
---	--

Each CAN bus participant can send and receive data via the CAN bus. For data transmission, this data is combined with a header (address from the data source, a “Heart Beat”) and the data itself. The data is transmitted to the CAN bus cyclically. Each CAN bus participant monitors the CAN bus to take off the relevant data.

The CAN bus must be terminated at both ends (within an application) via an ohm resistor (120 Ohms). This terminating resistor is set by jumpers at the respective connection (see chapter 3.6).

The termination has always to be set between the termination terminals (T) and the CAN LOW terminal (L). There are two types of CAN bus in an application:

- Single CAN bus
- Dual CAN bus

The difference between a Single CAN bus application and a Dual CAN bus application is a CAN bus redundancy. In most cases the Single CAN bus is duplicated for redundancy, but this feature is for a redundancy of the respective device not for the CAN bus itself.

Table 1-11 CAN Bus Cable Data

Designation	Data
Type	2x2x0.75 mm ² , screened, twisted pair (twisted pitch length <80 mm)
Impedance	120 Ω ±10 %
Capacitance	max. 50 pF/m
Cable Line Delay	max. 5 ns/m
Cable Length	max. 400 m (termination to termination)

2 Mounting

If the operator unit could not be integrated in a console or in case of a standalone application, mounting frame is necessary, see spare parts catalogue.

Intentionally left blank

3 Installation

3.1 Establish a Common Ground Point

In order to comply with the stringent EMC requirements, abide by the information given below regarding cable connections.

Use the cable types specified.




Figure 3-1 Establish a Common Ground Connection


Make all common ground connections as shown in the figure above.

The earthing cable attached to the cable bracket must possess a cross section of minimum 1.5 mm².

Mount the cable bracket between two toothed washers.

Common ground connections must be free of color, corrosion and well fastened.

3.2 Proper Cable Connections

<p>CAUTION</p> 	<p>Hazard due to unintended use of shielding clamp</p> <p>Risk of material damage</p> <ul style="list-style-type: none">• Do not use shielding clamp for any mechanical connection.• Use one shielding clamp only for one cable.
---	--

Adhere the following instructions:

- Strip the cable over a length of 60 mm, see Figure 3-2.
- Do not damage the cable shielding.
- Trim the cable shield until 15 mm is left on the cable.
- Use clamp to fix the cable at the casing, see Figure 3-3.




Figure 3-2 Stripping of Connection Cable




Figure 3-3 Example Cable Connection

3.3 Installation for BNWAS / BAM

To use PilotStar® NX in combination with a BNWAS and / or BAM system a MOXA switch is needed, see spare parts catalogue.
For configuration of the MOXA switch, see chapter 5.3.14.




Figure 3-4 Installation for BNWAS / BAM with MOXA Switch

3.4 Connection Overview

Table 3-1 Connection Overview

Designation	Plug	Chapter
Outputs		
Relays / alarm and status outputs	X508, X509, X510, X511	3.8
Inputs		
Supply voltage	X512	3.5
Output / Input		
Dual CAN bus	X513, X514	3.6
USB	X20	-
Ethernet	X19, X21	-
RS422 serial input / output	X505, X506, X507	3.7

Table 3-2 External Interfaces

Device	Interface	No.	Standard
Operator Unit 102-820 NG1	Serial	3	IEC 61162-1, IEC 61162-2
Moxa NPort	Serial	2	IEC 61162-1, IEC 61162-2
Operator Unit 102-820 NG1	Relais	4	
Operator Unit 102-820 NG1	Ethernet	1	IEC 61162-450

Table 3-3 Internal Interfaces



Device	Interface	No.	Standard
Operator Unit 102-820 NG1	Ethernet	1	Moxa NPort, Slave OU
Operator Unit 102-820 NG1	CAN Bus	2	APIF, Steering AS
Moxa NPort	Ethernet	1	Operator Unit

3.5 Connect Supply Voltage

Plug	X512
Connector poles	4

Pole numbers counted from left hand side (top view).

Table 3-4 Pole Assignment Supply Voltage

Pole	Depiction	Connection
X512/1		+24 V DC Power
X512/2		
X512/3		Ground +24 V DC
X512/4		

3.6 Connect Dual CAN Bus

Plug	X513, X514
Connector poles	4 each

Pole numbers counted from left hand side (top view).

Table 3-5 Pole Assignment Dual CAN Bus

Pole	Connection
X513/1	CAN bus termination
X513/2	CAN bus low
X513/3	CAN bus high
X513/4	CAN bus ground
X514/1	CAN bus termination
X514/2	CAN bus low
X514/3	CAN bus high
X514/4	CAN bus ground

Table 3-6 Dual CAN Bus Termination Jumper Position

Plug	Jumper Position for Termination
X513	Between X513/1 and X513/2
X514	Between X514/1 and X514/2

3.7 Connect RS422 Serial Inputs / Outputs

Plug	X505, X506, X507
Connector poles	5 each

Pole numbers counted from left hand side (top view).

Table 3-7 Pole Assignment RS422 Serial Inputs / Outputs

Pole	Connection
X505/1	Receiver -Rx
X505/2	Receiver +Rx
X505/3	Transmitter +Tx
X505/4	Transmitter -Tx
X505/5	Ground
X506/1	Receiver -Rx
X506/2	Receiver +Rx
X506/3	Transmitter +Tx
X506/4	Transmitter -Tx
X506/5	Ground
X507/1	Receiver -Rx
X507/2	Receiver +Rx
X507/3	Transmitter +Tx
X507/4	Transmitter -Tx
X507/5	Ground



In case of signal reflections, the serial inputs / outputs can be terminated to reduce signal reflections. Long signal cables or high baud rates cause signal reflections. Termination is done via DIP switches at the end of transmitter line and at the end of the receiver line. It is necessary to open the backside cover to reach the DIP switches.

Table 3-8 DIP Switches for Termination of Serial Inputs / Outputs





Pole	Function	Adjustments
S501	Termination of transmitter side at X505	Off = No termination (default) On = Termination
S502	Termination of receiver side at X505	Off = No termination (default) On = Termination
S503	Termination of transmitter side at X506	Off = No termination (default) On = Termination
S504	Termination of receiver side at X506	Off = No termination (default) On = Termination
S505	Termination of transmitter side at X507	Off = No termination (default) On = Termination
S506	Termination of receiver side at X507	Off = No termination (default) On = Termination

3.8 Connect Alarm and Status Outputs (Relays)

Plug X508, X509, X510, X511
Connector poles 3 each

Pole numbers counted from left hand side (top view).


Table 3-9 Pole Assignment Alarm and Status Outputs (Relays)


	Pole	Depiction	Connection
System failure	X508/1		NO
	X508/2		NC
	X508/3		COM
Off Heading	X509/1		NO
	X509/2		NC
	X509/3		COM
Heading Monitor	X510/1		NO
	X510/2		NC
	X510/3		COM
Backup Navigator	X511/1		NO
	X511/2		NC
	X511/3		COM

Intentionally left blank

4 Operation

4.1 Safety Information

<p>WARNING</p> 	<p>Danger due to installation by unqualified personnel</p> <p>Risk of injury and material damage</p> <ul style="list-style-type: none"> • Keep unqualified personnel away from the operation area. • All operation must be performed only by qualified personnel.
---	--

	<p>Confirm value changes with pushbutton Set. If there are longer inactivity after a value change without pressing Set, the respective value returns to the previous value.</p>
---	---

4.2 Switching On and Off

The system has no on and off-switch. System is ready for operation when voltage supply is connected.

4.3 General Display Elements for Operation

The following display functions / information are shown on several display pages.

4.3.1 Day / Night Softkey

Change between predefined day and night color mode. Day and night color mode can be predefined, see chapter 5.3.7.8 and 0.



Figure 4-1 Day / Night Softkey

4.3.2 Limits Indicator

This indicator is applicable for heading control mode and waypoint steering mode and displays the adjusted limit values, see chapter 1.13.

Click on this indicator to adjust limit values, see chapter 4.4.6.




Figure 4-2 Parameter Indicator

Pos.	Designation
1	Rudder angle limit in degree, see chapter 1.13.1
2	Off heading (within heading control mode) in degree, see chapter 1.13.3 or cross track error limit (within waypoint steering mode) in meter, see chapter 1.13.4
3	Heading monitor in degree, see chapter 1.13.2

4.3.3 Status Header Line

The header line of every operation display page includes the information about the current used parameter set in the top right corner.

The header line of every operation display page, except the main display pages, includes the name of the current display page. In the top left corner.

In the middle of the header line, a status note is displayed, if available.

There are 2 possible status notes:

- No Server Connection
- Manual Speed



Figure 4-3 Status Header Line Operation Display Page

4.3.4 Alert Messages Indication

All alert messages are shown with alert symbol and specific color, see chapter 1.14. Alert messages appear in the top left corner of the display. For all unacknowledged alerts the alert long text message is shown, for all acknowledged alerts the alert short text message is shown, see chapter 6.1.1.

While scrolling through all active alerts with pushbutton **Alert Acknowledgement** (see Figure 1-4) the alerts are displayed for 3 seconds on after another with an ascending number. The scrolling can be interrupted by pressing the pushbutton **Alert Acknowledgement** again. The alert with the highest priority is shown, if the scrolling is interrupted.



Figure 4-4 Unacknowledged Alert Indication



Figure 4-5 Alert Indication with an Ascending Number while Alert Scrolling

4.3.5 Parameter Indicator

This indicator is applicable for heading control mode and waypoint steering mode and displays the adjusted parameter values. Click on this indicator to select a stored parameter set, see chapter 4.4.9.

The parameter values are editable on display page **Parameter Modify**, see chapter 4.4.10.




Figure 4-6 Parameter Indicator

Pos.	Designation
1	Yawing Ratio between rudder activity and heading accuracy Adjustable from 1 (maximum accuracy due to highest rudder activity) to 6 (minimum accuracy due to lowest rudder activity) Default: 2

Pos.	Designation
2	Rudder Ratio between rudder angle and rudder movement effectivity within heading change manoeuvre Adjustable from 1 (minimum rudder movement effectivity due to small rudder angle) to 9 (maximum rudder movement effectivity due to large rudder angle) Default: 5
3	Counter Rudder Counter rudder value which counteracts the turning movement within heading change manoeuvre Adjustable from 0 (lowest counter rudder value) and 9 (highest counter rudder value) Default: 5

4.3.6 Value / Speed Indicator

Actual speed is displayed in knots. Click on this indicator to select a speed source, see chapter 4.4.7.









Figure 4-7 Value / Speed Indicator

4.3.7 Operation Mode Softkeys

Press the respective softkey to change the operation mode.

Further operational items are operating elements on the front of the operator unit casing (see chapter 1.7) and a reset button on the back of the operator unit casing (see chapter 5.2).

Table 4-1 Operation Mode Softkeys

Element	Depiction	Function / Description
	Operation mode softkey, HDG	Activate heading control mode; Softkey turns to inverse color if operation mode is deactivated.
	Operation mode softkey, NAV	Activate waypoint steering mode; Softkey turns to inverse color if operation mode is deactivated.
	Operation mode softkey, NFU/FU	Activate manual steering via operation unit; Softkey turns to inverse color if operation mode is deactivated.
	Operation mode softkey, HDG TRIM	Trim function within heading control mode is activated, see chapter 4.4.1.
	Operation mode softkeys are unavailable (greyed out)	PilotStar® NX is in an inactive mode, see chapter 1.4.2.



To change the operation mode, the respective softkey has to be pressed for a defined time. Green colored time bar appears under the softkey while pressing the operation mode softkey. Release softkey as long as time bar is colored green. If the operation mode is pressed to long, a sound appears. While processing the change, the time bar is colored blue. After successful change of the operation mode, the color of the operation mode softkey turns in inverse color.




Figure 4-8 Green Colored Time Bar



Figure 4-9 Blue Colored Time Bar

4.4 Operation Displays Pages

	Input and operation of the display pages works by softkey elements on the touchscreen display and hardware operating elements on the front of the operator unit casing (chapter 1.7).
---	---

4.4.1 HDG Main

HDG main is the initial display page for operation within heading control mode. HDG main page is accessible via the respective operation mode softkey, see chapter 4.3.7. This display page has limited access during inactive mode, see chapter 4.5.





Figure 4-10 HDG Main Display Page

Pos.	Designation
1	Day / Night softkey See chapter 4.3.1

Pos.	Designation
2	<p>Trim softkey Softkey that enables trim function, see chapter 1.4.1.1. Within trim function, offset on set rudder is adjustable via softkeys. The red bars show the rudder limits.</p> <div data-bbox="469 535 826 618" style="border: 1px solid black; padding: 5px; text-align: center;"> <p>Actual Rudder</p>  </div> <p>To disable trim function, select NAV or NFU/FU within operation mode softkeys.</p>
3	<p>Fix Turn Indication of adjusted change value of set heading by pressing arrow softkeys, see Figure 4-10/11 Clicking on this indication opens RoT & Radius display, where also fix turn value is adjustable, see chapter 4.4.11.</p>
4	<p>Parameter See Chapter 4.3.5</p>
5	<p>Value See chapter 4.3.6</p>
6	<p>Limits See chapter 4.3.2</p>
7	<p>Heading Difference Graphical indication of difference between set heading and actual heading in degree, scale limit shows adjusted heading monitor, see 1.13.3</p>
8	<p>Heading Actual heading is displayed in degree. Heading source is adjustable by clicking on this indication, see chapter 4.4.8.</p>
9	<p>Operation mode softkeys See chapter 4.3.7 HDG softkey is activated</p>
10	<p>Simplified view softkey Opens a display page Simplified View, see chapter 4.4.13</p>
11	<p>HDG & Rudder Plot softkey Opens a display page, which shows a steering history of last past minutes as a graph, see chapter 4.4.4.</p>

Pos.	Designation
12	<p>Set Heading Set heading is displayed in degree. Set heading is editable with side arrows by adjusted fix turn value, see Figure 4-10/3. Set heading is adjustable with sidewise softkeys or rotary knob by 0.5 degree per detent of the rotary knob. Turning the rotary knob clockwise increase the set heading value. Turning the rotary knob counter clockwise decreases the set heading value.</p>
13	<p>Set RoT Indication of rate of turn (displayed in °/min) or radius (displayed in nautical miles) within heading change manoeuvre. Value is adjustable with side softkeys. It is possible to switch between radius controlled heading changes and rate of turn controlled heading changes by clicking on this indication, see chapter 4.4.11.</p>
14	<p>Actual Rudder Graphical indication of actual rudder angle as a tendency display. Scale of tendency display depends on configured maximum rudder value. Limit of indication show configured maximum rudder value, see chapter 5.3.7.46. The limit zones are displayed as red bars on the left and the right side. The display shows the view backwards, so that the right side of the rudder indication represents port side and the left side of the rudder indication represents starboard.</p>

4.4.2 NAV Main

NAV main is the initial display page for operation within waypoint steering mode. NAV main page is accessible via the respective operation mode softkey, see chapter 4.3.7. Connected route planning system generates all necessary steering data for waypoint steering.

This display page has limited access during inactive mode, see chapter 4.5.




Figure 4-11 NAV Main Display Page

Pos.	Designation
1	Day / Night softkey See chapter 4.3.1
2	Parameter See Chapter 4.3.5
3	Value See chapter 4.3.6
4	Limits See chapter 4.3.2

Pos.	Designation
5	<p>Cross Track Distance Graphical indication of difference between planned waypoint and current waypoint in degree, scale limit shows adjusted cross track error limit, see 1.13.4.</p>
6	<p>Heading Actual heading is displayed in degree. Heading source is adjustable by clicking on this indication, see chapter 4.4.8.</p>
7	<p>Operation mode softkeys See chapter 4.3.7 NAV softkey is activated</p>
8	<p>Track Data softkey Opens a display page, which shows a track history of last past minutes as a graph, see chapter 4.4.5.</p>
9	<p>HDG & Rudder Plot softkey Opens a display page, which shows a steering history of last past minutes as a graph, see chapter 4.4.4.</p>
10	<p>Set Course Over Ground Set course over ground is displayed in degree.</p>
11	<p>Set RoT Indication of rate of turn (displayed in °/min) or radius (displayed in nautical miles) within heading change manoeuvre. Value is adjustable with sidewise softkeys. It is possible to switch between radius controlled heading changes and rate of turn controlled heading changes by clicking on this indication, see chapter 4.4.11.</p>
12	<p>Actual Rudder Graphical indication of actual rudder angle as a tendency display. Scale of tendency display depends on configured maximum rudder value. Limit of indication show configured maximum rudder value, see chapter 5.3.7.46. The limit zones are displayed as red bars on the left and the right side. The display shows the view backwards, so that the right side of the rudder indication represents port side and the left side of the rudder indication represents starboard.</p>

4.4.3 NFU/FU Main

NFU/FU is the initial display page for operation within NFU/FU mode. this page is accessible via the respective operation mode softkey, see chapter 4.3.7. Within NFU/FU display page, there are two possibilities to set a rudder:

- NFU mode: rudder angle is set via control keys
- FU mode: entry of target rudder angle value via rotary knob

This display page has limited access during inactive mode, see chapter 4.5.




Figure 4-12 NFU/FU Main Display Page

Pos.	Designation
1	Day / Night softkey See chapter 4.3.1.
2	Actual Rudder Actual rudder angle is displayed in degree. If arrow indicator is displayed right, rudder angle is set on starboard side. If arrow indicator is displayed left, rudder angle is set on port side.

Pos.	Designation
3	Speed WT (Water tracked) or Speed BT (Bottom tracked) See chapter 4.3.6.
4	Set Rudder Set rudder angle is displayed in degree. If arrow indicator is displayed right, rudder angle is set on starboard side. If arrow indicator is displayed left, rudder angle is set on port side.
5	Heading Actual heading is displayed in degree. Heading source is adjustable by clicking on this indication, see chapter 4.4.8.
6	Operation mode softkeys See chapter 4.3.7. NFU/FU softkey is activated.
7	Rudder indication Graphical indication of set rudder angle and actual rudder angle. Upper outer line and lower outer line show actual rudder angle. Middle line shows set rudder angle. The limit zones are displayed as red bars on the left and the right side. The display shows the view backwards, so that the right side of the rudder indication represents port side and the left side of the rudder indication represents starboard.
8	NFU mode adjustment Rudder angle can be set via side softkey arrows. Right softkey arrow sets rudder angle on starboard side. Left softkey arrow sets rudder angle on port side.

4.4.4 HDG & Rudder Plot

This display page shows a steering history of last past minutes as a graph. This display page is accessible from display pages **HDG Main**, **HDG TRIM Main**, **NAV Main**, **Simplified View** and **Track Data** via respective softkey.





Figure 4-13 HDG & Rudder Plot Display Page

Pos.	Designation
1	Day / Night softkey See chapter 4.3.1
2	Parameter softkey Opens display page Parameter Memory , see chapter 4.4.10
3	Actual Rudder Actual rudder angle is displayed in degree. If arrow indicator is displayed right, rudder angle is set on starboard side. If arrow indicator is displayed left, rudder angle is set on port side.

Pos.	Designation
4	<p>Set Heading / Set Course Over Ground Set heading is displayed in degree within heading control mode. Set course over ground is displayed in degree within waypoint steering mode.</p>
5	<p>Heading Actual heading is displayed in degree. Heading source is adjustable by clicking on this indication, see chapter 4.4.8.</p>
6	<p>Time axis [min] Axis for time recorded in minutes. Round checkbox to switch axis resolution between 5 minutes and 20 minutes.</p>
7	<p>Graph History of actual rudder angle in degree, actual heading in degree and set heading (set course over ground within waypoint steering mode) in degree displayed as a graph, see legend Figure 4-13/12</p>
8	<p>Heading axis [°] Axis for heading recorded in degree. Round checkbox to switch axis resolution between +/- 20 degree and +/-60 degree.</p>
9	<p>Operation mode softkeys See chapter 4.3.7</p>
10	<p>Main softkey Opens previous main page (HDG Main, HDG TRIM Main or NAV Main)</p>
11	<p>Simplified view softkey Opens a display page Simplified View, see chapter 4.4.13</p>
12	<p>Rudder angle axis [°] Axis for rudder angle recorded in degree. Round checkbox to switch axis resolution between half of maximum rudder angle (e.g. +/- 8 degree) and maximum rudder angle (e.g. +/- 16 degree).</p>
13	<p>Legend of graph Legend of graph appears by clicking on the symbol.</p> <div data-bbox="533 1868 743 1980" style="border: 1px solid black; padding: 5px; width: fit-content;">  </div>

4.4.5 Track Data

This display page shows a track history of last past minutes as a graph. This display page is accessible only within waypoint steering mode from display page **NAV Main** and **HDG & Rudder Plot** via respective softkey.




Figure 4-14 Track Data Display

Pos.	Designation
1	Day / Night softkey See chapter 4.3.1
2	Parameter softkey Opens display page Parameter Memory , see chapter 4.4.10.
3	Distance to Course line Distance to course line is displayed in meter. Arrow indicator shows the direction of the distance from the course line.
4	Set COG Set course over ground is displayed in degree.
5	Heading Actual heading is displayed in degree. Heading source is adjustable by clicking on this indication, see chapter 4.4.8.

Pos.	Designation
6	<p>Heading change mark A horizontal line shows point when a heading change caused by calling up of the next waypoint is performed.</p>
7	<p>Current ship position.</p>
8	<p>Colored midline shows course line / track.</p>
9	<p>History of distance to course line in meter The distance between two dotted horizontal lines shows time interval of one minute. Adjusted track limit is readable above the graph. Graph is limited to each side by the adjusted track limit. Track limit is adjustable at display page Limits, see chapter 4.4.6.</p>
10	<p>Operation mode softkeys See chapter 4.3.7.</p>
11	<p>Main softkey Opens display page NAV Main, see chapter 4.4.2.</p>
12	<p>HDG & Rudder Plot softkey Opens a display page HDG & Rudder Plot, see chapter 4.4.4.</p>

4.4.6 Limits

On this display page the available limits are adjustable. This display page is accessible from display pages **HDG Main**, **HDG TRIM Main** and **NAV Main** by clicking on limits indication, see chapter 4.3.2.


 D	If no user action is recognized for more than 15 seconds, view returns to previous page.
---	--




Figure 4-15 Limits Display Page

Pos.	Designation
1	Track limit for cross track error in meter, see chapter 1.13.4. The track limit value is changeable in steps of 1 deg in the range from 5 deg up to 30 deg.
2	Course trim limit in degree, see chapter 1.13.5. The course trim value is changeable in steps of 1 m in the range from 10 m up to 2000 m.

Pos.	Designation
3	Off heading in degree, see chapter 1.13.3. The off-heading value is changeable in steps of 1 deg in the range from 5 deg up to 30 deg.
4	Heading monitor in degree, see chapter 1.13.2. The heading monitor value is changeable in steps of 1 deg in the range from 5 deg up to 30 deg.
5	Rudder angle limit in degree, see chapter 1.13.1. The rudder limit value is changeable in steps of 1 deg in the range from 5 deg up to max rudder value.
6	Softkeys to adjust selected limit values.
7	Cancel softkey Opens previous display page. Not saved changes will be lost.

4.4.7 Speed Selection

Display page to select speed source. This display page is accessible from display pages **HDG Main**, **HDG TRIM Main** and **NAV Main** by clicking on value / speed indication, see chapter 4.3.6.

	<p>If no user action is recognised for more than 15 seconds, view returns to previous page.</p>
---	---




Figure 4-16 Speed Selection Display Page

Pos.	Designation
1	<p>System Radio button to select automatic system selection of speed source. Name of automatically selected speed source is displayed after colon. Selection is only possible, when speed sensor is available. Speed value is measured by sensor. The speed is marked with WT for water tracked or BT for bottom tracked.</p>
2	<p>Manual Speed Radio button to select manual input of speed value.</p>

4.4.8 HDG Selection

Display page to select compass for heading source. This display page is accessible from display pages **HDG Main**, **HDG TRIM Main**, **NAV Main**, **HDG & Rudder Plot** and **Track Data** by clicking on heading indication.



	<p>If no user action is recognized for more than 15 seconds, view returns to previous page.</p>
---	---



Figure 4-17 HDG Selection Display Page

	<p>If the autopilot is installed in an Integrated Navigation System (INS), which meets the standard IEC 61924-2 the heading information is distributed to the autopilot via a Consistent Common Reference System (CCRS). Therefore, the heading source is selected automatically and cannot be changed by the operator.</p>
---	---

Pos.	Designation
1	<p>System Radio button to select automatic system selection of heading source. Name of automatically selected heading source is displayed after colon. If system selection is activated, a heading source is selected automatically.</p>
2	<p>Magnet Radio button to select magnetic heading source, if available Name of magnet heading source is displayed after colon. If several magnet heading sources are connected within a navigation system, the heading source with the better performance or with a verified sequence is selected automatically.</p>
3	<p>Gyro Radio button to select gyro heading source, if available Name of gyro heading source is displayed after colon. If several gyro heading sources are connected within a navigation system, the heading source with the better performance or with a verified sequence is selected automatically. GPS heading sources are treated like gyro heading sources.</p>
4	<p>Cancel softkey Opens previous display page Not saved changes will be lost</p>

4.4.9 Parameter Memory

Display page to select a stored parameter set or to create a new parameter set. This display page is accessible via softkey **Parameter** within display pages **HDG & Rudder Plot** and **Track Data**. Within display pages HDG Main and NAV Main this display page is accessible by clicking on parameter indication, see chapter 4.3.3.


	<p>If no user action is recognised for more than 15 seconds, view returns to previous page.</p>
---	---



Figure 4-18 Parameter Memory Display Page

Pos.	Designation
1	<p>Set selection</p> <p>To modify a stored parameter set, select respective parameter set and select softkey Modify, see Figure 4-18/2.</p> <p>To create a new parameter set, select an empty entry and select softkey Modify, see Figure 4-18/2.</p>

Pos.	Designation
2	Modify softkey Opens display page Parameter Modify to change parameter set, see chapter 4.4.10
3	Cancel softkey Opens previous display page Not saved changes will be lost

4.4.10 Parameter Modify

Display page to change stored parameter set or to create a new parameter set. This display page is accessible via softkey **Modify** within display page **Parameter Memory**.





Figure 4-19 Parameter Modify Display Page

Pos.	Designation
1	Parameter selection Select respective parameter
2	Softkeys to adjust selected parameter value
3	Cancel softkey Opens previous display page Not saved changes will be lost.

4.4.11 RoT & Radius

Display page to switch between radius controlled heading changes and rate of turn controlled heading changes and to adjust heading change values.

This display page is accessible from display pages **HDG Main**, **HDG TRIM Main** and **NAV Main** by clicking on RoT / Rad indication or the Fix turn value on the **HDG Main** and **HDG Trim Main** page.

	<p>If no user action is recognised for more than 15 seconds, view returns to previous page.</p>
---	---




Figure 4-20 RoT & Radius Display Page

Pos.	Designation
1	<p>Fix turn</p> <p>Adjust fix turn change value for heading within heading course mode, see chapter 4.4.1.</p> <p>The fix turn value is changeable in steps of 1 deg in the range from 1 deg up to 180 deg.</p>

Pos.	Designation
2	<p>Rudder trim Adjust the rudder Trim value only in HDG Trim Mode (displayed in degree) Starts always with 0 degree when HDG Trim is activated. The rudder trim value is changeable in steps of 1 deg in the range from -max. rudder angle up to +max. rudder angle (max. rudder angle is adjustable within service menu, see chapter 5.3.7.46).</p>
3	<p>Selection drop-down Select between: Rad radius controlled heading changes RoT rate of turn controlled heading changes</p>
4	<p>Radius Radius value for radius controlled heading changes (displayed in nautical miles) Radius value is changeable in steps of 0.1 NM in the range from 0.2 NM up to 99.0 NM.</p>
5	<p>RoT Rate of turn value for rate of turn controlled heading changes (displayed in °/min) Rate of turn is changeable in steps of 1 °/min in the range from 5 °/min up to 500 °/min.</p>
6	<p>Softkeys to adjust selected parameter value</p>
7	<p>Cancel softkey Opens previous display page Not saved changes will be lost.</p>

4.4.12 Ship Data

Display page to get ship information. This display page is accessible from main display page only within inactive mode via respective softkey, see Figure 4-23.



Figure 4-21 Ship Data Display Page

4.4.13 Simplified View

This display page is accessible only within heading control mode from display page **HDG Main** and **HDG & Rudder Plot**, via respective softkey.

Simplified view is a simplification and summary of display page HDG Main, see chapter 4.4.1.




Figure 4-22 Simplified View Display Page

Pos.	Designation
1	<p>Set Heading</p> <p>Set heading is displayed in degree.</p> <p>Set heading is editable with side arrows by adjusted fix turn value, see Figure 4-10/3.</p> <p>Set heading is adjustable with rotary knob by 0.5 degree per detent of the rotary knob. Turning the rotary knob clockwise increase the set heading value. Turning the rotary knob counter clockwise decreases the set heading value.</p>

Pos.	Designation
2	Heading Actual heading is displayed in degree. Heading source is adjustable by clicking on this indication, see chapter 4.4.8.
3	Operation mode softkeys See chapter 4.3.7
4	HDG & Rudder Plot softkey Opens a display page, which shows a steering history of last past minutes as a graph, see chapter 4.4.4.
5	Main softkey Opens HDG Main , see chapter 4.4.1.
6	Set Rudder Set rudder is displayed in degree. If arrow indicator is displayed right, rudder angle is set on starboard side. If arrow indicator is displayed left, rudder angle is set on port side.
7	Actual Rudder Actual rudder angle is displayed in degree. If arrow indicator is displayed right, rudder angle is set on starboard side. If arrow indicator is displayed left, rudder angle is set on port side. If there is a rudder on starboard (STB) and port side (PT), there will be two displays. If there is only one rudder, there will be one display.

4.5 Inactive Modes

During inactive mode, there is no full access to all display pages and function. There is only one main display during inactive mode.




Figure 4-23 Main Display Page in Inactive Mode

Table 4-2 Access to Display Pages during Inactive Mode

Display	Inactive Access
HDG Main	Limited Access, see Figure 4-23 Value view and display adjustment only, no steering control
NAV Main	Limited Access, see Figure 4-23 Value view and display adjustment only, no steering control
NFU/FU	No access
HDG & Rudder Plot	No access
Track Data	No access
Limits	Full access
Speed Selection	Full access
HDG Selection	Full access
Parameter Memory	Full access
Parameter Modify	Limited Access

Display	Inactive Access
RoT & Radius	Full access
Ship Data	Access only in inactive mode
Simplified View	No access

4.6 Basic Operating Steps

4.6.1 Adjust RoT or Radius Controlled Heading changes

- Precondition
- Operation mode heading control or waypoint steering is enabled
 - Main display page of operation mode is active

1. Click on **RoT / Rad** indication.
 - **RoT & Radius** display page opens.
2. Use drop-down list within field **Selection** to select control method **RoT** or **Rad** for course change.
 - **SET LED** is flashing.
3. Click on respective indication e.g. **Radius [NM]** to adjust value
4. Adjust value with **+** and **-** keys.
5. Confirm adjustment with **SET** button.
 - **RoT / Rad** indication on main display is adjusted.
 - Display page shuts down.

4.6.2 Set Digital NFU Tiller

- Precondition
- Operation mode NFU / FU is enabled
 - Main display page of operation mode is active



Within NFU tiller function, rudder moves during adjustment of set rudder angle.

1. Use side arrow softkeys to set a rudder angle, see Figure 4-12/8.



- Rudder moves.
- Set rudder value is changed with a rate of 2,5 °/s as long as a softkey is pressed.
- Display shows adjusted rudder angle, see Figure 4-12/4.

4.6.3 Set Digital FU Tiller

- Precondition
- Operation mode NFU / FU is enabled
 - Main display page of operation mode is active



Within FU tiller function, rudder moves after adjustment of set rudder angle.

1. Turn rotary knob to set a rudder angle.
 - Display shows adjusted rudder angle, see Figure 4-12/4.
 - Rudder moves.

4.6.4 Heading Control Mode Operating Steps



The maximum adjustable set heading difference for one set heading command is limited to 270°. Set heading changes > 270° will be discarded.

4.6.4.1 Change Set Heading via Rotary Knob - Preselected Mode

- Precondition
- Operation mode heading control is enabled
 - Main display page of operation mode or **HDG & Rudder Plot** display is active.

1. Use **Rotary Knob** to set a heading.
 - Display shows adjusted **Set Heading**, see Figure 4-10/11.
 - **SET LED** is flashing.
2. Confirm adjustment with **SET** button.
 - Autopilot controls rudder in order to approach set heading.

4.6.4.2 Change Set Heading via Rotary Knob - Direct Mode

- Precondition
- Operation mode heading control is enabled
 - Main display page of operation mode or **HDG & Rudder Plot** display is active.

1. Press **Rotary Knob**.
2. Turn **Rotary Knob** while still pressed.
 - Value of **Set Heading changes** without confirmation, see Figure 4-10/11.
 - Autopilot controls rudder in order to approach set heading.

4.6.4.3 Change Set Heading via Fix Turn

- Precondition
- Operation mode heading control is enabled.
 - Main display page of operation mode is active.

1. Use **Fix Turn** softkeys to set a heading, see Figure 4-10/11.
 - Display shows adjusted set heading, see Figure 4-10/11.
 - **SET LED** is flashing.
2. Confirm adjustment with **SET** button.
 - Autopilot controls rudder in order to approach set heading.

4.6.4.4 Using HDG Trim Function

- Precondition
- Operation mode heading control is enabled.
 - Main display page of operation mode is active.

1. Press softkey **Trim** to enable trim function, see Figure 4-10/2.
 - Operation mode softkey **HDG** changes to **HDG TRIM**.



- Side softkeys on **Actual Rudder** indication appear.




2. Use side softkeys on **Actual Rudder** indication to adjust actual rudder.
 - Rudder moves.
 - Adjusted rudder angle is displayed on softkey **Trim**.




To disable trim function, select NAV or NFU/FU within operation mode softkeys.


5 Service and Configuration

5.1 Safety Information

<p>WARNING</p> 	<p>Danger due to improper operation and purpose</p> <p>Risk of serious injury and material damage</p> <ul style="list-style-type: none">• Use product only for the intended purpose.• Perform operation steps according to this manual.• Do not make any product modifications without authorization.
---	--

<p>WARNING</p> 	<p>Danger due to operation / maintenance by unqualified personnel</p> <p>Risk of serious injury and material damage</p> <ul style="list-style-type: none">• Keep unqualified personnel away from the operation area.• All operation / maintenance must be performed only by qualified personnel.
--	--

5.2 Setting Reset

<p>CAUTION</p> 	<p>Hazard due to wrong use of reset button</p> <p>Risk of material damage</p> <ul style="list-style-type: none">• Do not use metallic objects to push the reset button.
---	--

Reset button is located at the backside of the casing.
Use the **Reset** button to restart the operator unit. Reset does not affect configuration settings.

5.3**Service Menu**


In case of Master – Slave installation access to service menu and configurations are possible from each operation unit. Configurations are distributed to all installed slave and master units. Only configurations within service display page **Local Settings** are specific for every operator unit.



In case of Master – Master installation all configurations are specific for every operator unit.

5.3.1 Open Service Menu

Precondition Operator Unit is within inactive mode

	For service password contact Raytheon Anschütz service.
---	---

1. Press **Set** button and **Alarm Acknowledgement** button for 4 seconds.
 - Password input field appears.
 - **On-screen keyboard** appears.



2. Use **on-screen keyboard** to enter service password
 - **Service Menu Main** display page opens

5.3.2 Close Service Menu

1. Press **Rotary knob** within any service display page.
 - Service menu shuts down.
 - Not saved configurations will be lost.

or

1. Press softkey **Cancel** within **Service Menu Main**.
 - Service menu shuts down.

5.3.3 Structure of Service Menu

The **Service Menu Main** contains 5 menu points. The menu points **PilotStar® NX Settings** and **Steering Components** consist of several configuration sets.




Figure 5-1 Service Menu Structure

5.3.4 General Display Elements for Service Menu

There are 4 types of input fields for configurable parameters:

- Combobox
- Text Field
- Number Field
- Checkbox

There is one another not editable field:

- Information field

5.3.4.1 Combobox

A combobox includes several predefined values, which can be selected via +/- softkeys.

If combobox is selected via touchscreen, +/- softkeys appear.

For configuration of combobox, see chapter 5.3.8.1




Figure 5-2 Combobox and Selection Softkeys

5.3.4.2 Number Field

A number field can be configured via +/- softkeys. If number field is selected via touchscreen, +/- softkeys appear.

For configuration of number field, 5.3.8.4




Figure 5-3 Number field and +/- Softkeys

5.3.4.3 Checkbox

A checkbox can be select via **check** softkey. If checkbox is selected via touchscreen, **check** softkey appears.

For configuration of checkbox, see chapter 5.3.8.2.




Figure 5-4 Checkbox and Check Softkey

5.3.4.4 Text Field

A text field includes text characters, which can be edited via **on-screen keyboard**. If text field is selected via touchscreen, **edit** softkey appears. After selection of edit softkey, on-screen keyboard appears.

For configuration of text field, see chapter 5.3.8.3




Figure 5-5 Text Field and Edit softkey



Figure 5-6 On-Screen Keyboard

5.3.4.5 Information Field

An information field includes not editable information within the **Setup Assistant** function. This information leads through the menu and gives advices for correct completion of **Setup Assistant**.





Figure 5-7 Information Field

5.3.5 Service Menu Points / Display Pages

	Input and operation of the display pages works by softkey elements on the touchscreen display and hardware operating elements on the front of the operator unit casing (chapter 1.7).
---	---

5.3.5.1 Service Menu Main

This service display page is the initial display page after starting service menu. Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-8 Service Menu Main Display Page

Pos.	Designation
1	Setup Assistant softkey Opens Setup Assistant function, see chapter 5.3.6.8.
2	Sensor Data softkey Opens Service Sensor Data service display page, see chapter 5.3.6.2.

Pos.	Designation
3	Local Settings softkey Opens Local Settings service display page, see chapter 5.3.6.2
4	Error Log softkey Opens Error Log service display page, see chapter 5.3.6.4.
5	Export / Import softkey Opens Export / Import service display page, see chapter 5.3.6.5.
6	Steering Components softkey Opens Steering Components service display page, see chapter 5.3.6.6.
7	PilotStar® NX Settings softkey Opens PilotStar® NX Settings service display page, see chapter 5.3.6.7.
8	Status Header Line The header line includes the name of the current service menu point in the top left corner and current configuration set in the middle.
9	Cancel softkey Shuts down service menu.

5.3.5.2 Display Sensor Data

This service display page shows the received sensor data.




Figure 5-9 Sensor Data Service Display Page

Sensor information is built according to following scheme:

Source Identification: Sensor value @ time stamp: selection flag if available from sensor (if applicable further marking of sensor value e.g. corrected_heading)

5.3.5.3 Local Settings

This service display page includes configuration, which are specific for every operator unit.

Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-10 Local Settings Service Display Page

Pos.	Designation
1	<p>Configurable Parameters See chapter 5.3.7</p> <p>Note: IP addresses from multicast IP range (see annex 450 Support) are not allowed.</p> <p>The following IP address ranges are allowed: 10.0.0.0 - 10.255.255.255 172.16.0.0 - 172.31.255.255 192.168.0.0 - 192.168.255.255</p>
2	<p>Status Header Line The header line includes the name of the current service menu point in the top left corner.</p>

Pos.	Designation
3	Edit softkey or +/- softkeys or check softkey Softkey to configure parameter Kind of softkey depends on kind of input field, see chapter 4.3.5.
4	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1

5.3.5.4 Error Log

This service display page shows history of occurred alerts up to 32 entries. Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-11 Error Log Service Display Page

Pos.	Designation
1	RTC Status Indicates if the autopilot has ever received UTC time. 1 UTC time received at least one time any time in the past. 0 UTC-time received.
2	Reset Counter Counts the number of resets.
3	Actual Number of Entries Current number of entries at the Error Log. If the number of entries achieves maximum number of entries all new incoming messages are not shown in Error Log .
4	Maximum Number of Entries Maximum possible number of entries.
5	Version Current Error Log version - for development only.

Pos.	Designation
6	Operating time Total operating time is displayed.
7	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1.
8	Count Number of rests is displayed.
9	Error Message Message text is displayed.
10	Entry Number of current entry is displayed.
11	Status Header Line The header line includes the name of the current service menu point in the top left corner.
12	+/- softkeys Shows next or previous entry.
13	Delete Deletes all entries of Error Log .
14	Next Shows next entry.

5.3.5.5 Export / Import

This service display page enables export and import of current configuration. Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-12 Export / Import Service Display Page

Pos.	Designation
1	Import Indication See chapter 5.3.11.
2	Export Indication See chapter 5.3.10.
3	Status Header Line The status header line indicates the function of this display page in the middle of the header line. The top left corner shows that this display page is part of service menu.
4	+/- softkeys Changes combobox selection of Export / Import indication.
5	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1.

5.3.5.6 Steering Components

This service display page enables the configuration of connected devices. Alert messages can appear in the status header line during service menu, see chapter 4.3.4.

	<p>For more Information about steering components refer to Documentation 3963 Configuration Tool.</p> <p>The parameters within Steering Components should only be configured by Raytheon Anschutz service personnel.</p>
---	--




Figure 5-13 Steering Components Service Display Page

Pos.	Designation
1	Configurable Parameters See chapter 5.3.7. Use touchscreen to scroll up and down.
2	Status Header Line The header line includes the name of the component to configure in the middle of the header line. The top left corner shows that this display page is part of service menu.

Pos.	Designation
3	Edit softkey or +/- softkeys or check softkey Softkey to configure parameter Kind of softkey depends on kind of input field, see chapter 5.3.5.
4	Next softkey Opens next configuration set, see chapter 5.3.4.
5	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1.

5.3.5.7 PilotStar® NX Settings

This service display page enables configuration of the PilotStar® NX Autopilot itself. Alert messages can appear in the status header line during service menu, see chapter 4.3.4.

	The parameters within PilotStar® NX Settings should only be configured by Raytheon Anschutz service personnel.
---	---





Figure 5-14 PilotStar® NX Settings Service Display Page


Pos.	Designation
1	Configurable Parameters See chapter 5.3.7. Use touchscreen to scroll up and down.
2	Status Header Line The header line includes the name of the configuration set to configure in the middle of the header line, see chapter 5.3.4. The top left corner shows that this display page is part of service menu.

Pos.	Designation
3	Edit softkey or +/- softkeys or check softkey Softkey to configure parameter Kind of softkey depends on kind of input field, see chapter 5.3.5.
4	Next softkey Opens next configuration set, see chapter 5.3.4.
5	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1

5.3.5.8 Setup Assistant

The setup assistant gives a guided setting into operation. During the setup assistant, the configuration will be aligned with the characteristics of the existing system. The setup assistant guides through the menu and could only be finished, if all required entries will be done.

	Input and operation of the display pages works by softkey elements on the touchscreen display and hardware operating elements on the front of the operator unit casing (chapter 1.7).
---	---

WARNING 	<p>System configuration may cause rudder movements.</p> <p>Risk of serious injury and material damage</p> <ul style="list-style-type: none"> • Use product only for the intended purpose. • Perform operation steps according to this manual.
--	--

Influenced Parameter

The following parameters could be changed by the setup assistant. These parameters will be overwritten by the values, which are adjusted within the setup assistant. If one of these parameters requires system specific adjustments or if the one of these parameters was adjusted before the system assistant was started, this parameter has to be checked within the respective service menu point after finishing of the setup assistant. Parameter, which are not listed below, will not be changed by the setup assistant.

Table 5-1 Setup Assistant Influenced Parameter

Device	Influenced Parameter
PilotStar® NX operator unit	PSIFs, Instance Number, CAN Group, CAN Dev. Nb., CAN ID, Serial 1, Serial 2, Serial 3, Alert Mgr. UDP, BNWAS Mgr. UDP, MISC, NAVD, PROP, RCOM, SATD, TIME, TGTD, USR1, USR2, USR3, USR4, USR5, USR6, USR7, USR8, VDRD, Outgoing transm. Grp, Shiplength, No. of Rudder, max. Rudder Angle, Length, eff. Ship Length

Device	Influenced Parameter
PilotStar® NX interface unit	Analog Out Loop (B39), Analog Out Loop (B44), Pulse Log Input, PLOG [pulses/NM], ACO Probe Input, ACO Probe freq. [Hz], Max. Rudder [deg], Assignment, Deadband P1 [deg], Deadband P2 [deg], Deadband P1+P2 [deg], Analog Gain RudOut 1, Analog Gain RudOut 2, D-Return P1, D-Return P2, D-Return P1+P2, Solenoid Hyster. [%], Feedback Input, Gyro Input (B25), Magnetic Input (B29), Speed Input (B35)
FU tiller	Steering Position
NFU tiller	Max. Rudder [deg], Steering Position
Hand wheel	Steering Position

5.3.5.8.(1) Master/Slave

This setup assistant display page enables configuration of operator unit as slave or master unit.

Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-15 Master/Slave Setup Assistant Display Page

Pos.	Designation
1	Information and Configurable Parameters For configurable parameters see chapter 5.3.7. Use touchscreen to scroll up and down.
2	Status Header Line The header line includes the name of the configuration set to configure in the middle of the header line, see chapter 5.3.4. The top left corner shows that this display page is part of setup assistant.
3	Next softkey Opens next configuration set, see chapter 5.3.4.
4	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1

5.3.5.8.(2) System Type

This setup assistant display page enables configuration of system as standalone or NautoSteer AS integration.

Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-16 System Type Setup Assistant Display Page

Pos.	Designation
1	Information and Configurable Parameters For configurable parameters see chapter 5.3.7. Use touchscreen to scroll up and down.
2	Status Header Line The header line includes the name of the configuration set to configure in the middle of the header line, see chapter 5.3.4. The top left corner shows that this display page is part of setup assistant.
3	Next softkey Opens next configuration set, see chapter 5.3.4.
4	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1

5.3.5.8.(3) CAN Bus Addresses

This setup assistant display page enables configuration of CAN bus address for the used operator unit. .

Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-17 CAN Bus Addresses Setup Assistant Display Page

Pos.	Designation
1	Information and Configurable Parameters For configurable parameters see chapter 5.3.7. Use touchscreen to scroll up and down.
2	Status Header Line The header line includes the name of the configuration set to configure in the middle of the header line, see chapter 5.3.4. The top left corner shows that this display page is part of setup assistant.
3	Next softkey Opens next configuration set, see chapter 5.3.4.
4	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1

5.3.5.8.(4) Additional Tillers

This setup assistant display page enables configuration of further steering components. Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-18 Additional Tillers Setup Assistant Display Page

Pos.	Designation
1	Information and Configurable Parameters For configurable parameters see chapter 5.3.7. Use touchscreen to scroll up and down.
2	Status Header Line The header line includes the name of the configuration set to configure in the middle of the header line, see chapter 5.3.4. The top left corner shows that this display page is part of setup assistant.
3	Next softkey Opens next configuration set, see chapter 5.3.4.
4	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1

5.3.5.8.(5) Heading Input

This setup assistant display page enables configuration of heading input. Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-19 Heading Input Setup Assistant Display Page

Pos.	Designation
1	Information and Configurable Parameters For configurable parameters see chapter 5.3.7. Use touchscreen to scroll up and down.
2	Status Header Line The header line includes the name of the configuration set to configure in the middle of the header line, see chapter 5.3.4. The top left corner shows that this display page is part of setup assistant.
3	Next softkey Opens next configuration set, see chapter 5.3.4.
4	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1

5.3.5.8.(6) Speed Input

This setup assistant display page enables configuration of speed input. Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-20 Speed Input Setup Assistant Display Page

Pos.	Designation
1	Information and Configurable Parameters For configurable parameters see chapter 5.3.7.
2	Status Header Line The header line includes the name of the configuration set to configure in the middle of the header line, see chapter 5.3.4. The top left corner shows that this display page is part of setup assistant.
3	Next softkey Opens next configuration set, see chapter 5.3.4.
4	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1

5.3.5.8.(7) BAM/BNWAS

This setup assistant display page enables configuration of interfaces for BAM and BNWAS.

Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-21 BAM/BNWAS Setup Assistant Display Page

Pos.	Designation
1	Information and Configurable Parameters For configurable parameters see chapter 5.3.7. Use touchscreen to scroll up and down.
2	Status Header Line The header line includes the name of the configuration set to configure in the middle of the header line, see chapter 5.3.4. The top left corner shows that this display page is part of setup assistant.
3	Next softkey Opens next configuration set, see chapter 5.3.4.
4	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1

5.3.5.8.(8) VDR

This setup assistant display page enables information of interface for VDR. Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-22 VDR Setup Assistant Display Page

Pos.	Designation
1	Information
2	Status Header Line The header line includes the name of the configuration set to configure in the middle of the header line, see chapter 5.3.4. The top left corner shows that this display page is part of setup assistant.
3	Next softkey Opens next configuration set, see chapter 5.3.4.
4	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1

5.3.5.8.(9) Steering Locations

This setup assistant display page enables configuration of steering location for connected steering devices.

Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-23 Steering Locations Setup Assistant Display Page

Pos.	Designation
1	Information and Configurable Parameters For configurable parameters see chapter 5.3.7. Use touchscreen to scroll up and down.
2	Status Header Line The header line includes the name of the configuration set to configure in the middle of the header line, see chapter 5.3.4. The top left corner shows that this display page is part of setup assistant.
3	Next softkey Opens next configuration set, see chapter 5.3.4.
4	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1

5.3.5.8.(10) Ship Parameters

This setup assistant display page enables configuration of essential ship parameter. Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-24 Ship Parameters Setup Assistant Display Page

Pos.	Designation
1	Information and Configurable Parameters For configurable parameters see chapter 5.3.7.
2	Status Header Line The header line includes the name of the configuration set to configure in the middle of the header line, see chapter 5.3.4. The top left corner shows that this display page is part of setup assistant.
3	Next softkey Opens next configuration set, see chapter 5.3.4.
4	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1

5.3.5.8.(11) Rudder Feedback

This setup assistant display page enables configuration of rudder feedback settings. Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-25 Rudder Feedback Setup Assistant Display Page

Pos.	Designation
1	Information and Configurable Parameters For configurable parameters see chapter 5.3.7. Use touchscreen to scroll up and down.
2	Status Header Line The header line includes the name of the configuration set to configure in the middle of the header line, see chapter 5.3.4. The top left corner shows that this display page is part of setup assistant.
3	Next softkey Opens next configuration set, see chapter 5.3.4.
4	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1

5.3.5.8.(12) Rudder Control

This setup assistant display page enables configuration of output for set rudder within standalone system.

Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-26 Rudder Control Setup Assistant Display Page

Pos.	Designation
1	Information and Configurable Parameters For configurable parameters see chapter 5.3.7.
2	Status Header Line The header line includes the name of the configuration set to configure in the middle of the header line, see chapter 5.3.4. The top left corner shows that this display page is part of setup assistant.
3	Next softkey Opens next configuration set, see chapter 5.3.4.
4	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1

5.3.5.8.(13) Heading Control

This setup assistant display page enables information of heading control. Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-27 Heading Control Setup Assistant Display Page

Pos.	Designation
1	Information
2	Status Header Line The header line includes the name of the configuration set to configure in the middle of the header line, see chapter 5.3.4. The top left corner shows that this display page is part of setup assistant.
3	Next softkey Opens next configuration set, see chapter 5.3.4.
4	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1

5.3.5.8.(14) NAV Control

This setup assistant display page enables configuration and information of interface for NAV control.

Alert messages can appear in the status header line during service menu, see chapter 4.3.4.




Figure 5-28 NAV Control Setup Assistant Display Page

Pos.	Designation
1	Information and Configurable Parameters For configurable parameters see chapter 5.3.7.
2	Status Header Line The header line includes the name of the configuration set to configure in the middle of the header line, see chapter 5.3.4. The top left corner shows that this display page is part of setup assistant.
3	Next softkey Opens next configuration set, see chapter 5.3.4.
4	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1

5.3.5.8.(15) Summary

This setup assistant display page enables summary of configuration within setup assistant and configuration of Ethernet interface.

Alert messages can appear in the status header line during service menu, see chapter 4.3.4.



Figure 5-29 Summary Setup Assistant Display Page

Pos.	Designation
1	Information and Configurable Parameters For configurable parameters see chapter 5.3.7. Use touchscreen to scroll up and down.
2	Status Header Line The header line includes the name of the configuration set to configure in the middle of the header line, see chapter 5.3.4. The top left corner shows that this display page is part of setup assistant.
3	Next softkey Opens next configuration set, see chapter 5.3.4.
4	Cancel softkey Opens Service Menu Main display page, see chapter 5.3.6.1

5.3.6 Configurable Parameters

There are several sets of configurable parameters:

- Table 5-2 Parameters within PilotStar® NX Settings / Ship Data
- Table 5-3 Parameters within PilotStar® NX Settings / System
- Table 5-4 Parameters within PilotStar® NX Settings / Interfaces
- Table 5-5 Parameters within PilotStar® NX Settings / Controller
- Table 5-6 Parameters within Steering Components / PSIF
- Table 5-7 Parameters within Steering Components / Tiller Hand Wheel
- Table 5-8 Parameters within Steering Components / CAN Distribution Unit
- Table 5-9 Parameters within Local Settings
- Table 5-10 Parameters within Setup Assistant / Master/Slave
- Table 5-11 Parameters within Setup Assistant / System Type
- Table 5-12 Parameters within Setup Assistant / CAN Bus Addresses
- Table 5-13 Parameters within Setup Assistant / Additional Tillers
- Table 5-14 Parameters within Setup Assistant / Heading Input
- Table 5-15 Parameters within Setup Assistant / Speed Input
- Table 5-16 Parameters within Setup Assistant / BAM/BNWAS
- Table 5-17 Parameters within Setup Assistant / Steering Locations
- Table 5-18 Parameters within Setup Assistant / Ship Parameters
- Table 5-19 Parameters within Setup Assistant / Rudder Feedback
- Table 5-20 Parameters within Setup Assistant / Rudder Control
- Table 5-21 Parameters within Setup Assistant / NAV Control

Table 5-2 Parameters within PilotStar® NX Settings / Ship Data

PilotStar® NX Settings / Ship Data			
Parameter	Description	Type	Default
Shipname	5.3.7.1	Text Field	
IMO No.	5.3.7.2	Text Field	
Length	5.3.7.3	Number Field	
No. of Rudder	5.3.7.4	Number Field	1
Rudder Type	5.3.7.5	Combobox	Normal
Order Code	5.3.7.6	Text Field	

Table 5-3 Parameters within PilotStar® NX Settings / System

PilotStar® NX Settings / Systems			
Parameter	Description	Type	Default
Instance Number	5.3.7.7	Number Field	1
Day Color	5.3.7.8	Combobox	Day1
Night Color	5.3.7.9	Combobox	Night1
Software Archive	5.3.7.10	Combobox	
Software Action	5.3.7.11	Combobox	None
Service Menu enabled	5.3.7.12	Checkbox	Inactive

Table 5-4 Parameters within PilotStar® NX Settings / Interfaces

PilotStar® NX Settings / Systems			
Parameter	Description	Type	Default
Serial 1	5.3.7.13	Combobox	nmea4800bd
Serial 2	5.3.7.14	Combobox	nmea4800bd
Serial 3	5.3.7.15	Combobox	bam38400bd
CAN Group	5.3.7.16	Number Field	0
CAN- Dev. Nb.	5.3.7.17	Number Field	0
CAN ID	5.3.7.18	Number Field	0
CAN Nav.Data enabled	5.3.7.19	Checkbox	Active
Alert Mgr. UDP	5.3.7.20	Text Field	
Alert Mgr. Type	5.3.7.21	Combobox	INS
BNWAS Mgr. UDP	5.3.7.22	Text Field	
PSIFs	5.3.7.23	Number Field	1
CAN Central Dimming	5.3.7.24	Checkbox	Inactive
DDC Central Dimming	5.3.7.25	Checkbox	Inactive
INS	5.3.7.26	Checkbox	Inactive
Turn headings 180deg	5.3.7.27	Checkbox	Inactive
MISC	5.3.7.28	Checkbox	Inactive

PilotStar® NX Settings / Systems			
Parameter	Description	Type	Default
TGTD	5.3.7.29	Checkbox	Inactive
SATD	5.3.7.30	Checkbox	Inactive
NAVD	5.3.7.31	Checkbox	Inactive
VDRD	5.3.7.32	Checkbox	Inactive
RCOM	5.3.7.33	Checkbox	Inactive
TIME	5.3.7.34	Checkbox	Inactive
PROP	5.3.7.35	Checkbox	Inactive
USR1	5.3.7.36	Checkbox	Inactive
USR2	5.3.7.37	Checkbox	Inactive
USR3	5.3.7.38	Checkbox	Inactive
USR4	5.3.7.39	Checkbox	Inactive
USR5	5.3.7.40	Checkbox	Inactive
USR6	5.3.7.41	Checkbox	Inactive
USR7	5.3.7.42	Checkbox	Inactive
USR8	5.3.7.43	Checkbox	Inactive
Outgoing transm. grp.	5.3.7.44	Combobox	NAVD

Table 5-5 Parameters within PilotStar® NX Settings / Controller

PilotStar® NX Settings / Controller			
Parameter	Description	Type	Default
Rudder Gain [%]	5.3.7.45	Number Field	100
max. Rudder Angle	5.3.7.46	Number Field	35
Heading Monitor	5.3.7.47	Checkbox	Active
Heading Grad. Control	5.3.7.48	Checkbox	Active
HDG Grad. [deg/s]	5.3.7.49	Number Field	12
Set Rudder limited	5.3.7.50	Checkbox	Active
High Speed Craft	5.3.7.51	Checkbox	Active
SW-Key	5.3.7.52	Text Field	xxxx-xxxx-xxxxx-xxxx
Low Speed	5.3.7.53	Number Field	3
Eff. Ship Length	5.3.7.54	Number Field	100
Back up Nav. Alarm	5.3.7.55	Checkbox	Active
Developer Key	5.3.7.56	Text Field	



The parameter within **Steering Components** should only be configured by Raytheon Anschutz service personnel.

Table 5-6 Parameters within Steering Components / PSIF

Steering Components / PSIF	
Parameter	Description
Analog In Wire Break	See manual of configuration tool
Analog Out Loop (X39)	See manual of configuration tool
Analog Out Loop (X44)	See manual of configuration tool
Analog Out:	See manual of configuration tool
Analog In	See manual of configuration tool
Pulse Log Input	See manual of configuration tool
PLOG [pulses/NM]	See manual of configuration tool
ACO Probe Input	See manual of configuration tool
ACO Probe freq. [Hz]	See manual of configuration tool
Max. Rudder [deg]	See manual of configuration tool
Assignment	See manual of configuration tool
Trans/Diff	See manual of configuration tool
Linear/SinCos	See manual of configuration tool
Rudder stop enabled	See manual of configuration tool
Rudder Pulse enabled	See manual of configuration tool
Pulse length [ms]	See manual of configuration tool
SteeringFail enabled	See manual of configuration tool
Threshold [deg]	See manual of configuration tool
Delay Time [s]	See manual of configuration tool
Deadband P1 [deg]	See manual of configuration tool

Steering Components / PSIF	
Parameter	Description
Deadband P2 [deg]	See manual of configuration tool
Deadband P1+P2 [deg]	See manual of configuration tool
Analog Gain RudOut 1	See manual of configuration tool
Analog Gain RudOut 2	See manual of configuration tool
D-Return P1	See manual of configuration tool
D-Return P2	See manual of configuration tool
D-Return P1+P2	See manual of configuration tool
SoleNoid Hyster. [%]	See manual of configuration tool
Feedback Input	See manual of configuration tool
Gyro Input (X25)	See manual of configuration tool
Magnetic Input (X30)	See manual of configuration tool
Speed Input (X35)	See manual of configuration tool
GPS Input (X40)	See manual of configuration tool
Override Trigger	See manual of configuration tool
Type Number	See manual of configuration tool
Serial Number	See manual of configuration tool
Software Version	See manual of configuration tool
Description	See manual of configuration tool
History/Remarks	See manual of configuration tool



The parameter within **Steering Components** should only be configured by Raytheon Anschütz service personnel.

Table 5-7 Parameters within Steering Components / Tiller Hand Wheel

Steering Components / Tiller Hand Wheel	
Parameter	Description
Take Over Enable	See manual of configuration tool
Give Over Enable	See manual of configuration tool
Rudder Freeze	See manual of configuration tool
WatchAlarmReset	See manual of configuration tool
Contact Free Sensor	See manual of configuration tool
Port - Stbd	See manual of configuration tool
Auto brightness	See manual of configuration tool
Ext. Dim.	See manual of configuration tool
Dimming Cycle	See manual of configuration tool
Offset	See manual of configuration tool
Slope	See manual of configuration tool
Grad. Alarm enabled	See manual of configuration tool
Grad. thrshld [deg/s]	See manual of configuration tool
Max. Rudder [deg]	See manual of configuration tool
Transferrate [ms]	See manual of configuration tool
Steering Position:	See manual of configuration tool
Steering Group	See manual of configuration tool
Rudder Assignment	See manual of configuration tool
Operator Unit	See manual of configuration tool
Auto On	See manual of configuration tool
Input Port Unit Id	See manual of configuration tool

Steering Components / Tiller Hand Wheel	
Parameter	Description
Input Port StartBit	See manual of configuration tool
Type Number	See manual of configuration tool
Serial Number	See manual of configuration tool
Software Version	See manual of configuration tool
Description	See manual of configuration tool
History/Remarks	See manual of configuration tool



The parameter within **Steering Components** should only be configured by Raytheon Anschütz service personnel.

Table 5-8 Parameters within Steering Components / CAN Distribution Unit

Steering Components / CAN Distribution Unit	
Parameter	Description
Hardwired CAN Active	See manual of configuration tool
Single CAN X2 Active	See manual of configuration tool
Single CAN X3 Active	See manual of configuration tool
Single CAN X4 Active	See manual of configuration tool
Single CAN X5 Active	See manual of configuration tool
Operating Time [h]	See manual of configuration tool
Restart Counter Text	See manual of configuration tool
Output Dual CAN	See manual of configuration tool
Output Single CAN	See manual of configuration tool
Delete All	See manual of configuration tool
Set All	See manual of configuration tool
Type Number	See manual of configuration tool
Serial Number	See manual of configuration tool
Software Version	See manual of configuration tool
Description Text	See manual of configuration tool
History/Remarks Text	See manual of configuration tool

Table 5-9 Parameters within Local Settings

Local Settings			
Parameter	Description	Type	Default
Server-IP Address	5.3.7.57	Text Field	127.0.0.1
Input Beep Enabled	5.3.7.58	Checkbox	Active
Rear Steering Stand	5.3.7.59	Checkbox	Inactive
Steering Location	5.3.7.60	Combobox	0: Standalone
Client-IP Address	5.3.7.61	Text Field	192.168.85.1
Client-Subnet	5.3.7.62	Text Field	255.255.255.0

Table 5-10 Parameters within Setup Assistant / Master/Slave

Setup Assistant / Master/Slave			
Parameter	Description	Type	Default
Operator Unit Type	5.3.7.63	Combobox	Master

Table 5-11 Parameters within Setup Assistant / System Type

Setup Assistant / System Type			
Parameter	Description	Type	Default
Select System	5.3.7.64	Combobox	Standalone
Instance Number	5.3.7.7	Number Field	1

Table 5-12 Parameters within Setup Assistant / CAN Bus Addresses

Setup Assistant / CAN Bus Addresses			
Parameter	Description	Type	Default
CAN Group	5.3.7.16	Number Field	0
CAN Dev. Nb.	5.3.7.17	Number Field	0
CAN ID	5.3.7.18	Number Field	0

Table 5-13 Parameters within Setup Assistant / Additional Tillers

Setup Assistant / Additional Tillers			
Parameter	Description	Type	Default
Tiller Connected	5.3.7.65	Checkbox	Inactive
Update Devicelist	5.3.7.66	Checkbox	Inactive

Table 5-14 Parameters within Setup Assistant / Heading Input

Setup Assistant / Heading Input			
Parameter	Description	Type	Default
Gyro heading port	5.3.7.67	Combobox	No Change
Mag. heading port	5.3.7.68	Combobox	No Change
ACO Probe freq. . [Hz]	See manual of configuration tool		

Table 5-15 Parameters within Setup Assistant / Speed Input

Setup Assistant / Speed Input			
Parameter	Description	Type	Default
Speed input port	5.3.7.69	Combobox	No Change
PLOG [pulses/NM]	See manual of configuration tool		

Table 5-16 Parameters within Setup Assistant / BAM/BNWAS

Setup Assistant / BAM/BNWAS			
Parameter	Description	Type	Default
BAM Port	5.3.7.70	Combobox	No Change
Alert Mgr. UDP	5.3.7.20	Text Field	192.168.85.185:8100
BNWAS Port	5.3.7.71	Combobox	No Change
BNWAS Mgr. UDP	5.3.7.22	Text Field	192.168.85.185:8200

Table 5-17 Parameters within Setup Assistant / Steering Locations

Setup Assistant / Steering Locations			
Parameter	Description	Type	Default
NFU Tiller xxx	5.3.7.72	Combobox	Standalone
Ping NFU Tiller xxx	5.3.7.73	Checkbox	Inactive
FU Tiller xxx	5.3.7.74	Combobox	Standalone
Ping FU Tiller xxx	5.3.7.75	Checkbox	Inactive
Handwheel xxx	5.3.7.76	Combobox	Standalone
Ping Handwheel xxx	5.3.7.77	Checkbox	Inactive

Table 5-18 Parameters within Setup Assistant / Ship Parameters

Setup Assistant / Ship Parameters			
Parameter	Description	Type	Default
Shipname	5.3.7.1	Text Field	
Length	5.3.7.3	Number Field	100
No. of Rudder	5.3.7.4	Number Field	1
Max. Rudder Angle	5.3.7.46	Number Field	35

Table 5-19 Parameters within Setup Assistant / Rudder Feedback

Setup Assistant / Rudder Feedback			
Parameter	Description	Type	Default
Feedback Input	5.3.7.78	Combobox	Analog In1
Current Angle	5.3.7.79	Combobox	None

Table 5-20 Parameters within Setup Assistant / Rudder Control

Setup Assistant / Rudder Control			
Parameter	Description	Type	Default
Set Rudder Output	5.3.7.80	Combobox	No Change
Deadband P1 [deg]	See manual of configuration tool		
Deadband P2 [deg]	See manual of configuration tool		
Deadband P1+P2 [deg]	See manual of configuration tool		
D-Return P1	See manual of configuration tool		
D-Return P2	See manual of configuration tool		
D-Return P1+P2	See manual of configuration tool		
SoleNoid Hyster. [%]	See manual of configuration tool		
Analog Gain RudOut 1	See manual of configuration tool		
Analog Gain RudOut 2	See manual of configuration tool		
Analog Out:	See manual of configuration tool		
Analog Out Loop (X39)	See manual of configuration tool		
Analog Out Loop (X44)	See manual of configuration tool		

Table 5-21 Parameters within Setup Assistant / NAV Control

Setup Assistant / NAV Control			
Parameter	Description	Type	Default
NAV Input Port	5.3.7.81	Combobox	No Change

Table 5-22 Parameters within Setup Assistant / Summary

Setup Assistant / Summary			
Parameter	Description	Type	Default
Disable Ethernet X19	5.3.7.82	Checkbox	Inactive

5.3.6.1 Shipname

Parameter to set the ship name.

Type: Text field

For configuration of text field, 5.3.8.3.

5.3.6.2 IMO no.

Parameter to set the ship's IMO number.

Type: Text field

For configuration of text field, see chapter 5.3.8.3.

5.3.6.3 Length

Parameter to set the ship's length in meters.

Type: Number field

Range: 10 - 999

Step: 1

For configuration of number field, see chapter 5.3.8.4.

5.3.6.4 No. of Rudder

Parameter to set the number of rudders.

Type: Number field

Range: 1 - 6

Step: 1

For configuration of number field, see chapter 5.3.8.4.

5.3.6.5 Rudder Type

Parameter to set the type of rudders. Parameter is for information only and does not affect operation. Select from predefined values to set this parameter.

Predefined rudder types to set are:

- Normal
- Water jet
- Pod drive
- Flap

Type: Combobox

For configuration of combo box, see chapter 5.3.8.1.

5.3.6.6 Order Code

Use this parameter to input the Raytheon Anschütz order number.

Type: Text field

For configuration of text field, see chapter 5.3.8.3.

5.3.6.7 Instance Number

For Master operator unit only. Each master operator unit must have a unique instance number, even there is only one master operator unit.

Type: Number field

Range: 1 - 9

Step: 1

For configuration of number field, see chapter 5.3.8.4.

5.3.6.8 Day Colour

Parameter to set day colors. Select from predefined values to set this parameter. Configured values for each mode can be selected via the **Day / Night** softkey, see chapter 4.3.1.

Predefined values:

- Day1 (Bright sun colors)
- Day2 (Day colors - white)
- Day3 (Day colors - black)
- Night1 (Dusk colors)
- Night2 (Night colors - green)
- Night3 (Night colors – red)

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.9 Night Colour

Parameter to set night colours. Select from predefined values to set this parameter. Configured values for each mode can be selected via the **Day / Night** softkey, see chapter 4.3.1.

Predefined values:

- Day1 (Bright sun colors)
- Day2 (Day colors - white)
- Day3 (Day colors - black)
- Night1 (Dusk colors)
- Night2 (Night colors - green)
- Night3 (Night colors – red)

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.10 Software Archive

Combobox to select a software version. Select from predefined values to set this parameter. Up to 4 saved software version are predefined for selection. The selected action within parameter **Software Action** (see chapter 5.3.7.11) happens to the selected software version. A maximum of four software versions can be stored. The software currently used is not displayed in the software archive.

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.11 Software Action

Parameter to set an action for the software version which is selected in **Software Archive** (5.3.7.10).

Select from predefined values to set this parameter.

Select from predefined values:

- None (default)
- Install
- Remove

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.12 Service Menu enabled

With this checkbox it is possible to configure the PilotStar® NX in any control mode. It is not necessary to switch into inactive mode to start service menu. This function can be used for configuration under control conditions (test the configurations during operation). Use the checkbox to enable **Developer Key**, see chapter 5.3.7.56. If configuration is finished, parameter should set back to disabled.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.13 Serial 1

Parameter to select the data format/content of the serial input RS422 (at plug X505). Select from predefined values to set this parameter.

Select from predefined values:

- not used (which means this input is not connected)
- nmea 4800bd (one of following: heading, speed, NAV control data, low baud rate)
- nmea 38400bd (one of following: heading, speed, NAV control data, high baud rate)
- ecdis 4800bd (do not use)
- ecdis 38400bd (do not use)
- coursebus (Raytheon Anschütz format - contains all headings and speed over ground)
- bam 4800bd (connection to BAM, low baud rate)
- bam38400bd (connection to BAM, high baud rate)

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.14 Serial 2

Parameter to select the data format/content of the serial input RS422 (at plug X506). Select from predefined values to set this parameter.

Select from predefined values:

- not used (which means this input is not connected)
- nmea 4800bd (one of following: heading, speed, NAV control data, low baud rate)
- nmea 38400bd (one of following: heading, speed, NAV control data, high baud rate)
- ecdis 4800bd (do not use)
- ecdis 38400bd (do not use)
- coursebus (Raytheon Anschütz format - contains all headings and speed over ground)

- bam 4800bd (connection to BAM, low baud rate)
- bam38400bd (connection to BAM, high baud rate)

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.15 Serial 3

Parameter to select the data format/content of the serial input RS422 (at plug X507).
Select from predefined values to set this parameter.

Select from predefined values:

- not used (which means this input is not connected)
- nmea 4800bd (one of following: heading, speed, NAV control data, low baud rate)
- nmea 38400bd (one of following: heading, speed, NAV control data, high baud rate)
- ecdis 4800bd (do not use)
- ecdis 38400bd (do not use)
- coursebus (Raytheon Anschütz format - contains all headings and speed over ground)
- bam 4800bd (connection to BAM, low baud rate)
- bam38400bd (connection to BAM, high baud rate)

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.16 Can Group

Parameter to expand the CAN ID. CAN groups can be

- Compass and data distribution
- Steering components
- Navigation data sensors

The recommended group numbers for steering systems are 6, 7, 8 and 9.

The combination of the CAN Group and CAN Device Number must be unique within each steering system.

Type: Number field

Range: 0 - 9

Step: 1

For configuration of number field, see chapter 5.3.8.4

5.3.6.17 Can- Dev. Nb.

Parameter to set the CAN Device Number according to the connection diagram. Adjust the value to set this parameter. The combination of the CAN Group and CAN Device Number must be unique within the steering system.

Type: Number field

Range: 0 - 63

Step: 1

For configuration of number field, see chapter 5.3.8.4

5.3.6.18 CAN ID

Parameter to set the CAN Identification Number. This number identifies a CAN device within a CAN Group. The CAN ID must be unique within each steering system.

Type: Number field

Range: 0 - 255

Step: 1

For configuration of number field, see chapter 5.3.8.4

5.3.6.19 CAN Nav.Data enabled

Parameter to enable use of navigational data received via the CAN Bus. Use the checkbox to set this parameter. A set checkbox means that navigational data is taken from the CAN bus.

Type: Checkbox

For configuration of checkbox field, see chapter 5.3.8.2

5.3.6.20 Alert Mgr. UDP

Parameter to connect to the Alarm Manager port. This port is essential for an integrated Ethernet application.

Recommended is to set 192.168.85.185:8100 for this parameter.

The following IP address ranges are allowed:

10.0.0.0 - 10.255.255.255

172.16.0.0 - 172.31.255.255

192.168.0.0 - 192.168.255.255

For configuration of this parameter, see chapter 5.3.12

Type: Text field

For configuration of text field, see chapter 5.3.8.3

5.3.6.21 **Alert Mgr. Type**

Parameter to set the Alert Manager Telegram type. The selected type will be sent to the connected Alert Management System. The port must be entered at parameter **Alert Mgr. UDP**, see chapter 5.3.7.20.

Select from predefined values:

- INS (for ACN, ALC, ALF and ARC telegrams communication. IEC 61924-2)
- ALR/ACK (older alert communication)
- BAM (IEC 62923-1)

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.22 **BNWAS Mgr. UDP**

Parameter to connect to the BNWAS port. This port is essential for an integrated Ethernet application. Recommended is to set 192.168.85.185:8200 for this parameter. The following IP address ranges are allowed:

10.0.0.0 - 10.255.255.255

172.16.0.0 - 172.31.255.255

192.168.0.0 - 192.168.255.255

For configuration of this parameter, see chapter 5.3.13

Type: Text field

For configuration of text field, see chapter 5.3.8.3

5.3.6.23 **PSIFs**

Parameter is used to define the number of PSIFs within the application. Adjust the value to set this parameter.

Type: Number field

Range: 1 - 9

Step: 1

For configuration of number field, see chapter 5.3.8.4

5.3.6.24 **CAN Central Dimming**

Parameter is used to activate the function **CAN Central Dimming**. By activation of this parameter all connected components/devices of the respective dimming group (currently Dimming Group 1) can be adjusted (brightness) via the CAN bus.

Type: Checkbox
For configuration of checkbox, see chapter 5.3.8.2

5.3.6.25 **DDC Central Dimming**

Parameter to enable **DDC Central Dimming**. Within this function the device processes DDC telegram and adjusts the brightness according to given brightness values. The brightness of the device can be requested by “request” after DDC.

Type: Checkbox
For configuration of checkbox, see chapter 5.3.8.2

5.3.6.26 **INS**

This parameter is used to deactivate heading monitoring, position monitoring and the sensor selection (for heading and speed) because these functions are performed via INS.

This parameter can be set/reset during the installation from the service personnel.

Type: Checkbox
For configuration of checkbox, see chapter 5.3.8.2

5.3.6.27 **Turn headings 180deg**

This parameter is used to cover all incoming headings values with an offset of 180°. Activate checkbox to enable this parameter.

Type: Checkbox
For configuration of checkbox, see chapter 5.3.8.2

5.3.6.28 **MISC**

This parameter is used to receive data according to IEC61162-450 Ed.1 from transmission group MISC. Activate checkbox and restart device to enable this parameter.

Type: Checkbox
For configuration of checkbox, see chapter 5.3.8.2

5.3.6.29 **TGTD**

This parameter is used to receive data according to IEC61162-450 Ed.1 from transmission group TGTD. Activate checkbox and restart device to enable this parameter.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.30 SATD

This parameter is used to receive data according to IEC61162-450 Ed.1 from transmission group SATD. Activate checkbox and restart device to enable this parameter.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.31 NAVD

This parameter is used to receive data according to IEC61162-450 Ed.1 from transmission group NAVD. Activate checkbox and restart device to enable this parameter.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.32 TIME

This parameter is used to receive data according to IEC61162-450 Ed.1 from transmission group TIME. Activate checkbox and restart device to enable this parameter.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.33 PROP

This parameter is used to receive data according to IEC61162-450 Ed.1 from transmission group PROP. Activate checkbox and restart device to enable this parameter.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.34 USR1

This parameter is used to receive data according to IEC61162-450 Ed.1 from transmission group USR1. Activate checkbox and restart device to enable this parameter.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.35 USR2

This parameter is used to receive data according to IEC61162-450 Ed.1 from transmission group USR2. Activate checkbox and restart device to enable this parameter.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.36 USR3

This parameter is used to receive data according to IEC61162-450 Ed.1 from transmission group USR3. Activate checkbox and restart device to enable this parameter.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.37 USR4

This parameter is used to receive data according to IEC61162-450 Ed.1 from transmission group USR4. Activate checkbox and restart device to enable this parameter.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.38 USR5

This parameter is used to receive data according to IEC61162-450 Ed.1 from transmission group USR5. Activate checkbox and restart device to enable this parameter.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.39 USR6

This parameter is used to receive data according to IEC61162-450 Ed.1 from transmission group USR6. Activate checkbox and restart device to enable this parameter.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.40 USR7

This parameter is used to receive data according to IEC61162-450 Ed.1 from transmission group USR7. Activate checkbox and restart device to enable this parameter.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.41 USR8

This parameter is used to receive data according to IEC61162-450 Ed.1 from transmission group USR8. Activate checkbox and restart device to enable this parameter.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.42 Outgoing transm. grp.

This parameter enables to send data according to IEC61162-450 Ed.1 to selected group. This parameter must be identical to the group, which was selected for reception, see chapter 5.3.7.28 to 5.3.7.43.

Further information for data transfer according to IEC61162-450 Ed.1:

- Maximum number of datagrams per second received, intended for and processed by the equipment: 160
- Maximum number of datagrams per second received but not intended for the equipment: 40

- Maximum number of datagrams per second received by, but not intended for, the equipment at 50 % of the maximum load for item a): 120

ONF (Other Node Function): Client server communication data rate per connected slave operator unit about 650bytes net (40 frames) TCP/IPv4 Port 8000 during normal operation. During service mode higher bursts.

Client update only during service. TCP/IPv4 Port 8005 burst with size of software package typical 5Mbyte per client once.

Note: IP addresses from multicast IP range (see annex 450 Support) are not allowed.

Select from predefined values:

- DISABLED
- MISC
- TGTD
- SATD
- NAVD
- TIME
- PROP
- USR1
- USR2
- USR3
- USR4
- USR5
- USR6
- USR7
- USR8

Type: Combobox. Restart device for changes to take effect.

For configuration of combobox, see chapter 5.3.8.1

5.3.6.43 Rudder Gain [%]

Adjust this parameter to fit the rudder angle to that rudder value which is needed. If it is necessary to adjust a greater or smaller rudder value as it is configurable than the rudder gain value can be increased or decreased. The parameter is indicated in percent.

Example 1:

Rudder = 7 and Rudder Gain = 100%

is the same as

Rudder = 5 and Rudder gain = 170%

Example 2:

Rudder = 3 and Rudder Gain = 100%

is the same as
Rudder = 5 and Rudder Gain = 85%

Type: Number field
Range: 10 - 200
Step: 1
For configuration of number field, see chapter 5.3.8.4

5.3.6.44 Max. Rudder Angle

Use this parameter to set the rudder's maximum angle in degrees. This is the maximum desired rudder angle output from the autopilot.

The mechanical maximum rudder angle is defined by the limit switches in a rudder feedback unit. The maximum possible rudder angle to be ordered by the autopilot is to be less than this value. The parameter is indicated in degree.

Type: Number field
Range: 5 - 99
Step: 1
For configuration of number field, see chapter 5.3.8.4

5.3.6.45 Heading Monitor

The heading monitor function is needed for an approved Heading Control System according to ISO 11674.

This function can be switched off manually during the configuration procedure (controller parameter). This may be necessary if this monitoring is performed via other monitoring functions/devices. Only one heading monitor function must be active at the Heading Control System. Use this parameter to activate the comparison between selected gyro and magnetic compass. An alert is generated if difference between the heading sensors changes more than the configured limit during heading keeping or if one of the sensors transmits invalid or no data.

Use the checkbox to activate this function.

Type: Checkbox
For configuration of checkbox, see chapter 5.3.8.2

5.3.6.46 Heading Grad. Control

Heading Gradient Control function observes the incoming heading values and detects heading jumps between following values or while sensor switching. Enables/disables heading jump (gradient) monitor and heading jump detection and compensation of selected heading sensor.

Type: Checkbox
For configuration of checkbox, see chapter 5.3.8.2

5.3.6.47 HDG Grad. [deg/s]

This parameter value is used to define the threshold of a heading jump. Heading jumps lower than this threshold will remain without effect. Heading jumps greater than this threshold will lead to an action by the autopilot. In heading control mode, the actual heading is adjusted by the jump value as a new set heading. Within waypoint steering mode the set course over ground will remain without changes. Course trim is adjusted. Adjustments will not result in unintended rudder moves.

Type: Number field
Range: 8 - 20
Step: 1
For configuration of number field, see chapter 5.3.8.4

5.3.6.48 Set Rudder limited

If checkbox is selected, an alert is generated if the rudder command from the autopilot exceeds the configured rudder limit value.
If this checkbox is not selected, an alert is generated if actual rudder exceeds the configured rudder limit.

Type: Checkbox
For configuration of checkbox, see chapter 5.3.8.2

5.3.6.49 High Speed Craft

Use this checkbox to set the control parameter for high speed craft. High speed is defined as a speed greater than 30 knots. Use the checkbox to set this parameter. A set checkbox means that the control type (regulation behaviour) is matched to high speed craft.

Type: Checkbox
For configuration of checkbox, see chapter 5.3.8.2

5.3.6.50 SW-Key

Use this field to enter the 19-digit key of the current software version of the operator unit.

Type: Text field

For configuration of text field, see chapter 5.3.8.3

5.3.6.51 Low Speed

Use this parameter to set the alert activation limit.

Type: Number field

Range: 0 - 10

Step: 1

For configuration of number field, see chapter 5.3.8.4

5.3.6.52 Eff. Ship Length

Use this parameter to adjust the influence of the ship length on the control loop. This parameter should be set to the actual ship's length. It is useable to influence the suitable value for the counter rudder. Some more length results in more counter rudder and less length results in less counter rudder.

Type: Number field

Range: 10 - 999

Step: 1

For configuration of number field, see chapter 5.3.8.4

5.3.6.53 Back up Nav. Alarm


Use this parameter to set the Backup Navigator Alarm. This setting is for waypoint steering only.

A Backup Navigator Alarm is activated if a basic alarm is not acknowledged within a specified time period.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.54 Developer Key

	This parameter is for development only.
---	---

This key is necessary to enable parameter **Service Menu enabled**, see chapter 5.3.7.12.

This code can be input with the displayed keyboard after touching the input field.

Type: Text field

For configuration of text field, see chapter 5.3.8.3

5.3.6.55 Server-IP address

Use this parameter to set the internal server address of the autopilot for data transmission between the operator unit and the autopilot controller.

Example for network configuration If there is more than one operator unit within a Master – Slave configuration:

Designation	Master Main Bridge	Slave Port	Slave Starboard
Server-IP address	127.0.0.1	192.168.85.199	192.168.85.199
Client-IP address	192.168.85.199	192.168.85.198	192.168.85.197
Client-Subnet	255.255.255.0	255.255.255.0	255.255.255.0

The following IP address ranges are allowed:

10.0.0.0 - 10.255.255.255

172.16.0.0 - 172.31.255.255

192.168.0.0 - 192.168.255.255

Type: Text field

For configuration of text field, see chapter 5.3.8.3

5.3.6.56 Input Beep enabled

This checkbox enables an acoustical signal after valid data input.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.57 Rear Steering Stand

Activate this checkbox in case of rear standing stand. Operator display page **NFU/FU Main** is converted for rear standing stand.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.58 Steering Location

This parameter adjusts steering location at which the operator unit is built in.

Select from predefined values:

- 0: Standalone
- 1: Bridge
- 2: Wing (Port)
- 3: Wing (Stbd)
- 4: Aft
- 5: Location 5
- 6: Location 6
- 7: Location 7
- 8: Location 8

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.59 Client-IP address

Use this parameter to set the address of the NautoPilot Operator Unit for data transmission.

Example for network configuration If there is more than one operator unit within a Master – Slave configuration:

Designation	Master Main Bridge	Slave Port	Slave Starboard
Server-IP address	127.0.0.1	192.168.85.199	192.168.85.199
Client-IP address	192.168.85.199	192.168.85.198	192.168.85.197
Client-Subnet	255.255.255.0	255.255.255.0	255.255.255.0

The following IP address ranges are allowed:

10.0.0.0 - 10.255.255.255

172.16.0.0 - 172.31.255.255

192.168.0.0 - 192.168.255.255

Type: Text field

For configuration of text field, see chapter 5.3.8.3

5.3.6.60 Client-Subnet

Use this parameter to set a subnet mask for data filter.

Example for network configuration If there is more than one operator unit within a Master – Slave configuration:

Designation	Master Main Bridge	Slave Port	Slave Starboard
Server-IP address	127.0.0.1	192.168.85.199	192.168.85.199
Client-IP address	192.168.85.199	192.168.85.198	192.168.85.197
Client-Subnet	255.255.255.0	255.255.255.0	255.255.255.0

Type: Text field

For configuration of text field, see chapter 5.3.8.3

5.3.6.61 Operator Unit Type

Use this parameter to set type of operator unit, see chapter 1.5.

Predefined values:

- Master
- Slave

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.62 Select System

Use this parameter to set type of system, see chapter 1.3.

Predefined values:

- NautoSteer AS

- Standalone

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.63 Tiller Connected

Activate this checkbox in case of connected tiller. Checkbox will be activated automatically, if tiller will be detected. If checkbox is activated, list of devices appears.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.64 Update Devicelist

Activate this checkbox to update list of devices, which appears in case of connected tiller, see chapter 5.3.7.65.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.65 Gyro Heading Port

Use this parameter to set the standard interface of the gyro compass. If other interfaces than the predefined should be used, this must be set within the respective configuration tool or configuration menu, in this case **other** should be selected from predefined values.

If this selection within the setup assistant is done once before, the current setting appears in the information field above. **PSIF B25** is always activated and cannot be deactivated.

Ethernet SATD X19 cannot be deactivated within this selection. To deactivate **Ethernet SATD X19** use the parameter **Disable Ethernet X19**, see chapter 5.3.7.82.

Select from predefined values:

- no change (no change to the current setting shown in the above information field)
- Coursebus X505 (operator unit port X505 will be configured as coursebus interface)
- NMEA 4800bd X505 (operator unit port X505 will be configured as NMEA 4800 Baud / IEC 61162-1 interface)
- NMEA 38400bd X505 (operator unit port X505 will be configured as NMEA 3800 Baud / IEC 61162-1 interface)
- Ethernet SATD X19 (receive group SATD according to IEC 61162-450 will be activated at operator unit port X19)

- other (possible ports at operator unit and at PilotStar® NX interface unit will be reset and no further ports will be opened)
- PSIF B25 (port scan at PilotStar® NX interface unit port B25 unit will be activated)

Predefined values might change depending on system configuration.

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.66 Mag. Heading Port

Use this parameter to set the standard interface of the magnetic heading. If other interfaces than the predefined should be used, this must be set within the respective configuration tool or configuration menu, in this case **other** should be selected from predefined values.

If this selection within the setup assistant is done once before, the current setting appears in the information field above. **PSIF B29** is always activated and cannot be deactivated.

Ethernet SATD X19 cannot be deactivated within this selection. To deactivate **Ethernet SATD X19** use the parameter **Disable Ethernet X19**, see chapter 5.3.7.82.

Select from predefined values:

- no change (no change to the current setting shown in the above information field)
- Coursebus X505 (operator unit port X505 will be configured as coursebus interface)
- NMEA 4800bd X505 (operator unit port X505 will be configured as NMEA 4800 Baud / IEC 61162-1 interface)
- NMEA 38400bd X505 (operator unit port X505 will be configured as NMEA 3800 Baud / IEC 61162-1 interface)
- Ethernet SATD X19 (receive group SATD according to IEC 61162-450 will be activated at operator unit port X19)
- other (possible ports at operator unit and at PilotStar® NX interface unit will be reset and no further ports will be opened)
- same as gyro (heading from magnetic compass will be received at the same interface as heading from gyro compass)
- disable (no magnetic heading available, heading monitoring will be deactivated)
- PSIF B29 (port scan at PilotStar® NX interface unit port B29 unit will be activated)
- PSIF ACO Probe B32 (Anschütz magnetic sonde will be connected at PilotStar® NX Interface unit port B32)

Predefined values might change depending on system configuration.

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.67 Speed Input Port

Use this parameter to set the standard interface of speed through water. If other interfaces than the predefined should be used, this must be set within the respective configuration tool or configuration menu, in this case **other** should be selected from predefined values.

If this selection within the setup assistant is done once before, the current setting appears in the information field above. **PSIF B35** is always activated and cannot be deactivated.

Ethernet NAVD X19 cannot be deactivated within this selection. To deactivate **Ethernet NAVD X19** use the parameter **Disable Ethernet X19**, see chapter 5.3.7.82.

Select from predefined values:

- no change (no change to the current setting shown in the above information field)
- Coursebus X505 (operator unit port X505 will be configured as coursebus interface)
- NMEA 4800bd X505 (operator unit port X505 will be configured as NMEA 4800 Baud / IEC 61162-1 interface)
- NMEA 38400bd X505 (operator unit port X505 will be configured as NMEA 3800 Baud / IEC 61162-1 interface)
- Ethernet NAVD X19 (receive group NAVD according to IEC 61162-450 will be activated at operator unit port X19)
- other (possible ports at operator unit and at PilotStar® NX interface unit will be reset and no further ports will be opened)
- PSIF B35 (port scan at PilotStar® NX interface unit port B35 unit will be activated)

Predefined values might change depending on system configuration.

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.68 BAM Port

Use this parameter to set the standard interface for communication via BAM system.

If this selection within the setup assistant is done once before, the current setting appears in the information field above.

Ethernet NAVD X19 cannot be deactivated within this selection. To deactivate **Ethernet NAVD X19** use the parameter **Disable Ethernet X19**, see chapter 5.3.7.82.

Select from predefined values:

- no change (no change to the current setting shown in the above information field)
- BAM-4800bd X507 (operator unit port X507 will be configured as NMEA 4800 Baud / IEC 61162-1 interface)
- BAM-4800bd X507 (operator unit port X507 will be configured as NMEA 3800 Baud / IEC 61162-1 interface)
- Ethernet NAVD X19 (receive group NAVD according to IEC 61162-450 will be activated at operator unit port X19)
- Alert Mgr. UDP (in case of MOXA switch, see chapter 3.3, default setting for communication will be set, if not already done)
- disable (possible ports at operator unit will be reset and no further ports will be opened)

Predefined values might change depending on system configuration.

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.69 **BNWAS Port**

Use this parameter to set the standard interface for BNWAS.

If this selection within the setup assistant is done once before, the current setting appears in the information field above.

Ethernet NAVD X19 cannot be deactivated within this selection. To deactivate **Ethernet NAVD X19** use the parameter **Disable Ethernet X19**, see chapter 5.3.7.82.

Select from predefined values:

- no change (no change to the current setting shown in the above information field)
- PSNX X511 – PSIF B36 (output Backup Navigator Alarm at operator unit X511 and Watch Alarm Reset at PilotStar® NX interface unit B35)
- Ethernet NAVD X19 (receive group NAVD according to IEC 61162-450 will be activated at operator unit port X19)
- BNWAS Mgr. UDP (in case of MOXA switch, see chapter 3.3, default setting for communication will be set, if not already done)
- disable (possible ports at operator unit will be reset and no further ports will be opened)

Predefined values might change depending on system configuration.

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.70 NFU Tiller xxx

This parameter adjusts steering location at which the NFU tiller is built in.
(xxx represents the CAN ID of the device.)

Select from predefined values:

- 0: Standalone
- 1: Bridge
- 2: Wing (Port)
- 3: Wing (Stbd)
- 4: Aft
- 5: Location 5
- 6: Location 6
- 7: Location 7
- 8: Location 8

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.71 PING Tiller xxx

If this checkbox is selected, a blue LED will be activated for 10 s at the respective device to identify the device.
(xxx represents the CAN ID of the device.)

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.72 FU Tiller xxx

This parameter adjusts steering location at which the FU tiller is built in.
(xxx is represents the CAN ID of the device.)

Select from predefined values:

- 0: Standalone
- 1: Bridge
- 2: Wing (Port)
- 3: Wing (Stbd)
- 4: Aft
- 5: Location 5
- 6: Location 6

- 7: Location 7
- 8: Location 8

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.73 PING FU Tiller xxx

If this checkbox is selected, a blue LED will be activated for 10 s at the respective device to identify the device.

(xxx represents the CAN ID of the device.)

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.74 Handwheel xxx

This parameter adjusts steering location at which the FU tiller is built in.

(xxx is represents the CAN ID of the device.)

Select from predefined values:

- 0: Standalone
- 1: Bridge
- 2: Wing (Port)
- 3: Wing (Stbd)
- 4: Aft
- 5: Location 5
- 6: Location 6
- 7: Location 7
- 8: Location 8

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.75 PING Handwheel xxx

If this checkbox is selected, a blue LED will be activated for 10 s at the respective device to identify the device.

(xxx represents the CAN ID of the device.)

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2

5.3.6.76 Feedback Input

This parameter adjusts feedback input.

Select from predefined values:

- Digital In (CAN0) (for development only, do not use)
- Analog In1 (rudder is connected at analog input 1)
- Analog In2 (rudder is connected at analog input 1)
- Analog In1+In3 R1+R2 (starboard rudder is connected at analog input 1, port side rudder is connected at analog input 3)
- Analog In1+In3 R1+R1 (two feedback signals of one rudder are connected redundant at analog input 1 and analog input 3)

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.77 Current Angle

This parameter adjusts rudder correction value.

Select from predefined values:

- reset (all correction values will be deleted)
- port max deg (correction value for maximum port side rudder will be used)
- port 30 deg (correction value for 30 deg port side rudder will be used)
- port 20 deg (correction value for 20 deg port side rudder will be used)
- port 10 deg (correction value for 10 deg port side rudder will be used)
- 0 deg (correction value for rudder midship will be used)
- starboard 10 deg (correction value for 10 deg starboard rudder will be used)
- starboard 20 deg (correction value for 20 deg starboard rudder will be used)
- starboard 30 deg (correction value for 20 deg starboard rudder will be used)
- starboard max deg (correction value for maximum starboard rudder will be used)

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.78 Set Rudder Output

This parameter adjusts rudder output.

If this selection within the setup assistant is done once before, the current setting appears in the information field above.

Select from predefined values:

- no change (no change to the current setting)
- Solenoids (use values for Solenoid valves)
- Analog (use values for analog connection)

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.79 NAV Input Port

Use this parameter to set the standard interface for waypoint steering (NMEA APB-telegram).

If this selection within the setup assistant is done once before, the current setting appears in the information field above.

Ethernet NAVD X19 cannot be deactivated within this selection. To deactivate **Ethernet NAVD X19** use the parameter **Disable Ethernet X19**, see chapter 5.3.7.82.

Select from predefined values:

- no change (no change to the current setting shown in the above information field)
- NMEA 4800bd X506 (operator unit port X506 will be configured as NMEA 4800 Baud / IEC 61162-1 interface)
- NMEA 38400bd X506 (operator unit port X506 will be configured as NMEA 3800 Baud / IEC 61162-1 interface)
- Ethernet NAVD X19 (receive group NAVD according to IEC 61162-450 will be activated at operator unit port X19)
- disable (possible ports at operator unit will be reset and no further ports will be opened)

Type: Combobox

For configuration of combobox, see chapter 5.3.8.1

5.3.6.80 Disable Ethernet X19


If this checkbox is selected, recipient groups and sender group will be reset/deactivated.

Type: Checkbox

For configuration of checkbox, see chapter 5.3.8.2


5.3.7 Change Configurations of Parameters

5.3.7.1 Configure Combobox

	<p>Within a combobox one of several predefined values can be selected. For predefined values for the configurable parameters, see chapter 5.3.7.</p>
---	--

- Precondition
- Service menu is running.
 - Service display page is active which includes configurable parameter of the type combobox.

1. Use touchscreen to select desired combobox.
 - +/- softkeys appears.
 - Selected combobox is highlighted and black framed.




2. Use +/- softkeys until input field shows desired value.
 - Input field gets red framed.
 - Set symbol appears next to input field.




3. Press pushbutton **Set**.
 - Red frame disappears.
 - Set symbol disappears.
 - Parameter is configured.

5.3.7.2 Configure Checkbox


	<p>Within a checkbox, a function or setting can be selected or deselected. Overview of all configurable parameters, see chapter 5.3.7</p>
---	---

- Precondition
- Service menu is running.
 - Service display page is active which includes configurable parameter of the type checkbox.

1. Use touchscreen to select desired checkbox.
 - **check** softkey appears.
 - Selected combobox is highlighted and black framed.





2. Use **check** softkey to select or deselect checkbox.
 - Checkbox gets red framed.
 - Set symbol appears next to checkbox.



3. Press pushbutton **Set**.
 - Red frame disappears.
 - Set symbol disappears.
 - Parameter is configured.

5.3.7.3 Configure Text Field


	Context of text field is changed via data input with on-screen keyboard. Overview of all configurable parameters, see chapter 5.3.7
---	--

	Data input of some text fields is limited in length and type of character. If input of these text fields is not according to limitations, signal tone appears and context of text field returns to previous value.
---	--

Precondition

- Service menu is running.
- Service display page is active which includes configurable parameter of the type text field.

1. Use touchscreen to select desired text field.
 - **edit** softkey appears.
 - Selected text field is highlighted and black framed.




2. Select **edit** softkey.
 - **On-screen keyboard** and input field appear in separate window.



3. Use **on-screen keyboard** to change text field.
 - Text field gets red framed.
 - Set symbol appears next to input field.




4. Press pushbutton **Set**.
 - Separate window closes.
 - Previous service display page reappears.



5. Press pushbutton **Set**.
 - Red frame disappears.
 - Set symbol disappears.
 - Parameter value is configured.


5.3.7.4 Configure Number Field

	<p>Within a number field, numerical value can be changed within a predefined range.</p> <p>For predefined value ranges for the configurable parameters, see chapter 5.3.7.</p>
---	--


Precondition

- Service menu is running.
- Service display page is active which includes configurable parameter of the type number field.

1. Use touchscreen to select desired number field.
 - +/- softkeys appears.
 - Selected number field is highlighted and black framed.





2. Use +/- softkeys until input field shows desired value.
 - Input field gets red framed.
 - Set symbol appears next to input field.




3. Press pushbutton **Set**.
 - Red frame disappears.
 - Set symbol disappears.
 - Parameter is configured.

5.3.8 Update of Software

	Use only from Raytheon Anschutz admitted USB sticks.
---	--

	In case of Master – Slave installation to update software, update is only possible from master operator unit. After successful installation of new software version on master unit, new software version is spread out to all slave units. After update of software on slave units, slave units shut down and restart.
---	--

	For newest software version contact Raytheon Anschutz service.
--	--

Precondition **Service Action** within service display page **PilotStar® NX Setting / System** is set to **Install**.


1. Plug in USB stick with new software version.
2. Alert **COPYING VERSION EXX.XX** appears in status header line.
3. Wait until alert **SOFTWARE SUCCESSFULLY COPIED: EXX.XX** appears in status header line.
4. Open service display page **PilotStar® NX Setting**.
5. Use softkey **NEXT** until header status line shows the text **System**.
6. Use touchscreen to scroll down to parameter **Software Archive**.
7. Use touchscreen to select **Software Archive**.
8. Use **+/-** softkeys to select desired software version.
 - Input field gets red framed.
 - Set symbol appears next to input field.




9. Press pushbutton **Set**.

- Red frame disappears.
- Set symbol disappears.
- System shuts down and restarts.
- New software version is completely installed and ready to use after restart.

5.3.9 Export of Configuration

	Use only from Raytheon Anschutz admitted USB sticks.
---	--

	All local adjustments on the operator unit are saved within the export of configuration.
---	--

- Precondition
- Service menu is running.
 - Service display page **Service Menu Main** is active.

1. Plug in empty USB stick.
2. Select **Import / Export** from **Service Menu Main**.
 - Service display page **Import / Export** opens.
3. Use touchscreen to select **Export** from service display page **Import / Export**.
4. Use **+/-** softkeys until input field shows **Export**.
 - Input field gets red framed.
 - Set symbol appears next to input field.



5. Press pushbutton **Set**.
 - Red frame disappears.
 - Set symbol disappears.
 - Configuration will be saved under an automatically generated file name, which includes the name of the ship.

5.3.10 Import of Configuration



Use only from Raytheon Anschütz admitted USB sticks.



All local adjustments on the operator unit are saved within the export of configuration.

Precondition

- Service menu is running.
- Service display page **Service Menu Main** is active.

1. Plug in USB stick with saved configurations.
2. Select **Import / Export** from **Service Menu Main**.
 - Service display page **Import / Export** opens.
3. Use touchscreen to select **Import** from service display page **Import / Export**.
4. Use **+/- softkeys** to select desired configuration.
 - Input field gets red framed.
 - Set symbol appears next to input field.




5. Press pushbutton **Set**.
 - Red frame disappears.
 - Set symbol disappears.
 - System shuts down and restarts.
 - New software version is completely installed and ready to use after restart.

5.3.11 Configure PilotStar® NX for BAM

- Precondition
- Service menu is running.
 - Service display page **Service Menu Main** is active.

1. Open service display page **PilotStar® NX Settings**.
2. Use softkey **NEXT** until header status line shows the text **Interfaces**.
3. Use touchscreen to scroll down to parameter **Alert Mgr. UDP**.
4. Use touchscreen to select **Alert Mgr. UDP**.
5. Press softkey **edit**.
 - **On-screen keyboard** and input field appear in separate window.
6. Use **on-screen keyboard** to enter **192.168.85.185:8100**
 - Input field gets red framed.
 - Set symbol appears next to input field.




7. Press pushbutton **Set**.
 - Separate window closes.
 - Service display page PilotStar® NX Settings / Interfaces reappears.
8. Press pushbutton **Set**.
 - Red frame disappears.
 - Set symbol disappears.
 - Parameter value is configured.

5.3.12 Configure PilotStar® NX for BNWAS

- Precondition
- Service menu is running.
 - Service display page **Service Menu Main** is active.

1. Open service display page **PilotStar® NX Settings**.
2. Use softkey **NEXT** until header status line shows the text **Interfaces**.
3. Use touchscreen to scroll down to parameter **BNWAS Mgr. UDP**.
4. Use touchscreen to select **BNWAS Mgr. UDP**.
5. Press softkey **edit**.
 - **On-screen keyboard** and input field appear in separate window.
6. Use **on-screen keyboard** to enter **192.168.85.185:8200**.
 - Input field gets red framed.
 - Set symbol appears next to input field.




7. Press pushbutton **Set**.
 - Separate window closes.
 - Service display page PilotStar® NX Settings / Interfaces reappears.
8. Press pushbutton **Set**.
 - Red frame disappears.
 - Set symbol disappears.
 - Parameter value is configured.

5.3.13 Configure MOXA Switch

- Precondition
- MOXA switch is installed, see chapter 3.3.
 - Service display page **Service Menu Main** is active.
 - **Alert Mgr. UDP** is configured, see chapter 5.3.7.20
 - **BNWAS Mgr. UDP** is configured, see chapter 5.3.7.22

1. Connect MOXA and laptop vial Ethernet Patch Cable.
2. Check for IP address that is printed on the back of the MOXA-switch or stated in the belonging manual.
3. Set the IP address of the used laptop as follows:
 1. Put the first three blocks to the same as the MOXA switch.
 2. For the last block choose a number with a big difference to the one of the MOXA-switch.
4. Open a web browser and go to `http://IP_address` from the back of the MOXA switch.
5. Website welcome to NPort's is displayed.



Model Name	NPort 5232
MAC Address	00:90:E8:49:25:C8
Serial No.	8648
Firmware Version	2.6 Build 11080114
System Uptime	0 days, 00h:52m:08s
LCM	

NPort's web console provide the following function groups.


Basic Settings
Server name, real time clock, time server IP address, and Web console, Telnet console Enable, Disable function.

Network Settings
IP address, netmask, default gateway, static IP or dynamic IP, DNS, SNMP, IP location report.

Serial Settings
Baud rate, start bits, data bits, stop bits, flow control, UART FIFO.

Operating Settings
Operation mode, TCP alive check, inactivity, delimiters, force transmit timeout.

6. Click on **Network Settings** and edit settings.



MOXA www.moxa.com

Network Settings

IP address	192.168.85.154
Netmask	255.255.255.0
Gateway	
IP configuration	Static
DNS server 1	
DNS server 2	

SNMP Setting


SNMP	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Community name	public
Contact	
Location	

IP Address report

Auto report to IP	
Auto report to UDP port	4002
Auto report period	10 seconds

Submit

7. Delete the old IP address. Then type in the new IP address which is selected at the PilotStar® NX for **Alert Mgr. UDP** (e.g. 192.168.85.185).
8. Finish settings with **Submit** button.
 - Submit page is displayed.
9. Click on **Back** button and continue with the next step.




Warning! The changes will take affect until Save/Restart the NPort.

You can Save/Restart NPort now or Save/Restart NPort until all other settings configured.

Back Save/Restart Home

10. Click on **Operating Settings/ Port 1** and edit settings.



MOXA www.moxa.com

Operating Settings

Port 01

Operation mode: UDP Mode

Data Packing

Packing length: 0 (0 - 1024)

Delimiter 1: d (Hex) [Enable]

Delimiter 2: a (Hex) [Enable]

Delimiter process: Do Nothing (Processed only when Packing length is 0)

Force transmit: 0 (0 - 65535 ms)

UDP Mode


	Begin	End	Port
Destination IP address 1	192.168.85.199	192.168.85.199	8100
Destination IP address 2			4001
Destination IP address 3			4001
Destination IP address 4			4001

Local Listen port: 8100

Apply the above settings to all serial ports (Local listen port will be enumerated automatically).

Submit

11. Set **Operation mode** to **UDP Mode**.
Set **Delimiter 1** to **d** and enable checkbox.
Set **Delimiter 2** to **a** and enable checkbox.
Set **Destination IP Address 1 Begin** to the Local IP-Addr. (The master autopilot IP address, e.g. 192.168.85.199).
12. a) Remain default value for Master Autopilot only.
13. b) Refer to section xx for Master-Slave-Configuration.
14. Set **Destination IP Address 1 End** to the same IP address as set as **Destination IP Address 1 Begin**.
15. Set **Local Listen Port** to port from autopilot-setting **Alert Mgr. UDP** (e.g. 8100).
16. Finish settings with **Submit** button.
 - Submit page is displayed.
17. Click on **Serial Settings / Port 1** and edit settings.
18. Click on **Operating Settings / Port 2** and edit settings.




The screenshot shows the MOXA web interface for configuring Port 02. The 'Operating Settings' section includes the following fields:

- Operation mode:** Set to 'UDP Mode' (circled in red).
- Data Packing:**
 - Packing length: 0 (0 - 1024)
 - Delimiter 1: 0 (Hex) [Enable]
 - Delimiter 2: 0 (Hex) [Enable]
 - Delimiter process: Do Nothing (Processed only when Packing length is 0)
 - Force transmit: 0 (0 - 65535 ms)
- UDP Mode:**
 - Destination IP address 1: [] [] : 4002
 - Destination IP address 2: [] [] : 4002
 - Destination IP address 3: [] [] : 4002
 - Destination IP address 4: [] [] : 4002
 - Local Listen port: 8200 (circled in red)

At the bottom, there is a checkbox for 'Apply the above settings to all serial ports (Local listen port will be enumerated automatically)' and a 'Submit' button.


19. Set **Operation mode** to **UDP Mode**.
20. Set **Local Listen Port** to port from autopilot-setting **BNWAS Mgr. UDP** (e.g. 8200).
21. Finish settings with **Submit** button.
 - Submit page is displayed.
22. Click on **Back** button and continue with the next step.



Warning! The changes will take affect until Save/Restart the NPort.
You can Save/Restart NPort now or Save/Restart NPort until all other settings configured.

Buttons: **Back** (circled in red), Save/Restart, Home

23. Click on **Serial Settings / Port 1** and edit settings.



MOXA www.moxa.com

Main Menu

- Overview
- Basic Settings
- Network Settings
- Serial Settings
 - Port 1**
 - Port 2
- Operating Settings
- Accessible IP Settings
- Auto Warning Settings
- Monitor
- Change Password
- Load Factory Default
- Save/Restart

Serial Settings

Port 01


Serial Parameters

Port alias	BAM
Baud rate	4800
Data bits	8
Stop bits	1
Parity	None
Flow control	None
FIFO	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Interface	RS-422

Apply the above settings to all serial ports

Submit


24. Set **Port alias** to preferred alias, e.g. **BAM**.
25. Set **Baud rate** to **4800** or system's specific value.
26. Set **Data bits** to **8** or system's specific value.
27. Set **Stop bits** to **1** or system's specific value.
28. Set **Parity** to **none**.
29. Set **Flow control** to **none**.
30. Set **Interface** to **RS-422** or enter system's specific value.
31. Finish settings with **Submit** button.
 - Submit page is displayed.
32. Click on **Back** button and continue with the next step.




Warning! The changes will take affect until Save/Restart the NPort.

You can Save/Restart NPort now or Save/Restart NPort until all other settings configured.

33. Click on **Serial Settings/ Port 2** and edit settings.



34. Set **Port alias** to preferred alias, e.g. **BAM**.
35. Set **Baud rate** to **4800** or system's specific value.
36. Set **Data bits** to **8** or system's specific value.
37. Set **Stop bits** to **1** or system's specific value.
38. Set **Parity** to **none**.
39. Set **Flow control** to **none**.
40. Set **Interface** to **RS-422** or enter system's specific value.
41. Finish settings with **Submit** button.
 - Submit page is displayed.



42. Click on **Save/Restart** button.
43. Set the IP address of the used laptop as follows:
 1. Repeat the first three blocks of the IP address changed in step 7.
 2. For the last block choose a number with a big difference to the one which is set in step 7.
44. Open a web browser and enter the IP address of the PilotStar® NX, which was set in step 7.

Press **F5** on the keyboard. After website **welcome to NPort's** is displayed, it is possible to check all settings.

6 Fault Finding

6.1 Faults

6.1.1 Alert Messages

Alert messages that are unacknowledged but still active are escalated. Based on priority and category, the following escalations are possible:

- The alert is repeated
- The alert is escalated as an alarm
- The alert is escalated as an alarm and transferred to BNWAS (if available)

For more information see the Alert List in chapter 9 Annex.


The PilotStar® NX poses as the backup for the CAM display as defined in IEC 62923-1. PilotStar® NX is not able to silence alerts. Silencing is only possible with CAM.


The PilotStar® NX supports the responsibility take over functionality as defined in IEC 62923-1.


The display of incoming alerts is delayed by 4 seconds in order to allow responsibility transfer before activating optical and acoustical signals.

The PilotStar® NX accepts responsibility transfer from external systems using the alert communication as defined in IEC 62923-1 for category B alerts. The responsibility of category A alerts cannot be transferred to external systems.

The PilotStar® NX itself does not request responsibility from external systems.

	<p>PSIF related alert messages are displayed with “PSIF” add-on. For explanation of PSIF related alert messages, see PSIF manual. All PSIF related alerts are from category B.</p>
---	--

	<p>Not acknowledged warnings will be repeated after a given period of time. They might be related as warning again or as an alarm (see table in the annex).</p>
---	---

	User related alert messages are displayed with “USER” add-on. User related messages are caused by wrong operation / data input.
---	--


	A list of alert messages not designated as user alert messages (for those, see Table 6-1) is displayed in the annex.
---	--

Table 6-1 User Alert Messages

Message Text	Alert Category	Possible Cause	Remedy
USER: SOFTWAREINSTAL. SKIPPED: Exx.xx	B	During software update from USB stick a software version was found, which was already available on the device.	Software version can be selected within service menu, see chapter 5.3.7.10.
USER: HEADING MONITOR IS DISABLED	B	Heading monitor cannot be changed within Limits operator display page.	Activate heading monitor function within service menu, see chapter 5.3.7.47.
USER: ERROR ADJUSTING RUDDER	B	Rudder feedback within service menu (Steering Components / PSIF) could not be configured.	<ul style="list-style-type: none"> • Try again. • Configure rudder feedback within PSIF device.
USER: UNPLAUSIBLE SET HEADING CHANGE	B	Entry of set heading could not be detected.	Enter Set Heading again.

Message Text	Alert Category	Possible Cause	Remedy
USER: NO VAILD LICENCE	B	Try to switch to local NFU/FU, but no valid license for device found.	Contact Raytheon Anschutz service.
USER: NO VAILD LICENCE	B	Try to switch to waypoint steering, but no valid license for device found.	Contact Raytheon Anschutz service.
USER: NO VAILD LICENCE	B	Try to switch to HDG Control, but no valid license for device found.	Contact Raytheon Anschutz service.
USER: LOW HEADING INTEGRITY	B	Try wo switch to waypoint steering, but the heading sensor integrity check has not been past.	Check heading sensor system.
USER: NO GYRO SELECTED	B	Attempt to start waypoint steering, but magnetic compass is selected.	<ul style="list-style-type: none"> • Check heading source. • Select gyro compass source, see chapter 4.4.8.
USER: NO SPEED	B	No speed data available	<ul style="list-style-type: none"> • Select seed source, see chapter 4.4.7. • Check function of respective sensor. • Select manual speed, if no sensor available.

Message Text	Alert Category	Possible Cause	Remedy
USER: SPEED TO SLOW	B	Attempt to start waypoint steering, but selected speed is below low speed threshold.	Increase speed of ship.
USER: AP IS NOT ACTIVE SWITCH TO HDG CTRL	B	Attempt to start waypoint steering, but autopilot is not active.	Switch to heading control.
USER: NO TRACK COURSE	B	Waypoint steering is activated, but no data from a route planning system available.	<ul style="list-style-type: none"> • Check function of respective route planning system. • Check connection of respective route planning system.
USER: NO XTE	B	Attempt to switch to waypoint steering, but there is no valid cross track error.	<ul style="list-style-type: none"> • Check function of respective route planning system. • Check connection of respective route planning system.
USER: XTE GREATER THAN 1 NM	B	Ship is located out of track limit.	<ul style="list-style-type: none"> • Adjust new track limit, see chapter 4.4.6. • Check steering system and steering parameter.
USER: HDG MUST BE WITHIN 60DEG OF RTE LEG BEARING	B	Attempt to switch to waypoint steering, but actual heading is more than 60 ° away from current waypoint.	Orient ship according to current waypoint.

Message Text	Alert Category	Possible Cause	Remedy
USER: TRACK CONTROLLER NOT AVAILABLE	B	Attempt to switch to waypoint steering, but data set no complete.	Check function of route planning system.
USER: POWER FAILURE	B	Autopilot could not be started because of a power failure.	<ul style="list-style-type: none"> • Check LED indication, see Chapter 1.8.2. • Contact Raytheon Anschütz Service.
USER: NO HEADING	B	Attempt to switch to waypoint steering, but no valid heading found.	Check heading sensor system.
USER: HEADING CONTROLLER NOT AVAILABLE	B	Attempt to switch to waypoint steering, but data set no complete. try to switch to Heading Control,	Check heading sensor system
USER: DEVICE ACTIVATION NOT POSSIBLE	B	Try to start autopilot, but external system interrupts.	Check if autopilot is selected with steering mode selector switch (is part of bridge installation).
USER: UPDATE CLIENT SOFTWARE	B	After successful installation of new software version on master unit, software version is spread out to all slave units.	No action necessary.

6.1.2 Further Faults

Table 6-2 Further Faults

Fault	Possible Cause	Remedy
Operator unit does not start	Fuse is broken.	Change fuse, see chapter 6.2.
Operator unit does not react on input .	Display, operating element or LEDs is defective; Start display test to be sure, see chapter 6.3.	Contact Raytheon Anschütz service.
One or more of the LEDs P1 - P9 do not work.	Electrical fault within operator unit	Contact Raytheon Anschütz service.
Controller performance insufficient, although parameter was configured.	Wrong frequency	Check if heading value was sent with at least 10 Hz.
System Failure	<ul style="list-style-type: none"> • Voltage supply interrupted • Necessary data not available • User interface not accessible 	<ul style="list-style-type: none"> • Check fuse and voltage supply • Check alert messages • Contact Raytheon Anschütz Service

6.2 Change Fuse

Precondition: Voltage supply is disconnected.

1. Use screw driver to open fuse holder.
2. Replace broken fuse, see spare parts catalogue.
3. Close fuse holder.

6.3 Start Display Test

Purpose: Test the function of display, LEDs and operator elements.

Precondition: Any inactive mode runs.

4. Press **Set** and **Dim** for 4 sec.
 - Display test starts.
5. Follow the instructions on the display within the shown time window.
6. Press **Set** to stop the display test at any time.
 - Display shows previous display page.

Result: Contact Raytheon Anschütz service if any tested component failed the test.

Intentionally left blank

7 Documentation of Settings

Table 7-1 Documentation of User Settings

PilotStar® NX Settings / Ship Data		
Parameter	Default	User Settings
Shipname		
IMO no.		
Length	100	
No. of Rudder	1	
Rudder Type	Normal	
Order Code		
Instance Number	1	
Day Color	Day1	
Night Color	Night1	
Software Archive		
Software Action	none	
Service Menu enabled	Inactive	
Serial 1	nmea4800bd	
Serial 2	nmea4800bd	
Serial 3	bam38400bd	
Can Group	0	
Can- Dev. Nb.	0	
CAN ID	0	
CAN Nav.Data enabled	Active	
Alert Mgr. UDP	192.168.85.185:8100	
Alert Mgr. Type	INS	
BNWAS Mgr. UDP	192.168.85.185:8200	
PSIFs	1	

PilotStar® NX Settings / Ship Data		
Parameter	Default	User Settings
CAN Central Dimming	Inactive	
DDC Central Dimming	Inactive	
INS	Inactive	
Turn headings 180deg	Inactive	
MISC	Inactive	
TGTD	Inactive	
SATD	Inactive	
NAVD	Inactive	
VDRD	Inactive	
RCOM	Inactive	
TIME	Inactive	
PROP	Inactive	
USR1	Inactive	
USR2	Inactive	
USR3	Inactive	
USR4	Inactive	
USR5	Inactive	
USR6	Inactive	
USR7	Inactive	
USR8	Inactive	
Outgoing transm. grp.	NAVD	
Rudder Gain [%]	100	
max. Rudder Angle	35	
Heading Monitor	Active	
Heading Grad. Control	Active	
HDG Grad. [deg/s]	12	

PilotStar® NX Settings / Ship Data		
Parameter	Default	User Settings
Set Rudder limited	Active	
High Speed Craft	Active	
SW-Key	xxxx-xxxx-xxxxx-xxxx	
Low Speed	3	
Eff.Ship Length	100	
Back up Nav. Alarm	Active	
Developer Key		
Server-IP address	127.0.0.1	
Input Beep enabled	Active	
Rear Steering Stand	Inactive	
Steering Location	0: Standalone	
Client-IP address	192.168.85.1	
Client-Subnet	255.255.255.0	

Intentionally left blank

8 Disposal

The PilotStar® NX Operator Unit or components of it can be disposed according to the respective national regulations for electronic waste without harmful material according to 2002/96 EC WEEE (Waste Electrical and Electronically Equipment).

Intentionally left blank

9 Annex

9.1 Telegram Definitions

PANZRSA Telegram

PANZRSA is a Raytheon Anschütz specific NMEA telegram.

```
$PANZRSA, x.x, A, x.x, A, x.x, x.x*hh<CR><LF>
```

A	B	C	D	E	F	G	H	J

Pos.	Designation	Description
A	Private identifier	PANZ = propriety Anschütz
B	Sentence name	RSA = Rudder Sensor Angle
C	Starboard or single rudder sensor	x.x
D	Status	A = valid; V = invalid
E	Port rudder sensor	x.x
F	Status	A = valid; V = invalid
G	Starboard or single rudder order	x.x
H	Port rudder order	x.x
I	ChkSum	*hh<CR><LF>

* The number of digits behind the decimal point can be variable.

PANZSTA Telegram

PANZSTA is a Raytheon Anschutz specific NMEA telegram.

\$PANZSTA,A,c,A,c,c,A,A,ccccccc,x.x*hh<CR> <LF>

A	B	C	D	E	F	G	H	I	J	K	

Pos.	Designation	Description
A	Private identifier	PANZ = propriety Anschutz
B	Sentence name	STA = Status autopilot
C	Status	A = autopilot ready, V = autopilot not ready
D	Control mode	H = manual C = heading control D = course control T = track control O = override E = external heading control (currently not used)
E	Status	A = change manoeuvre running, V = change manoeuvre not running
F	Mode	P = precision, E = economy (only adaptive mode)
G	Request	A = request for waypoint, V = successful transmission
H	Status	A = waypoint transmission permitted V = waypoints are not accepted
I	Status	A = check waypoints V = no check, check finished (only NP5500)
J	Version	Used version of Track Control Standard 62065ED1 = IEC62065:2002 62065ED2 = IEC62065:2014
K	Distance	Distance between WOP and Waypoint for TO- Waypoint in meters

* The number of digits behind the decimal point can be variable.

9.2 Alerts

9.2.1 Alert List

Note
PSIF related alert messages are displayed with PSIF add-on. For explanation of PSIF related alert messages, see <i>PilotStar® Interface Unit PSIF</i> (chapter 0.4). All PSIF related alerts are from category B.

Tab. 11: Alerts HDG Control

Alert Title Alert Description	Category Priority	Escalation	Possible Cause	Remedy
HCS STOPPED POWER FAILURE: CHECK POWER SUPPLY	Alarm B	none	Power supply of the operator unit is outside of tolerable limits.	Use manual steering. Check supply voltage. Reset operator unit. Replace Operator unit.
SIM SENSOR DATA SIMULATED SENSOR DATA IN USE: CHECK SENSORS	Alarm B	none	Sensor data received which is tagged as simulated.	Check connected sensors, use manual steering.
ACT. OU FAIL CHECK AP OPERATOR UNIT	Warning B	none	Active Operator reports a failure	Use manual steering, check Operator unit
GYRO-MAG DIFF HDG DIFFERENCE DETECTED: CHECK HDG SENSORS	Warning B	as Warning	Heading monitor has detected a difference between two heading sources. The operator adjusted off heading limit was exceeded.	Check heading sensors.
HDG JUMPED CHECK ACTUAL AND SET HEADING	Warning B	as Warning	A jump in the heading data was detected.	Check set heading, check heading sensors.

Alert Title Alert Description	Category Priority	Escalation	Possible Cause	Remedy
LOW SPEED CTRL ACCURACY LIMITED: USE MAN- UAL STEERING	Warning B	as Warning	Current speed is be- low adjusted low speed limit. Control accuracy is degraded.	Increase speed, use manual steering.
MAG FAILED BACK UP HDG SENSOR FAILED: CHECK SENSOR	Warning B	as Warning	Backup magnetic heading sensor failed.	Check magnetic heading sensor.
MAG HDG SEL. MAGNETIC HEAD- ING USED FOR HEADING CON- TROL	Warning B	as Warning	Magnetic heading sensor selected for heading control.	
NO VALID SPD SWITCH TO VALID SPEED SOURCE	Warning B	as Warning	No valid speed avail- able.	
OFF HEADING DEVIATED FROM SET HEADING: TAKE HELM	Warning A	as Alarm to BN- WAS	Offset between ac- tual and set heading exceeds operator ad- justed off heading lim- it.	Check surroundings, use manual steering, check rudder limit, check steering sys- tem
POS VALID POS AVAILABLE: SWITCH TO VALID POSITION	Warning B	as Warning	Valid position avail- able.	Select the position sensor
RUDDER LIMIT RUDDER LIMIT REACHED	Warning B	as Warning	Rudder reached the operator adjusted rudder limit.	
SET HDG REFUSED COMMANDED SET HDG GREATER 270°: PLEASE RE- PEAT INPUT	Warning B	as Warning	Operator tried to in- put a course change > 270°	Repeat input, max. adjustable set head- ing difference is 270°
SPD IS VALID VALID SPEED AVAILABLE: SWITCH SPD SOURCE	Warning B	as Warning	Valid speed available	Select the speed sen- sor.

Alert Title Alert Description	Category Priority	Escalation	Possible Cause	Remedy
SPEED JUMPED SPEED JUMP DETECTED: CHECK SPEED SENSOR	Warning B	as Warning	Speed jump detected.	Check speed sensors.
ACT. FAIL DEVICE ACTIVATION NOT POSSIBLE	Caution B	none	Heading control not activated, No rudder control was transferred to Autopilot	Check steering system.
BACKUP GYRO FAIL NO BACKUP GYRO AVAILABLE	Caution B	none	A backup gyro sensor has reported an error.	Check backup gyro sensor.
CHECK LIMITS CHECK RUDDER/ROT/RAD LIMITS	Caution B	none	NAV Control was interrupted.	The operator shall check the limits for RAD/ROT and Rudder limits. Those might have changed by the TCS.
HCS UNAVAIL. NO HEADING: CHECK HEADING	Caution B		Autopilot in standby, but no heading data available. Heading control cannot be activated.	Check Heading sensors.
HCS UNAVAIL. POWER FAILURE: CHECK POWER SUPPLY	Caution B	none	Power supply of the operator unit is outside of tolerable limits, the device is in standby mode	Check power supply.
HCS UNAVAIL. PSIF: AUTOPILOT ACTIVATION FAILED	Caution B		AP was not activated.	
HCS UNAVAIL. CANNOT ACTIVATE HCS: USE MANUAL STEERING	Caution B		Unexpected behaviour in case of giveover of rudder control by steering system. Heading control not activated.	

Alert Title Alert Description	Category Priority	Escalation	Possible Cause	Remedy
HDG CHANGE SENSOR USED FOR CONTROL FUNCTION CHANGED	Caution B	none	Automatic change of selected heading sensor.	
HDG DOUBTFUL FUNCTION NOT ACTIVATABLE	Caution B	none		
HDG MON DIS. HEADING MONI- TOR DISABLED	Caution B	none		
HDG UNCORR. CHECK HEADING CORRECTION	Caution B	none	Gyro reports uncorrected heading information.	Check Gyro
LOW SPEED CTRL ACCURACY LIMITED	Caution B	none		
MAG FAILED BACK UP HDG SENSOR FAILED: CHECK SENSOR	Caution B	none	Magnetic compass connected to AP failed.	Check magnetic compass.
NO BACKUP GYRO NO BACKUP GYRO AVAILABLE	Caution B	none	Backup gyro reports failure.	Check backup gyro
NO RUD. CTRL NO RUDDER CTRL ON CAN: USE MAN- UAL STEERING	Caution B		Take over of rudder control not successful.	Check steering system.
NO SET HDG SET HDG REJECT- ED: ENTER NEW SET HEADING	Caution B	none	Error during set heading adjustment	Repeat set heading adjustment
NOT SPD ADAP- TIVE NO SPEED: CHECK SPEED SENSOR	Caution B	none	No speed sensor data available. Autopilot will not adapt to speed changes.	Check speed sensors.

Alert Title Alert Description	Category Priority	Escalation	Possible Cause	Remedy
OU CHANGE ACTIVE OPERATOR UNIT CHANGED	Caution B	none	Another OU was activated and is now the active OU.	
POS CHANGED POSITION SENSOR CHANGED	Caution B	as Warning		
POS INVALID SWITCH TO VALID POS SOURCE	Caution B	none	Selected Position sensor sends no or invalid data.	Select valid position sensor, check position sensor
REM. OU FAIL CHECK REMOTE OPERATOR UNITS	Caution B	none	An additional OU has reported an error.	Check remote operator units.
SPD CHANGED SPEED SENSOR CHANGED	Caution B	none	Selected speed sensor was changed automatically.	

Tab. 12: Alerts NAV Control

Alert Title Alert Description	Category Priority	Escalation	Possible Cause	Remedy
NO SPEED TURN RADIUS MAY NOT MATCH	Alarm B	to BN- WAS	No speed information during Track control. May result in less accurate control, especially during turns.	Check speed sensors, adjust manual speed.
TCS STOPPED NO HEADING: USE MANUAL STEERING	Alarm B	to BN- WAS	Track control stopped due to missing heading information, HDG control is active as fallback but rudder is frozen.	Use manual steering, check heading sensors
XTE EXCEEDED OFF TRACK CROSS TRACK LIMIT EX- CEEDED: nonexm	Alarm A	none	Ship is outside of adjusted limits around the current leg.	Check surroundings, use manual steering
POS INVALID SWITCH TO VALID POSITION SOURCE	Warning B	as Warning	No valid position available.	

Alert Title Alert Description	Category Priority	Escalation	Possible Cause	Remedy
TCS STOPPED HDG INTEGRITY: CHECK HEADING SENSORS	Warning B	none	Track control stopped due to doubtful heading information. Selected HDG differs from reference sensors or only one HDG sensor is available	Check heading sensors, use HDG Control or manual steering
TCS STOPPED POWER FAILURE: CHECK POWER SUPPLY	Warning B	as Warning	OU Power failure detected while in Track control	Check power supply.
TCS STOPPED INVALID INFORMATION FROM ECDIS: CHECK ECDIS	Warning B	as Alarm to BN- WAS	ECDIS Status is missing.	Check connection to ECDIS
TCS STOPPED NO SET COURSE: CHECK SET COURSE FROM ECDIS	Warning B	as Alarm to BN- WAS	Track control interrupted, no leg course received from ECDIS.	Check ECDIS
TCS STOPPED NO POSITION: CHECK POSITION SENSOR	Warning B	as Alarm to BN- WAS	Track control stopped, no position data available.	Check position sensors.
TCS STOPPED NO XTE: CHECK CROSS TRACK ERROR FROM ECDIS	Warning B	as Alarm to BN- WAS	Track control interrupted, no cross track error received from ECDIS.	Check ECDIS
TCS STOPPED POSITION JUMP: CHECK POSITION	Warning B	as Alarm to BN- WAS	Track control interrupted, position jump detected.	Check position sensors
TCS STOPPED MAG HDG SELECTED: SELECT GYRO HEADING	Warning B	as Alarm to BN- WAS	Track control interrupted, magnetic heading source selected.	Select gyro heading source.

Alert Title Alert Description	Category Priority	Escalation	Possible Cause	Remedy
TRCK-CRS-HDG.DIFF TAKE HELM TO KEEP COURSE STEADY	Warning A	as Warning	Difference between actual heading and leg course exceeds operator adjusted off course limit.	Check surroundings, high drift or other dis- turbances present.
AP NOT ACTIVE AUTOPILOT NOT ACTIVE: ACTIVATE HDG CONTROL	Caution B	none	Heading control has to be active to acti- vate Track control	Activate Heading con- trol
APPROACH WP APPROACHING NEW WAYPOINT	Caution B	none		
GYRO NOT SEL NO TCS OR CC WITH MAG: SELECT GYRO HEADING	Caution B	none	TCS may not be used in when a magnetic heading source is se- lected	Select Gyro compass as heading source
NEW TRACK NEW TRACK 000°	Caution B	none	Track change maneu- ver is complete.	none necessary.
NO TRACK CRS CHECK CONNEC- TION TO ECDIS	Caution B	none		
NO TRC DATA CHECK CONNEC- TION TO ECDIS	Caution B	none		
NOT SPD ADAP- TIVE NO SPEED: CHECK SPEED SENSOR	Caution B	none	Activation of Track or Course control while no speed is avaiable - activation not possi- ble.	
POWER FAIL. CHECK POWER SUPPLY	Caution B	none		
TCS NOT ACTIVAT. ACTIVATE TRACK CONTROL ON ECDIS	Caution B	none	Attempted to activate Track at the Operator unit.	Track control mode can only be activated at ECDIS

Alert Title Alert Description	Category Priority	Escalation	Possible Cause	Remedy
TCS UNAVAIL. NO POSITION: CHECK POSITION	Caution B	none	No position data available, AP is not in track control. Track control cannot be activated.	Check position sensors.
XTE MISSING CHECK CONNECTION TO ECDIS	Caution B	none		
XTE TO LARGE XTE GREATER THAN 000NM	Caution B	none	Activation of track control from ECDIS, XTE is greater than 1 nautical mile	

Tab. 13: Alerts PSIF

Alert Title Alert Description	Category Priority	Escalation	Possible Cause	Remedy
OVERRIDE PSIF: EXTERNAL AUTOPILOT OVERRIDE	Alarm B	none	External override is triggered.	
RUD. STOPPED PSIF NO ACTUAL RUDDER: USE MANUAL STEERING	Alarm B	none	Missing rudder feedback information from CAN. Rudder is frozen.	Check PSIF Manual, use manual steering.
RUD. STOPPED. PSIF ANALOG FEEDBACK: USE MANUAL STEERING	Alarm B	none	Missing analog rudder feedback. Rudder is frozen.	Check PSIF Manual, use manual steering.
RUD. STOPPED PSIF CONFIG FAILED: USE MANUAL STEERING	Alarm B	none	PSIF Configuration corrupted. PSIF SYS FAIL and Rudder is frozen.	Check PSIF Manual, use manual steering.
RUD. STOPPED PSIF SET RUDDER FAIL: USE MANUAL STEERING	Alarm B	none	PSIF has not received a valid Set rudder. Rudder is frozen.	Check PSIF Manual, use manual steering.

Alert Title Alert Description	Category Priority	Escalation	Possible Cause	Remedy
PSIF RESTART PSIF SOFTWARE RESTART: CHECK PSIF	Warning B	none	PSIF was restarted by internal watchdog.	Check PSIF Manual.
RUD. STOPPED PSIF CAN BUS FAILURE: USE MANUAL STEERING	Warning B	as Warning	No CAN-connection between PSIF and Feedback Unit. Rudder is frozen.	Check PSIF Manual, use manual steering.
STEER. FAIL. PSIF STEERING FAILURE: USE MANUAL STEERING	Warning B	none	PSIF has detected a difference between set and actual rudder exceeding the config- ured limit. Should occur only if PSIF is controlling the rudder.	Check PSIF Manual, use manual steering.
SYSTEM FAIL. PSIF DA CONVERT- ER FAIL: USE MAN- UAL STEERING	Warning B	none	D/A-Failure detected during self-test or sig- nal fault discovered.	Check PSIF Manual, use manual steering.
SYSTEM FAIL. PSIF FRAM FAIL: USE MANUAL STEERING	Warning B	none	PSIF FRAM not ac- cessible. PSIF SYS FAIL. Rudder is frozen.	Check PSIF Manual, use manual steering.
SYSTEM FAIL. PSIF POW- ER FAILURE: USE MANUAL STEERING	Warning B	none	PSIF Power failure. PSIF SYS FAIL.	Check PSIF Manual, use manual steering.
CAN 1 FAIL PSIF: USING BACK- UP CAN2: CHECK WIRING	Caution B	none	Communication er- ror using CAN1, on- ly CAN2 as backup available.	Check CAN connec- tion.
CAN 2 FAIL PSIF: USING BACK- UP CAN1: CHECK WIRING	Caution B	none	Communication er- ror using CAN2, on- ly CAN1 as backup available.	Check CAN connec- tion.

Alert Title Alert Description	Category Priority	Escalation	Possible Cause	Remedy
GYRO FAILED PSIF GYRO HEADING FAILED: CHECK HDG SENSOR	Caution B	none	Gyro connected at PSIF failed.	Check Gyro connected to PSIF.
GYRO FAILED PSIF GYRO: SELECT OTHER HEADING SENSOR	Caution B	none	Gyro connected at PSIF failed.	Check Gyro connected to PSIF.
HCS UNAVAIL. PSIF FAILURE: CHECK PSIF	Caution B	none	PSIF is not responding, AP is in standby.	Check PSIF.
MAG FAIL. PSIF: CHECK MAGNETIC HEADING SENSOR	Caution B	none	Magnetic compass connected to PSIF failed.	Check magnetic compass connected to PSIF.
POS FAILED PSIF: CHECK POSITION SENSOR	Caution B	none	Position sensor connected to PSIF failed.	Check position sensor connected to PSIF.
SPD FAILED PSIF SPEED SENSOR FAILED: CHECK SPEED SENSOR	Caution B	none	Speed sensor connected to PSIF failed.	Check speed sensor connected to PSIF.

9.2.2

Alert IDs and Instances

Tab. 14: List of all Alert IDs and Instances

Alert ID	Alert Instance	Alert Title	Alert Description
3012	76	GYRO-MAG DIFF	HDG DIFFERENCE DETECTED: CHECK HDG SENSORS
3014	10	NO SPEED	TURN RADIUS MAY NOT MATCH
3014	4	TCS STOPPED	NO HEADING: USE MANUAL STEERING
3024	15	XTE EXCEEDED	OFF TRACK CROSS TRACK LIMIT EXCEEDED: xxxxm

Alert ID	Alert Instance	Alert Title	Alert Description
3059	169	HCS UNAVAIL.	NO HEADING: CHECK HEADING
3065	65	LOW SPEED	CTRL ACCURACY LIMITED: USE MANUAL STEERING
3156	157	NOT SPD ADAPTIVE	NO SPEED: CHECK SPEED SENSOR
18015	79	NO VALID SPD	SWITCH TO VALID SPEED SOURCE
18018	78	SPD IS VALID	VALID SPEED AVAILABLE: SWITCH SPD SOURCE
18032	79	POS VALID	POS AVAILABLE: SWITCH TO VALID POSITION
18078	78	POS INVALID	SWITCH TO VALID POSITION SOURCE
20008	59	HDG JUMPED	CHECK ACTUAL AND SET HEADING
20012	60	SPEED JUMPED	SPEED JUMP DETECTED: CHECK SPEED SENSOR
20015	61	SPD CHANGED	SPEED SENSOR CHANGED
20017	17	ACT. OU FAIL	CHECK AP OPERATOR UNIT
20018	80	MAG HDG SEL.	MAGNETIC HEADING USED FOR HEADING CONTROL
20022	81	BACKUP GYRO FAIL	NO BACKUP GYRO AVAILABLE
20027	16	SIM SENSOR DATA	SIMULATED SENSOR DATA IN USE: CHECK SENSORS
20055	97	RUDDER LIMIT	RUDDER LIMIT REACHED
20062	62	POS CHANGED	POSITION SENSOR CHANGED
20062	214	SET HDG REFUSED	COMMANDED SET HDG GREATER 270°: PLEASE REPEAT INPUT
20082	82	MAG FAILED	BACK UP HDG SENSOR FAILED: CHECK SENSOR
20098	98	SW INSTALL ERROR	SOFTWARE INSTALLATION ERROR PACKAGE E00.00
20103	183	NO SET HDG	SET HDG REJECTED: ENTER NEW SET HEADING

Alert ID	Alert Instance	Alert Title	Alert Description
20103	188	POS INVALID	SWITCH TO VALID POS SOURCE
20103	191	ACT. FAIL	DEVICE ACTIVATION NOT POSSIBLE
20103	193	NOT SPD ADAPTIVE	NO SPEED: CHECK SPEED SENSOR
20103	194	HCS UNAVAIL.	NO HEADING: CHECK HDG SENSORS
20103	195	HDG DOUBTFUL	FUNCTION NOT ACTIVATABLE
20103	198	NO TRC DATA	CHECK CONNECTION TO ECDIS
20103	201	HDG MON DIS.	HEADING MONITOR DISABLED
20103	202	POWER FAIL.	CHECK POWER SUPPLY
20109	109	OU CHANGE	ACTIVE OPERATOR UNIT CHANGED
20113	103	BACK. POS CHNG	BACKUP POSTION SENSOR CHANGED
20119	102	HDG UNCORR.	CHECK HEADING CORRECTION
20123	101	HDG CHANGE	SENSOR USED FOR CONTROL FUNCTION CHANGED
20126	111	SOFTWARE COPIED	SOFTWARE SUCCESSFULLY COPIED E00.00
20129	112	SW INST SKIPPED	SOFTWARE INSTALLATION SKIPPED
20143	158	MAG FAILED	BACK UP HDG SENSOR FAILED: CHECK SENSOR
20156	156	NO BACKUP GYRO	NO BACKUP GYRO AVAILABLE
20159	159	LOW SPEED	CTRL ACCURACY MAY BE LIMITED
20169	179	MAN.CAUT.TEST	MANUAL CAUTION TEST 000° SECOND LINE
3008, 3007	35, 144	TCS STOPPED	MAG HDG SELECTED: SELECT GYRO HEADING
3021 (HC)	1	HCS STOPPED	POWER FAILURE: CHECK POWER SUPPLY

Alert ID	Alert Instance	Alert Title	Alert Description
3022 (TC)	177	TCS STOPPED	POWER FAILURE: CHECK POWER SUPPLY
3023 (Standby)	178	HCS UNAVAIL.	POWER FAILURE: CHECK POWER SUPPLY
3025, 3024	74, 122	OFF HEADING	DEVIATED FROM SET HEADING: TAKE HELM
20162, 20161	32, 175	HCS UNAVAIL.	PSIF: AUTOPILOT ACTIVATION FAILED
20005	57	CHECK LIMITS	CHECK RUDDER/ROT/RAD LIMITS
20092	92	REM. OU FAIL	CHECK REMOTE OPERATOR UNITS
20205, 20204	95, 152	NO RUD. CTRL	NO RUDDER CTRL ON CAN: USE MANUAL STEERING
20208, 20207	96, 153	HCS UNAVAIL.	CANNOT ACTIVATE HCS: USE MANUAL STEERING

PilotStar® NX Operator Unit

IEC 61162-450 Support

102-820.NG001



Dieses Dokument sowie dessen Inhalt sind urheberrechtlich geschützt. Die Weitergabe, Vervielfältigung und Speicherung sowie die Übersetzung wie auch Verwendung dieses Dokuments oder dessen Inhalts, als Ganzes oder in Teilen und egal in welcher Form, ist ohne vorherige ausdrückliche schriftliche Genehmigung nicht gestattet. Zuwiderhandlungen verpflichten zu Schadenersatz.

Änderungen dieses Dokuments und dessen Inhalt bleiben vorbehalten.

This document and its content are copyright protected. Distribution, reproduction and storage as well as translation and exploitation of this document and its content, in whole or in parts and regardless of what form, are prohibited without prior express written permission. Offenders will be held liable for the payment of damages.

Changes and modification to this document and its content reserved.

Table of Contents

1	IEC 611162-450 Support.....	1
1.1	Ethernet Interface Requirements.....	1
1.2	Transmission Groups.....	2
1.3	Internal Logging.....	4
1.4	Maximum Input Data Rates.....	4
2	Interface Specification.....	5
2.1	ACK - Acknowledge Alert.....	5
2.2	ACN - Alert Command.....	5
2.3	ALC - Cyclic Alert List.....	6
2.4	ALF - Alert Sentence.....	6
2.5	ALR - Set Alert State.....	7
2.6	ARC - Alert Command Refused.....	7
2.7	GGA - Global Positioning System (GPS) Fix Data.....	8
2.8	GLL - Geographic Position – Latitude / Longitude.....	10
2.9	GNS - GNSS Fix Data.....	10
2.10	HBT - Heartbeat Supervision Sentence.....	11
2.11	HCR - Heading Correction Report.....	11
2.12	HDT - Heading True.....	12
2.13	RMC - Recommended Minimum Specific GNSS Data.....	12
2.14	ROT - Rate of Turn.....	13
2.15	THS - True Heading and Status.....	15
2.16	VBW - Dual Ground / Water Speed.....	15
2.17	VER - Version.....	16
2.18	VHW - Water Speed and Heading.....	17
2.19	VTG - Course Over Ground and Ground Speed.....	17
2.20	ZDA - Time and Date.....	18
2.21	PANZHRP.....	18

Table of Figures

Figure 1-1	Error Counter.....	4
------------	--------------------	---

Table of Tables

Table 1-1	Supported Transmission Groups for Alert Management.....	2
Table 1-2	Transmission Groups for Alert Management.....	3
Table 1-3	Default Settings for Transmission Groups.....	3

0 Introduction

0.1 Preliminary Remarks

The present manual has been drawn up as a description and reference book.
It will help answer questions and will solve problems in the quickest possible manner.

Before operating the equipment read and follow the instructions and hints in this manual.

For this purpose, refer to the table of contents and read the corresponding chapters thoroughly.
If you have any further questions, please contact us on the following address:

RAYTHEON ANSCHÜTZ GMBH
Zeyestr. 16 - 24
D-24106 Kiel
Germany

Tel. +49 431 / 3019 - 0
Fax +49 431 / 3019 - 291

All rights reserved. No part of this manual may be copied, neither mechanically, electronically, magnetically, manually nor otherwise, or distributed, forwarded or stored in a data bank without written permission of RAYTHEON ANSCHÜTZ GMBH.

Copyright:
RAYTHEON ANSCHÜTZ GMBH
Zeyestr. 16 - 24
D-24106 Kiel
Germany


Since errors can hardly be avoided in the documentation in spite of all efforts, we should appreciate any remark and suggestion.
Subject to alterations.


0.2 Change History


Date	Change
April 2021	First Edition


1 IEC 61162-450 Support


The autopilot PilotStar® NX supports communication compliant to IEC 61162-450.

	No router and repeater hubs are allowed within network compliant to IEC61162-450.
---	---

	The device does not provide any repeater hub functions.
---	---

	The underlying network for communication compliant to IEC 61162-450 is Ethernet based.
---	--

	SFIs are configured at system setup. At runtime it is not possible for the mariner to modify the SFIs of the system.
---	--

	The device supports IGMP-2.
---	-----------------------------

1.1 Ethernet Interface Requirements

All interface connections must meet the requirements of IEC 61162-450, IEC 61162-450 Edition 2.0 table 3 (type 100BASE-T).

1.2 Transmission Groups

The autopilot PilotStar® NX has per default the following transmissions groups:

For transmitting:

Transmission Group	Multicast Address	Destination Port	Changeable in
SATD	239.192.0.3	60003	Ethernet Input

For receiving:

Transmission Group	Multicast Address	Destination Port	Changeable in
NAVD	239.192.0.4	60004	Ethernet Output

Table 1-1 Supported Transmission Groups for Alert Management

Transmission Group	Multicast Address	Destination Port	Default Setting
MISC	239.192.0.1	60001	Active
TGTD	239.192.0.2	60002	Active
SATD	239.192.0.3	60003	Active
NAVD	239.192.0.4	60004	Active
VDRD	239.192.0.5	60005	Active
RCOM	239.192.0.6	60006	Active
TIME	239.192.0.7	60007	Active
PROP	239.192.0.8	60008	Active
USR1	239.192.0.9	60009	
USR2	239.192.0.10	60010	
USR3	239.192.0.11	60011	
USR4	239.192.0.12	60012	
USR5	239.192.0.13	60013	
USR6	239.192.0.14	60014	
USR7	239.192.0.15	60015	
USR8	239.192.0.16	60016	
NETA	239.192.0.56	60056	Active

For alert management, the following transmission groups can be activated or deactivated via the service menu page **Interfaces**:


Table 1-2 Transmission Groups for Alert Management

Transmission Group	Multicast Address	Destination Port	Default Setting
BAM1	239.192.0.17	60017	
BAM2	239.192.0.18	60018	
CAM1	239.192.0.19	60019	Active if BAM1 selected
CAM2	239.192.0.20	60020	Active if BAM2 selected

The following settings are preselected or selectable via the service menu page **Interfaces**.

Table 1-3 Default Settings for Transmission Groups

Transmission Group	Transmitting (max. 1 option)	Transmitting BAM (max. 1 option)	Transmitting SRP	Receiving
MISC	Selectable			Selectable
SATD				Preselected
NAVD	Preselected	Preselected		Preselected
TGTD				Selectable
TIME				Selectable
PROP	Selectable			Selectable
USR1 to USR8	Selectable			Selectable
BAM1		Selectable		
BAM2		Selectable		
CAM1				Selectable, preselected if BAM1 is selected for Transmitting BAM
CAM2				Selectable, preselected if BAM2 is selected for Transmitting BAM
NETA			Preselected	Preselected, not alterable

	Multicast addresses and destination ports are not configurable.
---	---

1.3 Internal Logging

The internal logging uses an internal logfile which contains internal error messages as well as syslog messages. Each error is listed with its number, a counter, the error code and the error message and is not sent to other devices, see also chapter 5.3.7.44 of the Operator and Service Manual.

Once the maximum number of messages is reached the counter is reset. The counter is also reset once the system is started. The counter is found within the service menu, see chapter 5.3.6.1 of the Operator and Service Manual.



Figure 1-1 Error Counter

1.4 Maximum Input Data Rates

The maximum input rates for the autopilot PilotStar® NX are:

- Maximum number of datagrams per second received, intended for and processed by the equipment = 30
- Maximum number of datagrams per second received by, but not intended for the equipment = 50
- Maximum number of datagrams per second received by, but not intended for the equipment at 50% of the maximum load for item a) = 20

2 Interface Specification

The following telegrams can be sent / received via serial connection or via Ethernet (UDP) or via Ethernet (IEC 61162-450) depending on configuration.

2.1 ACK - Acknowledge Alert

Acknowledge device alert. This sentence is used to acknowledge an alert condition reported by a device.

Input only, cycle on event

```
$--ACK, xxx*hh<CR><LF>  
  a    b
```

- a) ACK identifier for acknowledge alert
- b) Unique alert number (identifier) at alert source

Talker: All

2.2 ACN - Alert Command

This sentence is used for acknowledge, request, mute / silence alerts at the autopilot.

Input only, cycle on event

NP5100-NP5500: Not all sentences are used or transmitted by each Autopilot type. The types are marked if the sentence is applicable for that.

```
$--ACN, hhmmss.ss, aaa, x.x, x.x, c, a*hh<CR><LF>  
  a      b      c    d    e    f    g
```

- a) ACN identifier for alert command
- b) Time
- c) Manufacturer mnemonic code
- d) Alert identifier
- e) Alert instance, 1 to 999999
- f) Alert command, A, Q, O or S
- g) Sentence status flag

Talker: All

2.3 ALC - Cyclic Alert List

The ALC sentence provides condensed ALF sentence information. It contains the identifying data for each present alert of one certain source / device so that the receiver can understand which ALF has been missed (and retransmission of ALF can be requested by using the ACN sentence). It shall be published cyclically at least every 30 s by each alert generating device. When all alerts are in normal state the cyclic alert list is empty.

Output only, cycle on event and every 30 s

```
$--ALC, xx, xx, xx, x.x, aaa, x.x, x.x, x.x, ..... , aaa, x.x, x.x, x.x*hh<CR><LF>  
  a  b  c  d  e  f  g  h  i  j  k  l  m  n
```

- a) ALC identifier for cyclic alert list
- b) Total number of sentences for this message, 01 to 99
- c) Sentence number, 01 to 99
- d) Sequential message identifier, 00 to 99
- e) Number of alert entries
- f) Manufacturer mnemonic code alert entry 1
- g) Alert identifier alert entry 1
- h) Alert instance alert entry 1
- i) Revision counter alert entry 1
- j) Additional alert entries
- k) Alert entry n

Talker: HE

2.4 ALF - Alert Sentence

This sentence is used to report an alert condition and the alert state of a device. An ALF message shall be published for an alert each time the alert information in this sentence changes and on alert request.

Output only, cycle on event

```
$--ALF, x, x, x, hhmmss.ss, a, a, a, aaa, x.x, x.x, x.x, x, c---c*hh<CR><LF>  
  a  b  c  d      e      f  g  h  I  j  k  l  m  n
```

- a) ALF identifier for alert sentence
- b) Total number of ALF sentences for this message, 1 to 2
- c) Sentence number, 1 to 2

- d) Sequential message identifier, 0 to 9
- e) Time of last change
- f) Alert category, A, B or C
- g) Alert priority, E, A, W or C
- h) Alert state, A, S, N, O, U or V
- i) Manufacturer mnemonic code
- j) Alert identifier
- k) Alert instance, 1 to 999999
- l) Revision counter, 1 to 99
- m) Escalation counter, 0 to 9
- n) Alert text

Talker: HE

2.5 ALR - Set Alert State

Local alert condition and status. This sentence is used to report an alert condition on a device and its current state of acknowledgement.

Output only, cycle on event

```
$--ALR, hhmmss.ss, xxx, A, A, c---c*hh<CR><LF>
      a      b      c  d e  f
```

- a) ALR identifier for set alert state
- b) Time of alert condition change, UTC
- c) Unique alert number (identifier) at alert source
- d) Alert condition (A = threshold exceeded, V = not exceeded)
- e) Alert's acknowledge state, A = acknowledged, V = unacknowledged
- f) Alert's description text

The BNWAS Mgr. NMEA interface transmits only the emergency call (navigator alert) telegram:

Navigator alert unacknowledged:

```
$AGALR,,260,A,V,Emergency Call*0C<CR><LF>
```

Navigator alert acknowledged:

```
$AGALR,,260,A,A,Emergency Call*0A<CR><LF>
```

Talker: HE

2.6 ARC - Alert Command Refused

This sentence is used for:

Category A or C alerts (see IMO MSC.302(87)), for which it is illegal to accept acknowledge or responsibility transfer.

Category B (see IMO MSC.302(87)), if the source of acknowledge is not acceptable.

Output only, cycle on event

```
$--ARC, hmmmss.ss, aaa, x.x, x.x, c---c*hh<CR><LF>  
      a      b      c  d  e      f
```

- a) ARC identifier for alert command refused
- b) Time
- c) Manufacturer mnemonic code
- d) Alert identifier
- e) Alert instance, 1 to 999999
- f) Refused alert command, A, Q, O or S

Talker: HE

2.7 GGA - Global Positioning System (GPS) Fix Data

Time, position and fix-related data for a GPS receiver.

Input only, cycle adjustable 1 Hz, 10 Hz, 50 Hz, default 1 Hz

```
$--GGA, hmmmss.ss, lll.ll, a, yyyyy.yy, a, x, xx, x.x, x.x, M, x.x, M, x.x, xxxx*hh<CR><LF>  
      a      b      c  d  e      f g h i  j  k  l  m  n      o
```

- a) GGA for GPS fix data
- b) UTC of position
- c) Latitude
- d) N/S
- e) Longitude
- f) E/W
- g) GPS quality indicator
- h) Number of satellites in use, 00-12, may be different from the number in view
- i) Horizontal dilution of precision
- j) Antenna altitude above / below mean sea level (geoid)
- k) Units of antenna altitude, m
- l) Geoidal separation
- m) Units of geoidal separation, m
- n) Age of differential GPS data
- o) Differential reference station ID, 0000-1023

Fields h-o not used.

Only quality indicators 1, 2, 3 are accepted.

Accepted talker: GA, GL, GN, GP, II, IN, for serial NMEA

2.8 GLL - Geographic Position – Latitude / Longitude

Latitude and longitude of vessel position, time of position fix and status.

Input only, cycle adjustable 1 Hz, 10 Hz, 50 Hz, default 1 Hz

```
$--GLL, llll.ll, a, yyyyy.yy, a, hhmss.ss, A, a*hh<CR><LF>  
      a      b      c      d      e      f      g      h
```

- a) GLL for geographic position – latitude / longitude
- b) Latitude
- c) N/S
- d) Longitude
- e) E/W
- f) UTC of position
- g) Status A=data valid, V=data invalid
- h) Mode indicator

Only mode indicators A, D, E are accepted.

Accepted talker: GA, GL, GN, GP, LC, II, IN for Serial NMEA

2.9 GNS - GNSS Fix Data

Fix data for single or combined satellite navigation systems (GNSS). This sentence provides fix data for GPS, GLONASS, possible future satellite systems and systems combining these. This sentence could be used with the talker identification of GP for GPS, GL for GLONASS, GA for Galileo, GN for GNSS combined systems, as well as future identifiers.

Input only, cycle adjustable 1 Hz, 10 Hz, 50 Hz, default 1 Hz

```
$--GNS, hhmss.ss, llll.ll, a, yyyyy.yy, a, c-c, xx, x.x, x.x, x.x, x.x, x.x, a*hh<CR><LF>  
      a      b      c      d      e      f      g      h      i      j      k      l      m      n
```

- a) GNS for GNSS fix data
- b) UTC of position
- c) Latitude
- d) N/S
- e) Longitude
- f) E/W
- g) Mode indicator
- h) Total number of satellites in use, 00-99
- i) Horizontal dilution of precision
- j) Antenna altitude, m, re: mean sea level (geoid)

- k) Geoidal separation, m
- l) Age of differential data
- m) Differential reference station ID
- n) Navigational status indicator

Fields h-m not used.

Only quality indicators A, D are accepted.

Navigational status indicator S is accepted.

Accepted talker: GA, GL, GN, GP, II, IN, for serial NMEA

2.10 HBT - Heartbeat Supervision Sentence

This sentence is intended to be used to indicate that equipment is operating normally. The sentence is transmitted at regular intervals specified in the corresponding equipment standard.

Output only, cycle every 10 s (adjustable 5 to 30 s)

```
$--HBT, x.x, A, x*hh<CR><LF>  
      a   b   c   d
```

- a) HBT identifier for heartbeat supervision sentence
- b) Configured repeat interval
- c) Equipment status
- d) Sequential sentence identifier

Talker: HE

2.11 HCR - Heading Correction Report

This sentence is used to inform the state and value of a heading correction included in the heading reported by the THS sentence when the heading source can apply a correction.

This sentence requires tight synchronization with THS sentence. This sentence should be sent immediately prior to every THS sentence for which the correction state field has changed compared to the previous THS sentence. For all correction states the HCR sentence should be transmitted periodically at intervals of not greater than 1,0 s.

Output only, cycle adjustable 1 Hz, 10 Hz, 50 Hz

```
$--HCR, x.x, a, a, x.x*hh<CR><LF>  
      a   b   c   d   e
```

- a) HCR identifier for heading correction report
- b) Heading, degrees true¹
- c) Mode indicator²
- d) Correction state³
- e) Correction value⁴

Comments:

- 1) Value of heading for which this HCR is referenced. This value is not replacing heading value from the THS sentence. This value is used for synchronization between high data rate of THS sentence and low data rate of HCR sentence.
- 2) Mode indicator. This field should not be null.
 - A = Autonomous
 - E = Estimated (dead reckoning)
 - M = Manual input
 - S = Simulator mode
 - V = Data not valid (including standby)
- 3) Correction state. This field should not be null.
 - A = Both speed / latitude and dynamic correction included in heading
 - D = Dynamic correction included in heading
 - S = Speed / latitude correction included in heading
 - N = No correction included in heading
 - V = Not available, reporting device does not know about correction state
- 4) Value of correction included in heading. Degrees +/- 180,0° with 1 decimal. Null field indicates correction state N (no correction included) or V (not available).

Talker: HE

2.12 HDT - Heading True

Actual vessel heading in degrees true produced by any device or system producing true heading.

Output only, cycle adjustable 1 Hz, 10 Hz, 50 Hz

\$--HDT, x.x, T*hh<CR><LF>

a b c

- a) HDT for heading true
- b) Heading [degrees]
- c) T, true

Talker: HE

2.13 RMC - Recommended Minimum Specific GNSS Data

RMC and RMB are the recommended minimum data to be provided by a GNSS receiver. All data fields should be provided, null fields used only when data is temporarily unavailable.

Input only, cycle adjustable 1 Hz, 10 Hz, 50 Hz, default 1 Hz

```
$--RMC, hhmmss.ss, A, llll.ll, a, yyyy.yy, a, x.x, x.x, xxxxxx, x.x, a, a, a*hh<CR><LF>  
      a      b      c      d      e      f      g      h      i      j      k      l      m      n
```

- a) RMC for recommended minimum specific GNSS data
- b) UTC of position fix
- c) Status A = data valid V = navigation receiver warning
- d) Latitude
- e) N/S
- f) Longitude
- g) E/W
- h) Speed over ground, knots
- i) Course over ground, degrees true
- j) Date: dd/mm/yy
- k) Magnetic variation, degrees
- l) E/W
- m) Mode indicator
- n) Navigational status

Fields k, l are not used.

Only mode indicators A, D are accepted. Navigational status indicator S is accepted.

Accepted talker: GA, GL, GN, GP, II, IN, for serial NMEA

2.14 ROT - Rate of Turn

Rate of turn and direction of turn.

Output only, cycle adjustable 1 Hz, 10 Hz, 50 Hz

```
$--ROT, x.x, A*hh<CR><LF>  
      a      b      c
```

- a) ROT for rate of turn
- b) Rate of turn, °/min, "-" = bow turns to port
- c) Status: A = data valid
 v = data invalid

Talker: HE, TI

2.15 THS - True Heading and Status

Actual vessel heading in degrees true produced by any device or system producing true heading. This sentence includes a mode indicator field providing critical safety related information about the heading data, and replaces the deprecated HDT sentence.

Output only, cycle adjustable 1 Hz, 10 Hz, 50 Hz


```
$--THS,x.x,a*hh<CR><LF>
      a  b  c
```

- a) THS for True heading and status
- b) Heading, true [degrees]
- c) Mode indicator

Only mode indicator A is accepted.

Accepted talker: GP, HC, HE, HF

Transmitted talker: HE, GP

	<p>This sentence replaces the deprecated sentence HDT.</p>
---	--

Talker: HE

2.16 VBW - Dual Ground / Water Speed

Water-referenced and ground-referenced speed data

Input only, cycle adjustable 1 Hz, 10 Hz, 50 Hz, default 1 Hz

```
$--VBW,x.x,x.x,A,x.x,x.x,A,x.x,A,x.x,A*hh<CR><LF>
      a  b  c  d  e  f  g  h  i  j  k
```

- a) VBW for dual ground / water speed
- b) Longitudinal water speed [kn]
- c) Transverse water speed [kn]
- d) Status: water speed, A = data valid, V = data invalid
- e) Longitudinal ground speed [kn]
- f) Transverse ground speed [kn]
- g) Status, ground speed, A = data valid, V = data invalid

- h) Stern transverse water speed [kn]
- i) Status: stern water speed, A = data valid, V = data invalid
- j) Stern transverse ground speed [kn]
- k) Status: stern ground speed, A = data valid, V = data invalid

Fields c, h - k are not used.

Accepted talker: GA, GL, GN, GP, VD, VM, VW, II, IN

2.17 VER - Version

This sentence is used to provide identification and version information about a device. This sentence is produced as a reply to a query sentence.

In order to meet the 79-character requirement, a multi-sentence message may be needed to convey all the data fields.

Output only, cycle every 120 s (adjustable 60 to 120 s)

```
$--VER, x, x, aa, c--c, c--c, c--c, c--c, c--c, c--c, ·x*hh<CR><LF>  
  a  b  c  d  e      f      g      h      i      j      k
```

- a) VER for version
- b) Total number of sentences needed, 1 to 9: 3
 (1 = System, 2 = Sensor PCB, 3 = OS PCB)
- c) Sentence number, 1 to 9: 1 to 3
- d) Device type: HE
- e) Vendor ID: ANZ
- f) Unique identifier: STD30 NX-1
- g) Manufacturer serial number: 4006247xxxxxx
- h) Model code (product code): 110-244.NG001
- i) Software revision: 110-244.P0001 Exx.xx
- j) Hardware revision: NB06-367 Exx
- k) Sequential message identifier

Talker: HE

2.18 VHW - Water Speed and Heading

The compass heading to which the vessel points and the speed of the vessel relative to the water.

Input only, cycle adjustable 1 Hz, 10 Hz, 50 Hz, default 1 Hz

```
$--VHW,x.x,T,x.x,M,x.x,N,x.x,K*hh<CR><LF>  
  a  b  c  d  e  f  g  h  i
```

- a) VHW for water speed and heading
- b) Heading true [degrees]
- c) T, true
- d) Heading magnetic [degrees]
- e) M, magnetic
- f) Speed [kn]
- g) N, knots
- h) Speed [km/h]
- i) K, km/h

Fields b - e and h - i are not used when receiving or sending.

Accepted talker: GA, GL, GN, GP, VD, VM, VW, II, IN

2.19 VTG - Course Over Ground and Ground Speed

The actual course and speed relative to the ground.

Input only, cycle adjustable 1 Hz, 10 Hz, 50 Hz, default 1 Hz

```
$--VTG,x.x,T,x.x,M,x.x,N,x.x,K,K*hh<CR><LF>  
  a  b  c  d  e  f  g  h  i  j
```

- a) VTG for course over ground and ground speed
- b) Course over ground, true [degrees]
- c) T, true
- d) Course over ground magnetic [degrees]
- e) M, magnetic
- f) Speed over ground [kn]
- g) N, knots
- h) Speed over ground [km/h]
- i) K, km/h
- j) Mode indicator

Fields h - i are not used. Field d is used if field b is empty.

Accepted talker: GA, GL, GN, GP, LC, VD, VM, VW, II, IN

2.20 ZDA - Time and Date

UTC, day, month, year and local time zone.

Input only, cycle adjustable 1 Hz, 10 Hz, 50 Hz, default 1 Hz

\$--ZDA, hhmmss.ss, xx, xx, xxxx, xx, xx*hh<CR><LF>
a b c d e f g

- a) ZDA for time and date
- b) UTC
- c) Day, 01 to 31 (UTC)
- d) Month, 01 to 12 (UTC)
- e) Year (UTC)
- f) Local zone hours (see note), 00 h to ±13 h
- g) Local zone minutes (see note), 00 to +59

Fields f - g are not used.

Accepted talker: all

2.21 PANZHRP



Private data sentence for HEADING, ROLL, PITCH according to NMEA183 version 2.0

\$--PANZHRP, x, x.x, x.x, x.x, x.x, x.x, x.x, x.x, a, a*hh, <CR><LF>
a b c d e f g h i j k

- a) Private identifier
- b) Sentence identifier
- c) Source
- d) Heading angle
- e) Roll angle
- f) Pitch angle
- g) Heading angular rate
- h) Roll angular rate
- i) Pitch angular rate
- j) Status
- k) Selection (optional)


Intentionally left blank

For this technical document all rights reserved.



TYPE OF ENCLOSURE: EN 60529 IP23/IP56 FRONT-SIDED
 EVENNESS OF MOUNTING SURFACE < 0.1mm
 DIMENSIONS WITHOUT TOLERANCES ARE MAXIMUM DIMENSIONS

		CAD: Pro/E	ID. NO. 5023317
		SCALE -	WEIGHT ca. 1,5
			DRAWING TITLE Operator Unit PilotStar NX DIMENSIONAL DRAWING
00	500000038693	24.06.14	Zm
VER.	REVISIONS	DATE OF ISSUE	
		DRAWING NO. 102-820.HP005	
		SHEET 1 OF 1	



CAD		B 5030_01	ID.NR.	5025976
MASSSTAB		1:1		
WERKSTOFF				
BENENNUNG		OPERATOR UNIT PILOTSTAR NX ANSCHLUSSPLAN / CONNECTION DIAGRAM		
ERSTELLT DURCH		KOHL		
GENEHMIGT VON		STOFFER		
VER.		01	50000044142	01.08.2019
ANDERUNG		00	50000038693	23.11.2016
AUSGABEDATUM		NAME		
ZEICHNUNGSNUMMER		102-820.HP008		
BLATT		1		
VON		1		



PilotStar® NX Operator Unit

Illustrated Spare Parts Catalog

102-820.NG001



Dieses Dokument sowie dessen Inhalt sind urheberrechtlich geschützt. Die Weitergabe, Vervielfältigung und Speicherung sowie die Übersetzung wie auch Verwendung dieses Dokuments oder dessen Inhalts, als Ganzes oder in Teilen und egal in welcher Form, ist ohne vorherige ausdrückliche schriftliche Genehmigung nicht gestattet. Zuwiderhandlungen verpflichten zu Schadenersatz.

Änderungen dieses Dokuments und dessen Inhalt bleiben vorbehalten.

This document and its content are copyright protected. Distribution, reproduction and storage as well as translation and exploitation of this document and its content, in whole or in parts and regardless of what form, are prohibited without prior express written permission. Offenders will be held liable for the payment of damages.

Changes and modification to this document and its content reserved.

Illustrated Spare Parts Catalog


Content

00-0000 PilotStar® NX Operator Unit

Intentionally left blank

Definitions

Col.	Description
1	Fig. No. The figure number gives the relation to the respective figure.
2	Item No. The item number gives the relation to the position number on the respective figure.
3	Designation This column comprises the designation of a spare part.
4A	Supplier This column comprises the name of the manufacturer. If column 4A and 4b contain only one name, then the supplier is also the manufacturer.
4B	Manufacturer This column comprises the name of the manufacturer. If column 4A and 4b contain only one name, then the supplier is also the manufacturer.
5A	Supplier Part No. This column comprises the supplier part number of the spare part.
5B	Manufacturer Part No. This column comprises the manufacturer part number of the spare part.
6	UOI (Unit of Issue) The unit of issue determines the measure-, weight-, count or the packing drum units for the supply of the spare parts. EA = Each, MR = Meter, SE = Set, GR = Gramm
7	QI (Quantity Installed) This column gives the installed quantity of the spare part only for this unit or subunit.
8	Remarks This column gives more information about the spare part.



PilotStar® NX Operator Unit

00-0000, Sheet 1 of 1

Fig. No.	Item No.	Designation	Manufacturer Supplier	Manufacturer Part No. Supplier Part No	UOI	QI	Remarks
00-0000	01	PilotStar® NX Operator Unit	Raytheon Anschutz	4006050	EA	1	No color
00-0000	01	PilotStar® NX Operator Unit	Raytheon Anschutz	4006051	EA	1	Color RAL 7012
00-0000	01	PilotStar® NX Operator Unit	Raytheon Anschutz	4006052	EA	1	Color RAL 9005
00-0000	02	Nut	Raytheon Anschutz	1500299	EA	4	
00-0000	03	Washer, contact	Ettinger GmbH Raytheon Anschutz	03.20.049 1620363	EA	4	
00-0000	04	Frame, Mounting	Raytheon Anschutz	4005216	EA	1	Not illustrated
00-0000	05	2Port Serial Device Server	Moxa Raytheon Anschutz	NPORT 5232-T 2012319	EA	1	Not illustrated

Apache License
Version 2.0, January 2004
<http://www.apache.org/licenses/>

TERMS AND CONDITIONS FOR USE, REPRODUCTION, AND DISTRIBUTION

1. Definitions.

"License" shall mean the terms and conditions for use, reproduction, and distribution as defined by Sections 1 through 9 of this document.

"Licensor" shall mean the copyright owner or entity authorized by the copyright owner that is granting the License.

"Legal Entity" shall mean the union of the acting entity and all other entities that control, are controlled by, or are under common control with that entity. For the purposes of this definition, "control" means (i) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (ii) ownership of fifty percent (50%) or more of the outstanding shares, or (iii) beneficial ownership of such entity.

"You" (or "Your") shall mean an individual or Legal Entity exercising permissions granted by this License.

"Source" form shall mean the preferred form for making modifications, including but not limited to software source code, documentation source, and configuration files.

"Object" form shall mean any form resulting from mechanical transformation or translation of a Source form, including but not limited to compiled object code, generated documentation, and conversions to other media types.

"Work" shall mean the work of authorship, whether in Source or Object form, made available under the License, as indicated by a copyright notice that is included in or attached to the work (an example is provided in the Appendix below).

"Derivative Works" shall mean any work, whether in Source or Object form, that is based on (or derived from) the Work and for which the editorial revisions, annotations, elaborations, or other modifications represent, as a whole, an original work of authorship. For the purposes of this License, Derivative Works shall not include works that remain separable from, or merely link (or bind by name) to the interfaces of, the Work and Derivative Works thereof.

"Contribution" shall mean any work of authorship, including the original version of the Work and any modifications or additions to that Work or Derivative Works thereof, that is intentionally submitted to Licensor for inclusion in the Work by the copyright owner

or by an individual or Legal Entity authorized to submit on behalf of the copyright owner. For the purposes of this definition, "submitted" means any form of electronic, verbal, or written communication sent to the Licensor or its representatives, including but not limited to communication on electronic mailing lists, source code control systems, and issue tracking systems that are managed by, or on behalf of, the Licensor for the purpose of discussing and improving the Work, but excluding communication that is conspicuously marked or otherwise designated in writing by the copyright owner as "Not a Contribution."

"Contributor" shall mean Licensor and any individual or Legal Entity on behalf of whom a Contribution has been received by Licensor and subsequently incorporated within the Work.

2. Grant of Copyright License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable copyright license to reproduce, prepare Derivative Works of, publicly display, publicly perform, sublicense, and distribute the Work and such Derivative Works in Source or Object form.
3. Grant of Patent License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable (except as stated in this section) patent license to make, have made, use, offer to sell, sell, import, and otherwise transfer the Work, where such license applies only to those patent claims licensable by such Contributor that are necessarily infringed by their Contribution(s) alone or by combination of their Contribution(s) with the Work to which such Contribution(s) was submitted. If You institute patent litigation against any entity (including a cross-claim or counterclaim in a lawsuit) alleging that the Work or a Contribution incorporated within the Work constitutes direct or contributory patent infringement, then any patent licenses granted to You under this License for that Work shall terminate as of the date such litigation is filed.
4. Redistribution. You may reproduce and distribute copies of the Work or Derivative Works thereof in any medium, with or without modifications, and in Source or Object form, provided that You meet the following conditions:
 - (a) You must give any other recipients of the Work or Derivative Works a copy of this License; and
 - (b) You must cause any modified files to carry prominent notices stating that You changed the files; and
 - (c) You must retain, in the Source form of any Derivative Works that You distribute, all copyright, patent, trademark, and attribution notices from the Source form of the Work, excluding those notices that do not pertain to any part of

the Derivative Works; and

(d) If the Work includes a "NOTICE" text file as part of its distribution, then any Derivative Works that You distribute must

include a readable copy of the attribution notices contained within such NOTICE file, excluding those notices that do not pertain to any part of the Derivative Works, in at least one of the following places: within a NOTICE text file distributed as part of the Derivative Works; within the Source form or documentation, if provided along with the Derivative Works; or, within a display generated by the Derivative Works, if and wherever such third-party notices normally appear. The contents of the NOTICE file are for informational purposes only and do not modify the License. You may add Your own attribution notices within Derivative Works that You distribute, alongside or as an addendum to the NOTICE text from the Work, provided that such additional attribution notices cannot be construed as modifying the License.

You may add Your own copyright statement to Your modifications and may provide additional or different license terms and conditions for use, reproduction, or distribution of Your modifications, or for any such Derivative Works as a whole, provided Your use, reproduction, and distribution of the Work otherwise complies with the conditions stated in this License.

5. Submission of Contributions. Unless You explicitly state otherwise, any Contribution intentionally submitted for inclusion in the Work by You to the Licensor shall be under the terms and conditions of this License, without any additional terms or conditions. Notwithstanding the above, nothing herein shall supersede or modify the terms of any separate license agreement you may have executed with Licensor regarding such Contributions.

6. Trademarks. This License does not grant permission to use the trade names, trademarks, service marks, or product names of the Licensor, except as required for reasonable and customary use in describing the origin of the Work and reproducing the content of the NOTICE file.

7. Disclaimer of Warranty. Unless required by applicable law or agreed to in writing, Licensor provides the Work (and each Contributor provides its Contributions) on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied, including, without limitation, any warranties or conditions of TITLE, NON-INFRINGEMENT, MERCHANTABILITY, or FITNESS FOR A PARTICULAR PURPOSE. You are solely responsible for determining the appropriateness of using or redistributing the Work and assume any risks associated with Your exercise of permissions under this License.

8. Limitation of Liability. In no event and under no legal theory, whether in tort (including negligence), contract, or otherwise, unless required by applicable law (such as deliberate and grossly negligent acts) or agreed to in writing, shall any Contributor be liable to You for damages, including any direct, indirect, special, incidental, or consequential damages of any character arising as a result of this License or out of the use or inability to use the

Work (including but not limited to damages for loss of goodwill, work stoppage, computer failure or malfunction, or any and all other commercial damages or losses), even if such Contributor has been advised of the possibility of such damages.

9. Accepting Warranty or Additional Liability. While redistributing the Work or Derivative Works thereof, You may choose to offer, and charge a fee for, acceptance of support, warranty, indemnity, or other liability obligations and/or rights consistent with this License. However, in accepting such obligations, You may act only on Your own behalf and on Your sole responsibility, not on behalf of any other Contributor, and only if You agree to indemnify, defend, and hold each Contributor harmless for any liability incurred by, or claims asserted against, such Contributor by reason of your accepting any such warranty or additional liability.

END OF TERMS AND CONDITIONS

APPENDIX: How to apply the Apache License to your work.

To apply the Apache License to your work, attach the following boilerplate notice, with the fields enclosed by brackets "[]" replaced with your own identifying information. (Don't include the brackets!) The text should be enclosed in the appropriate comment syntax for the file format. We also recommend that a file or class name and description of purpose be included on the same "printed page" as the copyright notice for easier identification within third-party archives.

Copyright [yyyy] [name of copyright owner]

Licensed under the Apache License, Version 2.0 (the "License");
you may not use this file except in compliance with the License.
You may obtain a copy of the License at

<http://www.apache.org/licenses/LICENSE-2.0>

Unless required by applicable law or agreed to in writing, software distributed under the License is distributed on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied.

See the License for the specific language governing permissions and limitations under the License.

LICENSE ISSUES
=====

The OpenSSL toolkit stays under a dual license, i.e. both the conditions of the OpenSSL License and the original SSLeay license apply to the toolkit.

See below for the actual license texts. Actually both licenses are BSD-style

Open Source licenses. In case of any license issues related to OpenSSL please contact openssl-core@openssl.org.

OpenSSL License

```
/* =====  
* Copyright (c) 1998-2011 The OpenSSL Project. All rights reserved.  
*  
* Redistribution and use in source and binary forms, with or without  
* modification, are permitted provided that the following conditions  
* are met:  
*  
* 1. Redistributions of source code must retain the above copyright  
* notice, this list of conditions and the following disclaimer.  
*  
* 2. Redistributions in binary form must reproduce the above copyright  
* notice, this list of conditions and the following disclaimer in  
* the documentation and/or other materials provided with the  
* distribution.  
*  
* 3. All advertising materials mentioning features or use of this  
* software must display the following acknowledgment:  
* "This product includes software developed by the OpenSSL Project  
* for use in the OpenSSL Toolkit. (http://www.openssl.org/)"  
*  
* 4. The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used  
to  
* endorse or promote products derived from this software without  
* prior written permission. For written permission, please contact  
* openssl-core@openssl.org.  
*  
* 5. Products derived from this software may not be called "OpenSSL"  
* nor may "OpenSSL" appear in their names without prior written  
* permission of the OpenSSL Project.  
*  
* 6. Redistributions of any form whatsoever must retain the following  
* acknowledgment:  
* "This product includes software developed by the OpenSSL Project  
* for use in the OpenSSL Toolkit (http://www.openssl.org/)"  
*  
* THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT ``AS IS'' AND ANY  
* EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE  
* IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR  
* PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR  
* ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL,  
* SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT  
* NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES;  
* LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)  
* HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT,
```



```
* STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE)
* ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED
* OF THE POSSIBILITY OF SUCH DAMAGE.
* =====
*
* This product includes cryptographic software written by Eric Young
* (eay@cryptsoft.com). This product includes software written by Tim
* Hudson (tjh@cryptsoft.com).
*
*/
```

Original SSLeay License

```
/* Copyright (C) 1995-1998 Eric Young (eay@cryptsoft.com)
* All rights reserved.
*
* This package is an SSL implementation written
* by Eric Young (eay@cryptsoft.com).
* The implementation was written so as to conform with Netscapes SSL.
*
* This library is free for commercial and non-commercial use as long as
* the following conditions are aheared to. The following conditions
* apply to all code found in this distribution, be it the RC4, RSA,
* lhash, DES, etc., code; not just the SSL code. The SSL documentation
* included with this distribution is covered by the same copyright terms
* except that the holder is Tim Hudson (tjh@cryptsoft.com).
*
* Copyright remains Eric Young's, and as such any Copyright notices in
* the code are not to be removed.
* If this package is used in a product, Eric Young should be given
attribution
* as the author of the parts of the library used.
* This can be in the form of a textual message at program startup or
* in documentation (online or textual) provided with the package.
*
* Redistribution and use in source and binary forms, with or without
* modification, are permitted provided that the following conditions
* are met:
* 1. Redistributions of source code must retain the copyright
* notice, this list of conditions and the following disclaimer.
* 2. Redistributions in binary form must reproduce the above copyright
* notice, this list of conditions and the following disclaimer in the
* documentation and/or other materials provided with the
distribution.
* 3. All advertising materials mentioning features or use of this
software
* must display the following acknowledgement:
* "This product includes cryptographic software written by
* Eric Young (eay@cryptsoft.com)"
* The word 'cryptographic' can be left out if the rouines from the
library
* being used are not cryptographic related :-).
* 4. If you include any Windows specific code (or a derivative thereof)
from
* the apps directory (application code) you must include an
acknowledgement:
* "This product includes software written by Tim Hudson
(tjh@cryptsoft.com)"
*
```

* THIS SOFTWARE IS PROVIDED BY ERIC YOUNG ``AS IS'' AND
* ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE
* IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR
PURPOSE
* ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE
LIABLE
* FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR
CONSEQUENTIAL
* DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE
GOODS
* OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)
* HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT,
STRICT
* LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY
WAY
* OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF
* SUCH DAMAGE.
*
* The licence and distribution terms for any publically available
version or
* derivative of this code cannot be changed. i.e. this code cannot
simply be
* copied and put under another distribution licence
* [including the GNU Public Licence.]
*/

GNU LESSER GENERAL PUBLIC LICENSE

The Qt Toolkit is Copyright (C) 2015 The Qt Company Ltd.
Contact: <http://www.qt.io/licensing/>

You may use, distribute and copy the Qt GUI Toolkit under the terms of GNU Lesser General Public License version 2.1, which is displayed below.

GNU LESSER GENERAL PUBLIC LICENSE
Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc.
51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA
Everyone is permitted to copy and distribute verbatim copies
of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts
as the successor of the GNU Library Public License, version 2, hence
the version number 2.1.]

Preamble

The licenses for most software are designed to take away your
freedom to share and change it. By contrast, the GNU General Public
Licenses are intended to guarantee your freedom to share and change
free software--to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some
specially designated software packages--typically libraries--of the
Free Software Foundation and other authors who decide to use it. You
can use it too, but we suggest you first think carefully about whether
this license or the ordinary General Public License is the better
strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use,
not price. Our General Public Licenses are designed to make sure that
you have the freedom to distribute copies of free software (and charge
for this service if you wish); that you receive source code or can get
it if you want it; that you can change the software and use pieces of
it in new free programs; and that you are informed that you can do
these things.

To protect your rights, we need to make restrictions that forbid
distributors to deny you these rights or to ask you to surrender these
rights. These restrictions translate to certain responsibilities for
you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis
or for a fee, you must give the recipients all the rights that we gave
you. You must make sure that they, too, receive or can get the source
code. If you link other code with the library, you must provide
complete object files to the recipients, so that they can relink them
with the library after making changes to the library and recompiling
it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the
library, and (2) we offer you this license, which gives you legal
permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

GNU LESSER GENERAL PUBLIC LICENSE
TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) The modified work must itself be a software library.
- b) You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.
- c) You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.
- d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful.

(For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

a) Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)

b) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.

c) Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.

d) If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.

e) Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you

distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.

b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Libraries

If you develop a new library, and you want it to be of the greatest possible use to the public, we recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

To apply these terms, attach the following notices to the library. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the library's name and a brief idea of what it does.>

Copyright (C) <year> <name of author>

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details.

You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Also add information on how to contact you by electronic and paper mail.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the library, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the library `Frob' (a library for tweaking knobs) written by James Random Hacker.

<signature of Ty Coon>, 1 April 1990
Ty Coon, President of Vice

That's all there is to it!